



Assembly Instructions




General Assembly Guidelines

- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are wood dowels, screws and bolts.
- V. A Phillips head screwdriver is required for the assembly of this product.




- VI. Power tools should not be used to assemble this product.



Parts List











The side drawer with WARNING LABEL, should be mouted in highest drawer.




Part#	Description	Qty
1	Top panel	01 pcs
2	Left side panel	01 pcs
3	Right side panel	01 pcs
4	Bottom rear panel	01 pcs
5	Drawer runner	08 pcs
6	Bottom panel	01 pcs
7	Foot crossbeam	02 pcs
8	Side foot	04 pcs


Part#	Description	Qty
9	Front / Back foot	02 pcs
10	Back panel	02 pcs
11	Apply Drawer	08 pcs
12	Front Drawer	04 pcs
13	Drawer Right Side	04 pcs
14	Drawer Left Side	04 pcs
15	Drawer bottom	04 pcs
16	Drawer Back	04 pcs

Hardware List

A		Ø8*30mm	Wooden dowel	68 pcs
B		Ø3,5*30mm	Screw	59 pcs
C		Ø4,0*40mm	Screw	06 pcs
D		Ø4,0*25mm	Screw	41 pcs
E		Ø8*20mm	Wooden dowel	32 pc
F		Ø10*10	Nail	26 pcs
G			Washer	02 pcs
H			Wall anchor	01 pc
J		Ø6mm		01 pc
K			Profile H	01 pc




Hammer recommended for assembly
(not included)



Philips head screwdriver required for assembly
(not included)

*The hardware quantities listed above are required for proper assembly.
Some extra hardware may also have been included.*


Step 1



Insert Wooden dowel (A) into part (4), (7), (9), (13) and (14).

Insert Wooden dowel (E) into part (5).


Step 2



Insert Wooden dowel (A) into part (2) and (3).


Secure part secure part (5) to part (2) and (3) with screw (D).

Step 3



Secure part (4) to part (2) and (3) with screw (B).



Step 4



Secure part (1) to part (2) and (3) with screw (B).



Secure part (6) to part (2) and (3) with screw (C).

Step 5




Secure part (8) to part (7) with screw (B).

Step 6



Secure part (9) to part (7) with screw (B).


Step 7



B		Ø3,5*30mm	08
---	--	-----------	----

Secure part (7) to part (6) with screw (B).


Step 8




D		Ø4*25mm	04
---	--	---------	----

Secure part (5) to part (2) and (3) with screw (D).




Step 9





A		Ø8*30mm	08
---	--	---------	----

Insert Wooden dowel (A) into part (5).


Step 10






F		Ø10*10mm	26
K			01

Secure back panel (10) and hardware (K) to body with nails (F)

Step 11






D		Ø4*25mm	01
G			01
H			01

Attach hardware (H) part (1), with screw (D+G).

Step 12


4x





D		Ø4*25mm	24
E		Ø8*20mm	16

Insert Wooden dowel (E) into part (17).
Secure part (17) to part (12) with screw (D).

Step 13



4x



Secure part (13) and (14) to part (12) with screw (B).





Insert part (15) between parts (13) and (14)

Secure part (16) with screw (B).

Step 14

Drawer Stop

Insert wood dowel (A) on the inside of all drawers while drawer is inside the unit.
Make sure dowel is flush with panel.









Step 15

WARNING


Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall.

Wall anchor and hardware are included with this product. Please make sure hardware is suitable for your walls before installing, as different wall materials may require different types of anchors.



B	 Ø3,5*30mm	01
G		01
J		01

Step 16



Assembly Complete!

Maintenance Guide

To maintain long term performance and easy gliding of your solid wood drawers, we recommend applying wax to the wooden guide rails.

1. Bee's wax is recommended or Paraffin wax from a standard candle can be used.
2. Apply the wax by rubbing it on the wooden guide rails where there is wood-on-wood contact when opening and closing the drawer. (Wax should be room temperature, do not melt the wax onto the wood)
3. Wax should be applied every few months for the first year and then only when needed after that to keep the drawers sliding smoothly.