



© Overlap Pent 6x3



These instructions are for your safety. Please read through them thoroughly before use .
PLEASE KEEP THIS LEAFLET FOR FUTURE REFERENCE

Let's get started...

Important information...



Safety	03
Base and positioning	04
Warranty	04
Care maintenance & Recycling	05





In more detail...

Stacked Parts List & Fascia bag	06-07
Hardware Chart	08
Before you start	09
Detailed Technical Drawings	10-11
Assembly instructions	12-24

EN	For a copy of the instructions or a copy in another language please send an email or write to the address below.
F	Pour obtenir un exemplaire des instructions ou une copie dans une autre langue s'il vous plaît envoyez un e-mail ou écrire à l'adresse ci-dessous.
PL	Na kopii instrukcji lub kopii w innym języku prosimy o wysłanie maila lub pisać na adres podany poniżej.
RUS	Для получения копии инструкции или копия на другом языке, пожалуйста, отправьте по электронной почте или написать по указанному ниже адресу.
TR	Başka bir dilde talimatları veya bir kopyasını bir kopyası için bir e-posta gönderebilir veya aşağıdaki adrese yazınız.

Check that you have noted all the following instructions

- 
- 
- ☒ We advise the use of non slip protective gloves throughout the assembly process.
 - ☒ We advise the use of steel capped protective footwear throughout the assembly process
 - ☒ We advise that you use a helper to hold the glass in position whilst you nail the beading in place
 - ☒ We advise the use of protective headwear and safety goggles throughout the assembly process
 - ☒ Where a ladder is in use another person must hold the ladder.
 - ☒ Do not attempt to work in windy conditions
 - ☒ We advise the use of a scaffold tower when fitting the roof, for felting or if you cannot reach from the ground.
 - ☒ Do not allow children near the tools and work area
 - ☒ Follow any safety precautions quoted by the manufacturer for any equipment you use
 - ☒ Check all parts before assembly
 - ☒ Only use child and animal safe wood preservative
 - ☒ Do not use creosote
 - ☒ Allow the wood preservative to fully dry before use
 - ☒ Regularly check the building for wear and tear

Important!



EVERY PRECAUTION IS TAKEN TO ENSURE THAT YOUR BUILDING HAS NO ELEMENT INCORRECTLY PLACED OR POSSIBLY HAZARDOUS, HOWEVER PRIOR TO USE PLEASE CHECK ALL SURFACES FOR THE FOLLOWING:

- (1) RAISED GRAIN, SPLINTERS: Sand down timber to smooth finish
- (2) NAIL/SCREW/PIN HEADS PROUD: Tap home to be flush with surface of timber
- (3) DAMAGED SCREW HEADS RESULTING IN SHARP SPLINTERS OF METAL: Replace
- (4) SHARP ENDS OF NAILS/ SCREWS/ PINS PROTRUDING THROUGH THE PANEL: Remove and reposition.
- (5) ENSURE ALL PARTS ARE SECURED AGAINST REASONABLE FORCE: Remove and refit
- (6) ENSURE THERE ARE NO LOOSE PARTS: Remove and refit/discard



IMPORTANT ! For your safety please read carefully the safety warnings

Preparation of base...

We recommend that the base onto which your building will stand should be at least 75mm larger in each direction than the total floor size of the building.

Actual floor area of the building: 1790mm x 750mm

Total height clearance: 1772mm

Roof size 1821mm wide x 876mm long

The chosen position in your garden for your building should be excavated to a depth of 75mm to allow a base of sand, on to which paving slabs can be evenly laid.

You may also use an adjustable timber base or a concrete base. Whatever base you decide upon IT MUST BE LEVEL AND FIRM.

Warranty...

10 Year anti rot warranty subject to the following -

- The building must be raised so it is not in contact with any water retaining base surface (for example grass).
- This can be achieved using a timber, concrete or slab base
- When using a concrete or slab base use damp proofing strips under the bearers
- The building must have been completely treated and sealed immediately prior to or after assembly
- The building must have been re-treated and re-sealed annually
- If your building has been pressure treated or has any pressure treated parts additional treatment need not be applied (except for aesthetic purposes)
- Wood is a natural product and therefore the following are excluded from the warranty
 - Colour changes
 - Warping
 - Splitting

The following are also excluded

- Damage resulting from poor assembly
- Poor treatment application
- Poor care and maintenance
- Changes to the design
- Misuse
- General wear and tear

The 5 golden rules of care

- (1) Ensure your base is level and firm
- (2) Ensure the building is not sitting directly on the ground using damp proof membrane or the optional timber base.
- (3) Ensure every piece of timber and surface, especially that is hidden upon assembly is treated with a top quality wood preservative at least twice (see note on pressure treated buildings in warranty section). Turn the panels upside down whilst painting so the treatment runs into the seams.
- (4) Garden buildings are not waterproof, therefore we recommend you seal between all the panels with a silicone based sealant .
- (5) Regularly check your roofing felt for weather damage and leaks

The 7 golden rules of maintenance

- (1) Re apply the timber treatment annually. (see note on pressure treated buildings in warranty section)
- (2) Visually check for weather damage
- (3) Check and replace if necessary any Silicone sealant if used on your building.
- (4) Check the roofing material for wear
- (5) The doors and windows may require periodical adjustment
- (6) Ensure your building is well ventilated especially during hot weather
- (7) During extremely hot periods humidify your building to prevent the timber from drying out .

Recycling and disposal



packaging

1. Pallet and timber widely recycled
2. Cardboard widely recycled
3. Plastic strapping subject to local regulations
4. Plastic sheeting subject to local regulations




Building


1. Timber widely recycled
2. Metal fixings widely recycled
3. Glass widely recycled
4. Roofing felt not currently recycled

Stacked parts list


FLOOR
(A4740)x01




BACK
(A4743)x02




LH END
(A4744)x01




RH END
(A4853)x01




WING
(A4742)x02




OSB ROOF
(A4741)x03




DOOR
(A4745)x02




Top bar
(A4856)x01




ROOF EDGE
(A4866)x02




COVER STRIP
(A4861)x03



COVER STRIP
(A1404)x03






FASCIA
(A4867)x02







Description
(part No) qty

Stacked parts list

<p>DOOR STOP (A4868)x02</p> 	<p>DOOR STOP (A4870)x01</p> 	<p>FELT STRIP 2m (A3318)x01</p> 

Description
(part No) qty

Nail bag contents


<p>TEE HINGE (A0049)x06</p> 	<p>HASP & STAPLE (A0123)x01</p> 	<p>DOOR BOLT (A0014)x02</p> 
<p>BOLT SHIM (A0052)x02</p> 		

Hardware Chart Scale 1:1


13mm Felt Nail
(A0023) x 42




40mm Round head nail
(A0025) x 74



25mm Posi-drive screw
(A0032) x 66




60mm Posi-drive screw
(A0035) x 24





Things to check before you start

- ✓ Ensure your base is ready– See page 3
- ✓ Check all parts as listed in the parts lists
- ✓ Read the instructions fully before starting work
- ✓ Follow all the health and safety guidelines



When you see the drill icon
Only ever drill through the first piece of framework which will be a pilot hole for the screw to attach the second piece of framework
The required drill bit size is shown with the icon.



You will need




- Hammer



- Spirit level




- Ladder




- 1mm, 3mm 5mm
• & 8mm drill bit



- Drill



- Tape measure & Ruler




- Sand paper



- Gloves




- Saw




- Pencil




- Goggles



- String





- A helper for some tasks



- Screwdriver







In more detail.....


Assembly

These instructions are for your safety. Please read through them thoroughly before use .
Treat all the parts before assembly –see page 5




GB-IE

Doors go at the Closed end of the floor where you can't see the floor framework ends.
The back panels "A4743" run the full width of the floor and the side panels push up to it.

01





Floor panel
(A4740)x01




Panel "**A4743**" for the back goes into the corner (two of these panels will cover the full length of the floor).

The cladding overhangs the floor edge, push **LH SIDE** panel "**A4744**" up to it.


02



BACK
(A4743) x01








LH SIDE
(A4744) x01



60mm Screw
(A0035)x03


This panel into the corners




GB-IE

Position the **Wing “A4742”** with the biggest overhand to the top.
The next back panel and the wing only need drilling for the floor.
Fix them to the adjoining panels with the holes drilled previously.


03





BACK
(A4743) x01



Wing
(A4742) x01



60mm Screws
(A0035)x06



A4743

Reverse
view


A4742




GB-IE

Align the **“A4853”** RH side and drill the same as the other side.
Fix with 60mm screws



04



RH SIDE
(A4853) x01





60mm Screws
(A0035)x03




A4853

Position the **Wing "A4742"** with the biggest overhand to the top.
Drill 2 holes for fixing later.

05



Wing
(A4742) x01




60mm Screws
(A0035)x03




Position the **Top Bar "A4856"** on top of the two **Wing panels "A4742"** so the ends are level with the outside of the wing framework.
Make sure the opening is 1390mm top and bottom and fix at the top as shown.




06



Top Bar
(A4856)x02




60mm Screws
(A0035)x03




Fit the two roof edge framework A4866 under the three roof panels A4741 .
Ensure all the edges are inline with each other and everything is square.
Nail each osb sheet to the roof edgings with 6 nails each.


07






**Roof Panel
(A4741)x03**



**Roof Edging
(A4866)x02**




**40mm Nails
(A0025)x18**




Align the roof assembly from the previous step so there is even overlaps on all sides.
Start a nail in each corner and run string along the length between the nails as a guide for the other nails.




08



Step
07 x 01



40mm Nail
(A0025)x18




The door stops are fitted widest side to panel framing.


Fit the side door stop strips flush with the edge of the framework not the cladding. The doorstop must be fitted to leave a step (behind the front face of the cladding where it meets the framing—detail A and level with the face of the top bar) with 4 nails each.

The top door stop is fitted flush to the face of the top bar between the other two door stops with 4 nails.


09





Door stop
(A4868)x 02



Door stop
(A4870)x 01




40mm Nail
(A0025)x12




A

There is a gap at either end of the horizontal framework on the back of the doors.
Fix the hinges so the screws go into the horizontal framework on the back of the door and the pivot part is on the door edge.


10







**Doors
(A4745)x 02**




**Tee hinge
(A0049)x06**




**25mm screws
(A0032)x24**




11





Rustic Cover strip
(A4861) x02




Rustic Cover strip
(A1404) x03




40mm Nail
(A0025) x20






12




Step 10
x2




25mm Screws
(A0032)x18



13




**60mm Screw
(A0035) x06**




GB-IE

Fit a bolt to the top and bottom of the secondary door with a bolt shim between the bolt and the door. The screws go through the door bolt and the shim directly into the door. Then drill an 8mm hole for the bolt shaft.


14





**Door bolt
(A0014)x 02**



**Rustic Bolt shim
(A0052)x 02**




**25mm Screw
(A0032)x08**




15





6mm



**Hasp & staple
(A0123) x01**




**25mm Screw
(A0032)x06**




Mark a cover strip either side of the Hasp and staple, cut, over lap the other door and only screw it to the door that opens first (primary door).



16



**Rustic Cover strip
(A4861) x01**





**25mm Screw
(A0032)x10**




1 Strip of felt has been supplied. The narrow edge of the felt goes to the side of the building. Place the felt over the entire roof folding the felt over the roof edging flush with its edge at the front and 35 mm at the end then secure with a couple of nails to hold the felt in position and gently pull it tight across the roof and nail at the back corners of the roof edging then at approximately 100mm centres front and back. And four at each end. Trim the excess off at the back and about 35mm at the other side .



17





**2.0m Felt strip
(A3318)x01**



**12mm Felt Nails
(A0023) x42**




Tidying the corner



18



Fascia
(A4867)x02



40mm Nail
(A0025) x06

