


# END TABLE

Assembly Instructions - Please keep for future reference



Width-35.43inch  
Depth-23.62inch  
Height-15.75inch

**Important-Please read these instructions fully before starting assembly**




# Safety and Care Advice

**Important – Please read these instructions fully before starting assembly**

- Check you have all the components and tools listed on the following pages.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.

- During assembly do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



power drill is set on a low torque setting.

- To reduce the likelihood of damaging your product please ensure that your

## Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.














## Handy Hints

- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts
- Regularly check and ensure That all bolts and fittings are tightened properly.

# Components - Fittings

Please check you have all the panels listed below


Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

|   |  |   |   |   |
|---|--|---|---|---|
| <p>A</p>  <p>35MM x8+2</p> | <p>B</p>  <p>∅14.5 x8+2</p> | <p>C</p>  <p>∅8*30 x12+1</p> | <p>D</p>  <p>M6*60 x4</p> | <p>E</p>  <p>M4 x1</p>   |
| <p>F</p>  <p>M8*70 x4</p> | <p>G</p>  <p>M8 x4</p>     | <p>H</p>  <p>M8 x4</p>     | <p>I</p>  <p>x1</p>     | <p>J</p>  <p>∅50 x4</p> |
| <p>K</p>  <p>∅22 x8</p>  | <p>L</p>  <p>x1</p>       |  <p>Person x2</p>          |   |   |

## Using Camlocks 3 in 1


### Step 1

Connect the male camlock as directed in the assembly instructions using a screwdriver.



### Step 2


Push the male camlock into the entry hole.



### Step 3

Insert the female camlock as shown in the instruction.

Note: ensure that the arrow on the top of the camlock points towards the entry hole for the male camlock.




### Step 4

Turn the female camlock clockwise with a screwdriver.

You should feel a click when the camlock is locked in place.


The joint is now secure.



## Using Camlocks 4 in 1


### Step 1

Push the male camlock into the entry hole.




### Step 2

Push the male camlock into the entry hole.




### Step 3

Insert the female camlock (half-moon cam and screw nut) to ensure the female camlock hole points towards the screw pole of the male camlock.




### Step 4

Turn the female camlock clockwise with a wrench till the camlock is locked tightly.




# Assembly Instructions

① \*1




450\*450\*25mm

② \*2



468\*446\*25mm

③ \*1



394\*430\*18mm

④ \*2











394\*50\*25mm

# Assembly Instructions

## Step 1


**WARNING:** Before assembling the furniture, please thoroughly inspect the work area and remove any small debris to prevent scratches on the product surface.






|  |  |  |  |  |  |   |
|--|--|--|--|--|--|---|
| <p>A</p>  | <p>C</p>  | <p>D</p>  | <p>E</p>  | <p>F</p>  | <p>L</p>  |  |
| <p>35MM x8</p>   | <p>∅8*30 x12</p>   | <p>M6*60 x2</p>  | <p>M4 x1</p>   | <p>M8*70 x4</p>  | <p>x1</p>  | <p>Person x2</p>  |

# Assembly Instructions


## Step 2






|  |  |  |
|--|--|--|
| <p>B</p>  <p>ø14.5 x4</p> | <p>L</p>  <p>x1</p> |  <p>Person x2</p> |
|--|--|--|

# Assembly Instructions


## Step 3









|  |  |  |
|--|--|--|
| <p>B</p>  <p>ø14.5 x4</p> | <p>L</p>  <p>x1</p> |  <p>Person x2</p> |
|--|--|--|

# Assembly Instructions


## Step 4






|   |   |   |   |  |   |
|---|---|---|---|--|---|
| D   | E   | G   | H   | I  |  |
|  |  |  |  |  |   |
| M6*60 x2  | M4 x1   | M8 x4   | M8 x4   | x1   | Person x2   |

# Assembly Instructions

## Step 5



|   |   |   |
|---|---|---|
| <p>J</p>  <p>ø50    x4</p> | <p>K</p>  <p>ø22    x8</p> |  <p>Person    x2</p> |
|---|---|---|

# Assembly Instructions

## Step 6

