





Installation & Assembly

Version:1.0



IT IS RECOMMENDED
TO USE POWER TOOLS




180MIN




EN_IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY.


USING CAM LOCK AND QUICKFIT




EN_QUICKFIT: Tighten quickfit until shoulder is flush with panel. Do not overtighten or undertighten.



EN_CAM LOCK: When fitting cam lock, ensure starting position is correct before you insert connecting quickfit.

























EN_Quickfit head should be in the centre of the cam lock when the two panels are joined.
Cam lock should be inserted before quickfit.














EN_Turn cam lock clockwise to tighten.








PACKING DELALS



NO.	PARTS	QTY	SPARE
①		x1	
②		x1	
③		x1	
④		x1	
⑤		x1	
⑥		x1	
⑦		x2	
⑧		x1	
⑨		x2	
⑩		x1	
⑪		x2	




























NO.	PARTS	QTY	SPARE
⑫		x1	
⑬		x2	
⑭		x1	
⑮		x1	
⑯		x1	
⑰		x1	
⑱		x1	
⑲		x1	
⑳		x1	
㉑		x1	
㉒		x3	






PACKING DELALS

NO.	PARTS	QTY	SPARE
23		x3	
24		x1	
25		x1	
26		x1	
27		x2	
28		x2	
29		x2	
30		x1	
31		x1	
32		x2	
33		x1	




NO.	PARTS	QTY	SPARE
34		x1	
35		x1	
36		x4	
37		x1	
38		x1	
39		x1	
	 Hardware Kit		







 <p>A x38 Ø6x35mm +3(spare)</p>	 <p>B x38 Ø15x10mm +3(spare)</p>	 <p>C x64 Ø6x30mm +6(spare)</p>	 <p>D x69 Ø4x35mm +6(spare)</p>	 <p>E x52 Ø3.5x12mm +5(spare)</p>	 <p>F-1 F-2</p>
 <p>G x2 Ø3x14mm</p> <p>G-1 G-2</p>	 <p>H x16</p>	 <p>I x8</p>	 <p>J x4</p>	 <p>x1 K-1 x1 K-2 x8 K-3 x8 K-4</p> <p>K x1</p>	
 <p>L x1</p>	 <p>M x2 Ø3.5x12mm</p>	 <p>N x1</p>	 <p>O x7 Ø4x12mm</p>	 <p>P x5</p>	 <p>Q-1 Q-2</p>
 <p>R x2 Ø6x30mm</p>	 <p>S-1</p>  <p>S-2</p>	 <p>T-1</p>  <p>T-2</p>	 <p>U x32 +5(spare)</p>		
 <p>CL x3 L300mm</p>	 <p>CR x3 L300mm</p>	 <p>DL x3 L300mm</p>	 <p>DR x3 L300mm</p>		



x2



x2










A x3

E x6

CL x1

CR x1






A x3

E x6

G x1



CL x1

CR x1





G-1

G-2



180°






A x3

E x6


G x1

CL x1

CR x1




G-1 G-2




4

180°



4



CL

E

G-2




A

G-1

B x1

C x6



D x4



B x2

C x4



D x4



B x2

C x6



D x4



B x1

C x4




D x4



B x3

C x4

D x8



N x1





O x2




P x2



The final effect is that it is perpendicular to the ground and through the triangular cut.






Note Plan the position before pasting. After removing the glue protective film on the back of the lamp belt, attach it to the side panel along the edge of the side panel, and finally lock the cable buckle to secure the lamp belt.






C x4

D x4






C x6

D x4






C x4

D x4





C x6

D x4



A x14





B x2



C x3






D x2



A x2



B x2

D x2





C x4

D x4



C x2


D x4





B x2

C x3

D x2





After assembly
gently support plates 37, 38, and 39.



E x12





I x6



B x10




C x8



L x1


M x2

Q x1



Q-1

Q-2




K x1




x8
K-3




x8
K-4




(1)



(2)



(3)





x1
K-1



x1
K-2



K x1



O x3





P x1



O x2


P x2








Scan qr code to download APP
Bluetooth control


OR

Flip to the other side for
key control









E x4

F x2



I x2


J x4




F-1



F-2









Please tear off the film on the outside of the mirror.





D x2




R x2




S x2




First fix the anti-rewind screw in the reserved hole of the product.




Then, put the expansion bolt into the hole



then, use a ruler to measure the approximate height of the product on the wall, and then mark it with a pen.



Finally, pass the matching screws through the "anti-rewind" and tighten them to fix them on the wall.



Then use a tape drill to make holes in the wall that are suitable for the product screws.

