




85063 Product Installation Instructions







1x2




2x4




3x2




4x2




5x1




6x2




7x1




8x1




9x1




10x1




11x1




12x1




13x1




14x1




15x1




16x1




17x1



18x2




19x1




20x1







21x1




22x1




23x1




24x1




25x1




26x1




27x1




28x1




29x1




30x1




31x1




32x1




33x1




34x1




35x2




36x1




37 & 38




39x1



40x1































41x2


















42x1





(A)				Two In One Screw (6x28mm)	105pcs +4pcs	
(B)				Two In One Nut (10x12mm)	105pcs +4pcs	
(C)				Wood Chipping (6x30mm)	38pcs +4pcs	
(D)				Pull loop handle (4x14mm)	10pcs 10pcs +2pcs	
(E)				Screw (3x10mm)	8pcs +2pcs	
(F)				Screw & Guide(12 inch) (3x12mm)	30pcs +4pcs 6pcs	
(G)				Wheel & Screw (3.5x12mm)	16pcs +2pcs 4pcs	
(H)				Hinge& Screw (3.5x12mm)	32pcs +4pcs 4pcs	
(I)				Screw (4x25mm)	8pcs +1pcs	
(J)				Non-slip pads	6pcs	
(K)				Buffer plastic particles (10x2mm)	4pcs	
(L)				Rubber Strip Guide & Screw (4x16mm)	1pcs 2pcs	
(M)				Fixing clip & screw (3x16mm)	8pcs	
(N)				Cabinet door hinge & Screw (3x12mm)	2pcs 4pcs +1pcs	
(O)				Clamp	2pcs	
(P)				Laminate support nail	8pcs	
(Q)				Magnetic attraction Screw (3x10mm) Iron sheet	1pcs 4pcs +1pcs 1pcs	
(R)				Locks & tools & key	1pcs	
				AC/DC Adapter (12V==3. 0A)	1pcs	
(S)	 x2  x2  (3. 5x14mm) x2  x4  x2 (4x45mm)			 1pcs  Double-head screwdriver, use as required <div><div>3</div></div>		

Product structure decomposition




A		49pcs	B		49pcs	C		25pcs
D	 6pcs	 6pcs	 6pcs	E	 4pcs	F	 6pcs	 18pcs
G	 16pcs	 4pcs	H	 2pcs	 12pcs	K	 2pcs	




Use parts A and B




Step1



Step2






Step3




Use a screwdriver to lock in the direction of the "+" sign

Disassemble along the direction of "-" sign


Step 1





Step 2





Step 3



Step 4




Step 5





Don't beat the acrylic board too tightly, it will crack

Step 6


- D



x1
- 


x1
- 

x1




Step 7


- B



x8





Drawer rail breakdown diagram




Step 1 : Pull the rails apart

Step 2 : Push the nylon buckle outward ①



②

③






①

②

③

Step 8












F

x2

x4

Step 9



- A  x8
- B  x8
- D  x1  x1  x1
- E  x4
- F  x2  x4




x2

Repeat the drawer installation steps


Step 10




Step 11







Step 12




Step 13





- | | | |
|----------|---|----|
| A |  | x4 |
| D |  | x1 |
| |  | x1 |
| |  | x1 |

Step 14

B




x8




Step 15





F



x2





x4






14

Step 16




Step 17




Step 18

F




x2




Step 19

F




x1




This hole is for strengthening fixed hole customers can choose to install according to their needs.

Step 20


- A




x4
- C





x4




Step 21

- B
- 
- x4




Step 22

F




x2




Step 23

F





x1




This hole is for strengthening fixed hole customers can choose to install according to their needs.


Step 24




A  x4



C  x4

Step 25





B  x4

Step 26




Step 27




Step 28

B




x7




Step 29

A




x7

C




x4




Step 30

B



x7



Step 31


G



x4






x16






22

Step 32



Please note that the screw holes cannot be tightened during installation and require adjustment positions for adjustment


Step 33



After installing the hinge, tighten all screws


Attention: Please find something to support the stool on your own to prevent it from slide away during the installation of the 15 boards

Step 34



































As shown, When installing the drawer, pull the guide rail out first, Slide beads are also pulled out.

Step 35





If a large gap is found after installing the drawer the slide rail can be moved up and down to adjust the gap



A		56pcs	B		56pcs	C		13pcs	
D	 4pcs	 4pcs	 4pcs	F	 4pcs	H	 2pcs	 12pcs	
I	 8pcs	J	 6pcs	K	 2pcs				
L	 1pcs	 2pcs	M	 8pcs	N	 2pcs	 4pcs		
O	 2pcs	P	 8pcs	Q	 1pcs	 4pcs	 1pcs		
R	 1pcs	 1pcs	 1pcs	S	 2pcs	 4pcs	 2pcs	 (3. 5x14mm) 2pcs	 (4x45mm) 2pcs
	 1pcs								



Step 36




Step 37




Step 38


I




x4



Proper installation




Incorrect installation






Step 39

F




x4




Step 40

F




x2



This hole is for strengthening fixed hole customers can choose to install according to their needs.

Step 41

A




x8

C




x2




Step 42

B




x2




Step 43


Q



x1




x2




Step 44

B




x2




Step 45

A




x1


C




x1





Step 46

B  x1





Step 47



B  x4



Step 48




Step 49




Attention: There are two side holes on this side

Step 50

F




x4




Step 51

F





x2





This hole is for strengthening fixed hole customers can choose to install according to their needs.

34

Step 52





Step 53




Step 54

B



x8





Step 55



Step 56




Step 57





Step 58


B





x4





Step 59



- A  x8
- C  x2


Step 60




- A  x3

Step 61

B




x3




Step 62

B




x4




Step 63


- D




x1



x1




x1




Step 64

- B




x2




Step 65

B




x2




Step 66

A




x4




43

Step 67

B




x4




Step 68



I





x4



Step 69




Step 70




Step 71


B




x8



Step 72




J




x6

Tear off release paper and stick the black foot pad on the board

Step 73




H



x2





H






x6

Please note that the screw holes cannot be tightened during installation and require adjustment positions for adjustment

Step 74


L		
	x1	x2
M		
	x8	x8







Step 75

After installing the hinge,tighten all screws


- H

 x6
- K

 x2




Step 76





Attention:

1. Please gently close the mirror panel
2. After installing the mirror panel you need to check if you need to adjust the position slightly

Step 77




Step 78




Step 79


B




x4




The decomposition of the lock




①



②




③



④


Step 1

1. Facing the direction of the keyhole position with the teeth, clamp the wooden board tightly
2. Insert part 1 into the hole of the 34 plate first, and then lock the hex nut




Step 2

1. Clip part 3 into the tail of part 1




The installation is completed as shown in the figure




Step 3


1. Twist screw 4 into the hole position at the tail of 1



Lock steps




Unlock






lock

Step 80


Pay attention to the direction of the hole position




Lock the hex nut with a wrench

(R)		x1
		x1
		x1


Step 81



Unlock




Step 82




You can carve the desired shape with a knife

Step 83

P




x4




Step 84

Attention: The lock is placed
in the unlocked state





Attention: If you want to remove the 34 board, the
lock must be in an unlocked state

Step 85




The mirror can be opened and leaned against board 35

Step 86



As shown, When installing the drawer,
pull the guide rail out first, Slide beads are also pulled out.


Step 87




If a large gap is found after installing the drawer the slide rail can be moved up and down to adjust the gap


Step 88

- Q




x1
- 


x2




Step 89


- D



x3
- 


x3
- 

x3




Step 90


N




x2





Step 91




Step 92

N  x4





First




Second

Step 93


P  x4





Step 94



Step 95




Step 96





Step 97



Install as required



3.5x14mm





Install the anti fall hardware on the cabinet as shown in the picture first





Then mark the wall with a pen through the holes in the anti-fall hardware

Step 98




Drill the hole with an electric drill and punch in the colloidal particles





Fix the dressing table to the wall

Step 99



Step 100





User's Guide

Thank you for purchasing this product.

To use this product, please plug it into a 12V DC power supply.

Please use if the product works normally after connecting to power.

Introduction

The box is an intelligent controller. It has 1 USB port and 1 type-C port and can distribute the current output up to 5V DC-2A. With 2 touch buttons, it can turn ON/OFF the light, change light colors, and adjust the light luminance.

Operation




This touch button is used to turn on/off, change colors, and adjust brightness.

- A. Short touch -> lighting on -> short touch -> change light color -> short touch -> change light color -> short touch -> lighting off.
- B. Long touch -> adjust the luminance.



This touch button is used to turn on/off the induction function.

- A. Short touch to turn on the induction function. It can auto-turn on the light when people are close to the controller in 1 meters. It can auto power off the light when the body is far away from the controller after 30 seconds.
- B. Long touch to turn off the induction function.
- C. Note: When you touch the light button to change the light modes, the induction function will automatically turn off. It is best to turn on this function after selecting the light color and adjusting the brightness you want.



This range is a wireless charging area, and only mobile phones with wireless charging function can be charged.



ATTENTION PLEASE

1. If there is no touch response suddenly, Re-plug the power to reset the touch static electricity.
2. If bubbles appear on the panel, remove the protective film.
3. If you have any questions when installing, please feel free to contact us. Thank you.