



# Assembly Instruction




# General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are : wood dowels , screws and bolts.
- V. A Phillips head screwdriver is required for the assembly of this product .



- VI. Power tools should not be used to assemble this product .













# Parts List




Part#	Description	Qty
1	Top panel	01 pcs
2	Shelf	01 pcs
3	Base	01 pcs
4	Center upper panel	01 pcs
5	Center bottom panel	02 pcs
6	Left side panel	01 pcs
7	Right side panel	01 pcs
8	Feet	02 pcs

Part#	Description	Qty
9	Upper back panel	01 pcs
10	Back panel	01 pcs
11	Drawer front	03 pcs
12	Drawer left side	03 pcs
13	Drawer right side	03 pcs
14	Drawer bottom	03 pcs
15	Drawer back	03 pcs
16	Back side panel	02 pcs

# Hardware List


A		Ø 5,5x28mm	Cam Bolt	10 pcs
B		Ø 14x14mm	Cam Lock	10 pcs
C		Ø 3,5x30 mm	Screw	46 pcs
D		Ø 8,0x30 mm	Wood dowel	54 pcs
E		Ø 3,5x16 mm	Screw	28 pcs
F			Plastic Slide	06 pcs
G		Ø 4,0x40 mm	Screw	14 pcs
H				07 pcs
I		Ø 3,5x20 mm	Screw	08 pcs
J			Drawer Limiter	03 pcs




Philips head screwdriver required for assembly  
(not included)

*The hardware quantities listed above are required for proper assembly.  
Some extra hardware may also have been included.*

**Step 1** Insert wooden dowel (D) into part (2), (4), (5), (6), (7), (8), (12), (13) and (16).







**Step 2** Secure Slide (F) to part (6) and (7) with Screw (E).






**Step 3** Attach the Plastic Slide (F) into part (5) using Screw (I) and a Phillips head screwdriver. Complete this step twice.

**2x**






**Step 4** Secure part (2) to part (4) with screw (G).






## Step 5

Secure parts (5) to part (2) with screw (C).






## Step 6

Secure parts (6) and (7) to part (2) with screw (C).










# Step 7

Insert screw Cam Bolt (A) into top panel (1).




# Step 8

Secure parts (8) to part (3) with screw (C). Insert stop (J) to part (3) with screw (E).







# Step 9

Secure part (3) to parts (5), (6), (7) and (16).






# Step 10

Attach part (1) in the wood dowels of part (4), (6), (7) and (16) using cam bolt (B) and phillips screw driver (not included).







# Step 11

Secure part (3) with screw (G).





# Step 12

Secure back panel (9) and (10) with screw (E) at some points as shown using the hardware (H).




**Step 13** Attach part (12) and (13) in the part (11) using screw (C).  
Attach part (14) and (15) as shown using screw (C).

**3x**



**Step 14**



**Assembly Complete!**