

Base Table Lamp



IMPORTANT:

- Mains Voltage: 220-240V~ ;50Hz
- This lamp is double insulated (Class II) and does not require an earth connection.

USER ADVICE:

- Keep all packaging until after a successful installation and retain instructions for future use.
- The design of the lamp may vary slightly from the illustration.

LOCATION:


- Indoor use only.
- Ensure the lamp is in a location where the power cable will not cause an accident.
- Place lamp on a level surface.

INSTALLATION:

- Fit the shade to the base by passing the lampholder through the base and securing with the shade ring
- Insert the bulb (not supplied) into the lamp holder. (bulb type & Wattage as stated on the product)

SAFETY:

- Before inserting or replacing bulbs make sure that the light is unplugged and has cooled down.
- Always disconnect from the mains after use.
- Do not allow the bulb to contact the material of the shade.
- If the supply cord is damaged, it cannot be replaced, and the lamp must be scrapped.



Base Table Lamp



IMPORTANT:

- Mains Voltage: 220-240V~ ;50Hz
- This lamp is double insulated (Class II) and does not require an earth connection.

USER ADVICE:

- Keep all packaging until after a successful installation and retain instructions for future use.
- The design of the lamp may vary slightly from the illustration.

LOCATION:

- Indoor use only.
- Ensure the lamp is in a location where the power cable will not cause an accident.
- Place lamp on a level surface.

INSTALLATION:

- Fit the shade to the base by passing the lampholder through the base and securing with the shade ring
- Insert the bulb (not supplied) into the lamp holder. (bulb type & Wattage as stated on the product)

SAFETY:

- Before inserting or replacing bulbs make sure that the light is unplugged and has cooled down.
- Always disconnect from the mains after use.
- Do not allow the bulb to contact the material of the shade.
- If the supply cord is damaged, it cannot be replaced, and the lamp must be scrapped.

