



# BED FRAME

## FULL















## Before You Start



- ✓ Read through each step carefully and follow the proper order
- ✓ Separate and count all your parts and hardware
- ✓ Give yourself enough room for the assembly process
- ✓ Have the following tools: Flat Head Screwdriver, #2 Phillips Head Screwdriver and Hammer
- ✓ Caution: If using a power drill or power screwdriver for screwing, please be aware of to slow down and stop when screw is tight. Failure to do so may result in stripping the screw. (Assembly speed can be increased by using electric screwdriver)


# Parts Identification 1/2

Not actual size

|  |  |   |
|--|--|---|
|  <p><b>A</b></p> <p>HEADBOARD FRAME<br/>Q'ty: 2</p>         |  <p><b>B</b></p> <p>HEADBOARD BACKREST<br/>Q'ty: 1</p>  |  <p><b>C</b></p> <p>HEADBOARD TUBE<br/>Q'ty: 4</p>     |
|  <p><b>D</b></p> <p>HEADBOARD CONNECTER<br/>Q'ty: 1</p>    |  <p><b>E</b></p> <p>SIDE RAIL-1<br/>Q'ty: 2</p>  |  <p><b>F</b></p> <p>SIDE RAIL-2<br/>Q'ty: 2</p>       |
|  <p><b>G</b></p> <p>MIDDLE CONNECTING ROD<br/>Q'ty: 1</p> |  <p><b>H</b></p> <p>HEADSTOCK TAIL CONNECTING ROD<br/>AND BED SIDE TRANSVERSE TUBE<br/>Q'ty: 2</p> |  <p><b>I</b></p> <p>MIDDLE CROSS BAR<br/>Q'ty: 1</p> |
|  <p><b>J</b></p> <p>SUPPORT LEG<br/>Q'ty: 2</p>           |  <p><b>K</b></p> <p>SLAT<br/>Q'ty: 10</p>   |  <p><b>L</b></p> <p>TOP PLATE<br/>Q'ty: 1</p>        |


# Parts Identification 2/2

Not actual size




M

SHELF PANEL  
Q'ty: 1




N

BED-END  
Q'ty: 1




O

CLOTH BAG  
Q'ty: 2




P

CLOTH BAG  
Q'ty: 2



Q


drawer board  
Q'ty: 4




R

BASKET  
Q'ty: 4


# Hardware List




BOLT  
spare: 1




BOLT  
spare: 3




BOLT  
spare: 1




BOLT  
spare: 1




BOLT  
spare: 2




BOLT  
spare: 1




SCREW




ALLEN KEY




ALLEN KEY




SOCKET




LED STRIP




CABLE HOLE COVER




⑬ x 2




PLASTIC CAP



CASTER




DRAWER CLIP





DRAWER CLIP

# Parts Identification

Not actual size



**COMPLETE**



# STEP 1



⚠ Please tighten the bolts to 80% first, and tighten all bolts 100% after all parts are assembled.

Ø1/4" x 50mm

5 x 6


M4

8 x 1




Ø1/4" x 50mm

5



Please pay attention to the direction of the metal bolt plate.


# STEP 2



10 x 1

Ø3 x 12mm

7 x 2




# STEP 3

⚠ Please tighten the bolts to 80% first, and tighten all bolts 100% after all parts are assembled.

|   |     |
|---|-----|
| 2 | x 8 |
|---|-----|

|   |     |
|---|-----|
| 8 | x 1 |
|---|-----|






# STEP 4

⚠ Please tighten the bolts to 80% first, and tighten all bolts 100% after all parts are assembled.




|   |     |
|---|-----|
| 5 | x 4 |
|---|-----|

|   |     |
|---|-----|
| 8 | x 1 |
|---|-----|







Please pay attention to the direction of the metal bolt plate.

# STEP 5




# STEP 6




# STEP 7

⚠ Please tighten the bolts to 80% first, and tighten all bolts 100% after all parts are assembled.




Ø1/4" x 11mm

|   |     |
|---|-----|
| 2 | x 4 |
|---|-----|




M4

|   |     |
|---|-----|
| 8 | x 1 |
|---|-----|




# STEP 8

⚠ Please tighten the bolts to 80% first, and tighten all bolts 100% after all parts are assembled.




Ø1/4" x 25mm

|   |     |
|---|-----|
| 4 | x 4 |
|---|-----|




M4


|   |     |
|---|-----|
| 8 | x 1 |
|---|-----|




|    |     |
|----|-----|
| 13 | x 2 |
|----|-----|






# STEP 9





# STEP 10

 Please tighten the bolts to 80% first, and tighten all bolts 100% after all parts are assembled.


|   |   |
|---|---|
|  |  |
|---|---|

|   |
|---|
|  |
| Ø1/4" x 11mm  |
| 2 x 4   |

|   |
|---|
|  |
| M4  |
| 8 x 1   |






# STEP 11







Expand the folded portion


# STEP 12

 Please tighten the bolts to 80% first, and tighten all bolts 100% after all parts are assembled.

|   |   |
|---|---|
|  |  |
|---|---|

|  |   |
|--|---|
|  |  |
| $\text{Ø}1/4" \times 50\text{mm}$  | M4  |
| 5 x 2  | 8 x 1   |

|   |   |
|---|---|
|  |  |
| $\text{Ø}1/4" \times 50\text{mm}$   | M4  |
| 5 x 2   | 8 x 1   |



# STEP 13


⚠ Please tighten the bolts to 80% first, and tighten all bolts 100% after all parts are assembled.

Ø1/4" x 25mm


|   |     |
|---|-----|
| 4 | x 4 |
|---|-----|

M4

|   |     |
|---|-----|
| 8 | x 1 |
|---|-----|



**ATTENTION:** This metal plate is on the bottom instead of on top. Don't install it wrongly.



# STEP 14

⚠ Please tighten the bolts to 80% first, and tighten all bolts 100% after all parts are assembled.

M8 x 13mm

|   |     |
|---|-----|
| 1 | x 4 |
|---|-----|

Ø1/4" x 50mm


|   |     |
|---|-----|
| 5 | x 1 |
|---|-----|

M4


|   |     |
|---|-----|
| 8 | x 1 |
|---|-----|

M5


|   |     |
|---|-----|
| 9 | x 1 |
|---|-----|




**ATTENTION:** This metal plate is on the bottom instead of on top. Don't install it wrongly.




# STEP 15




## Assemble the slats




1. Squeeze the clamp (14) tightly.



2. Put the clamp into the gaps.




3. Put the slat (14) into the clamp.





4. Finished.

# STEP 16



Expand the drawer frame






# STEP 17








# STEP 18



# STEP 19




# STEP 20






# x 4



# STEP 21



# STEP 22



Stick LED strip(11) underneath board(L), attach the LED strip to the edges.



The LED switch is free to put onto or hidden underneath the board ①.

