









# Installation & Assembly

## Coffee Table






## Before You Start

-  Please read all instructions carefully.
-  Retain instructions for future reference.
-  Separate and count all parts and hardware.
-  Read through each step carefully and follow the proper order.
-  We recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.
-  Always place the product on a flat, steady and stable surface.
-  Keep all small parts and packaging materials for this product away from babies and children as they potentially pose a serious choking hazard.


## Assembly Instructions

We have designed our furniture with you, the customer in mind. Our clear, easy to follow step by step instructions will guide you through the project from start to finish. Feel confident that this will be a fun and rewarding project. The final product will be a quality piece of furniture that will go together smoothly and give years of enjoyment.


# Completed Assembly



# Parts Description




1




① Back Top Panel 1pc

2




② Front Top Panel 1pc

3




③ Back Side Panel 1pc

4




④ Front Side Panel 1pc

5




⑤ Left Side Panel 1pc

6




⑥ Right Side Panel 1pc

7




⑦ Left Top Support Bar 1pc

8




⑧ Right Top Support Bar 1pc

9




⑨ Left Bottom Panel 1pc

10




⑩ Right Bottom Panel 1pc

11




⑪ Bottom Support Bar 2pcs

12



⑫ Bottom Support Bar 2pcs

13



⑬ Middle Bottom Support Bar 1pc


A



Cam Bolt

38pcs


B



Cam Lock

38pcs

C



8x30mm Wooden Dowel 28pcs

D



4\*20mm Screw

12pcs

E



4\*35mm Screw

12pcs


F



3x14mm Screw

2pcs


G



Magnet

1pc


H



Hinge

2pcs

I



Magnet Strip

1pc


J



3x12mm Screw

22pcs


K



Left Folding Pull Rod

1pc


L



Right Folding Pull Rod

1pc


M



Bolt

1pc


N



Knob

1pc


O



4\*12mm Screw

28pcs


P



Left Lifting Rod

1pc


Q



Right Lifting Rod

1pc


R



Angle Iron Piece

4pcs


S



Iron Piece

4pcs

T



Iron Piece

4pcs

U



3\*12mm Screw

32pcs



Note: Please do not use any power tools. Use of power tools may cause damage and void manufacture warranty.

## Instructions For Fastening Cam Bolt and Cam Lock





CAM BOLT




CAM LOCK

### Cam Bolt

Place Cam Bolt on the designated pre-drilled hole on the panel. Use a Phillips Screwdriver to screw in Cam Bolt vertically until shoulder is snug and flushed with panel. Do not over-tighten or under-tighten Cam-bolt. See illustrations below.





Shoulder is flushed  
(on the same level)  
with the panel.



Shoulder is  
above the panel.



**CAM-LOCK**  
Align the arrow on the Cam-lock to the  
Cam-bolt head and insert the Cam-lock.



Use a Flat-head Screwdriver to turn Cam Lock clockwise to lock onto the head of the Cam Bolt. Turn until it is snug (about a half turn) – over-tightening could damage Cam Lock and/or Cam Bolt.



## Step 1


- 1.Screw Cam Bolt(A) into Left Side Panel(5) and Right Side Panel(6).
- 2.Insert Wooden Dowel(C) into Left Side Panel(5) and Right Side Panel(6).
- 3.Attach Left Top Support Bar(7) to Left Side Panel(5), using Screw(D).
- 4.Attach Right Top Support Bar(8) to Right Side Panel(6), using Screw(D).




## Step 2

- 1.Attach Left Side Panel(5) and Right Side Panel(6) into Back Side Panel(3) by Cam Lock(B) .








⑨ Left Bottom Panel 1pc



⑩ Right Bottom Panel 1pc

### Step 3

- 1.Screw Cam Bolt(A) into Left Bottom Panel(9).
- 2.Insert Wooden Dowel(C) into Left Bottom Panel(9).
- 3.Attach Left Bottom Panel(9) into Right Bottom Panel(10) by Cam Lock(B).




A x 4



B x 4



C x 2




C x 8



E x 12

### Step 4

- 1.Insert Wooden Dowel(C) into the completed piece from step 2.
- 2.Attach Left Bottom Panel(9) and Right Bottom Panel(10) into the completed piece from step 2 by Screw(E).








A x 16




C x 8

### Step 5


- 1.Screw Cam Bolt(A) into Left Bottom Panel(9) and Right Bottom Panel(10).
- 2.Insert Wooden Dowel(C) into Left Bottom Panel(9) and Right Bottom Panel(10).



⑪ Bottom Support Bar 2pcs






⑫ Bottom Support Bar 2pcs



⑬ Middle Bottom Support Bar 1pc

### Step 6

- 1.Screw Cam Bolt(A) into Bottom Support Bar(11) .
- 2.Insert Wooden Dowel(C) into Bottom Support Bar(11) .
- 3.Attach Bottom Support Bar(12) and Middle Bottom Support Bar(13) into Bottom Support Bar(11) by Cam Lock(B).



A x 10



B x 10






C x 2



B x 16

### Step 7

1. Attach the completed piece from step 6 into Left Bottom Panel(9) and Right Bottom Panel(10) by Cam Lock(B).




② Front Top Panel

1pc

### Step 8

1. Turn over the part completed in step 7 as shown.
2. Screw Cam Bolt(A) into Front Top Panel(2).
3. Attach Magnet (G) to Front Top Panel(2) by Screw (F).
4. Insert Wooden Dowel(C) into Left Side Panel(5) and Right Side Panel(6).
5. Attach Front Top Panel(2) to Left Side Panel(5) and Right Side Panel(6) by Cam Lock (B).



A x 4




B x 4





C x 4





F x 2




G x 1





Note that Magnet(G) is outside and facing downwards







### Step 9

1. Attach Hinge(H) to Front Side Panel(4) by Screw(J).
2. Attach Magnet Strip(I) to Front Side Panel(4) by Screw(J).
3. Attach Left Folding Pull Rod(K) and Right Folding Pull Rod(L) to Front Side Panel(4) by Screw(J).
4. Attach knob(N) to Front Side Panel(4) by Bolt(M).




### Step 10

1. Attach Hinge(H) to Left Bottom Panel(9) and Right Bottom Panel(10) by Screw(J).
2. Attach Left Folding Pull Rod(K) to Left Side Panel(5) by Screw(J).
3. Attach Right Folding Pull Rod(L) to Right Side Panel(6) by Screw(J).



Pay attention to the bending angle of the folding pull rod



① Back Top Panel


1pc

### Step 11


1. Attach Left Lifting Rod(P) and Right Lifting Rod(Q) to Back Top Panel(1) by Screw(O).





O x 12



P x 1



Q x 1




### Step 12


1. Attach Left Lifting Rod(P) to Left Top Support Bar(7) by Screw(O).  
2. Attach Right Lifting Rod(Q) to Right Top Support Bar(8) by Screw(O).



O x 16




This step requires two people to complete







U x 32



R x 4



S x 4



T x 4

### Step 13

1. Use Screw (J) to connect Angle Iron Piece (R) the four corners of Back Side Panel (3).
2. Attach Angle Iron Piece (R) to Left Side Panel (5) and Right Side Panel (6) by Screw (J).
3. Attach Iron Piece (T) to Left Side Panel (5) and Right Side Panel (6) by Screw (J).
4. Attach Iron Piece (S) to Front Side Panel (4) by Screw (U).

