

ASSEMBLY INSTRUCTIONS

CABINET

ASSEMBLY

1 Hour

2 -Person Assembly

Tools Required (Not Provided):


REQUIREMENTS

Assembly Time



(Approximate)

Phillips Screwdriver



Flat Head Screwdriver



Thank you for purchasing our product!

Please refer and use this assembly instruction to assemble the product.
Contact our customer service department in case there are any missing or damage parts or hardware.
Replacement parts are normally shipped within 2 or 3 days.

We appreciate your business!

PRODUCTS PURCHASED THROUGH OUR AUTHORIZED VENDORS ONLY ARE ELIGIBLE FOR REPLACEMENT PARTS.

THIS PRODUCT IS FOR INDOOR AND HOUSEHOLD USE ONLY - NOT FOR COMMERCIAL USE.

ASSEMBLY PREPARATION

1. Remove all packaging materials, staples and packing straps from the carton.
2. Refer to Parts List and Hardware List and ensure they are correct before assembly.
Contact customer service for missing parts.
3. Place all wooden parts on a clean, flat and soft surface (e.g. carpet or rug) to prevent parts from getting scratched.

SAFETY PRECAUTION

1. KEEP ALL HARDWARE PARTS OUT OF REACH OF CHILDREN.
2. DISPOSE PLASTIC PACKAGING MATERIAL IMMEDIATELY TO AVOID ANY RISK OF SUFFOCATION TO CHILDREN AND ANIMALS.

TIPS FOR ASSEMBLY


1. Allow ample room for assembly and in close proximity to where product will be placed.
2. Assemble the product on a surface that does not scratch or damage the exterior gloss and finish of the furniture.
3. Identify all of the parts, hardware and quantities required for each step.
4. During assembly, do not over-tighten any fittings as this may cause damage.
5. DO NOT USE POWER TOOLS TO ASSEMBLE THIS PRODUCT.
6. Always place the product on a flat, level surface.
7. Do not sit or stand on the partially assembled product; only use the product for which it is intended.

CARE AND MAINTENANCE

















1. Wipe clean with a soft, dry cloth; avoid the use of harsh chemicals or household cleaners as they may damage the exterior finish of the furniture.
2. Hardware may loosen over time. Periodically, check that all connections are tight; re-tighten as necessary.
3. Solid wood is impacted by heat and humidity fluctuations which may cause small joint separations or hairline cracks; place the furniture away from direct sunlight and air conditioning vents, heating vents or units to protect the furniture.

ASSEMBLY INSTRUCTIONS

Cabinet














Hardware List

ITEM	DESCRIPTION	PART	QTY	ITEM	DESCRIPTION	PART	QTY
A	Cam-bolt	 6*35mm	15 pcs	I	Handle		2 pcs
B	Cam-lock	 15*10mm	15 pcs	J	Wood Dowel	 6*30mm	20 pcs
C	Screw	 4*40mm	3 pcs	K	Magnetic Catch		1 pc
D	Screw	 3*14mm	2 pcs	L	Magnetic Bar	 35*12*1mm	2 pcs
E	Screw	 3*12mm	26 pcs	M	Plastic Anchor		1 pc
F	Screw	 2.5*10mm	26 pcs	N	Screw	 3.5*40mm	1 pc
G	Hinge	 40mm	4 pcs	O	Bracket		1 pc
H	Handle Bolt	 4*14mm	2 pcs	P	Screw	 4*12mm	1 pc


ASSEMBLY INSTRUCTIONS

Parts List

ITEM	DESCRIPTION	PART	QTY	ITEM	DESCRIPTION	PART	QTY
1	Bottom Connect Bar		1 pc	7	Left Door		1 pc
2	Bottom Panel		1 pc	8	Right Door		1 pc
3	Shelf		1 pc	9	Upper Back Panel		1 pc
4	Top Panel		1 pc	10	Lower Back Panel		1 pc
5	Left Panel		1 pc	11	Top Connect Bar		1 pc
6	Right Panel		1 pc				

ASSEMBLY INSTRUCTIONS

ASSEMBLY OVERVIEW



Instructions For Fastening CAM-BOLT AND CAM-LOCK




CAM-BOLT




CAM-LOCK


Tools Required




INSERTING AND TIGHTENING CAM-BOLT



Place Cam-bolt on pre-drilled hole and screw in vertically.




Shoulder is flushed (on the same level) with the panel.




Shoulder is above the panel.

Place Cam-bolt to the designated pre-drilled holes on the panel. Use a Phillips Screwdriver to tighten Cam-bolt vertically until shoulder is flushed (on the same level) with panel. Do not over-tighten or under-tighten.

INSERTING CAM-LOCK



Insert Cam-lock with arrow align to Cam-bolt head.




CORRECT

WRONG




Align the arrow on the Cam-lock to the Cam-bolt head and insert the Cam-lock. Ensure Cam-lock is fully inserted.



TIGHTENING CAM-LOCK



Use a Flat-head Screwdriver to turn Cam-lock clockwise so it locks onto the head of the Cam-bolt. Turn until it is snug (about 3/4ths of a turn) -- over-tightening could damage Cam-lock or/and Cam-bolt.



STEP 1



A		15 pcs
O		1 pc
P		1 pc



- Lay Top Panel (4), Bottom Connect Bar (1), Left Panel (5) and Right Panel (6) as shown on a material that does not scratch the surface of each part.
- Screw in Cam-bolt (A) into the designated holes on each. Refer to Page 5 for instructions on inserting and tightening Cam-bolt.
- Attach Bracket (O) to (4) by using Screw (P) as shown.



STEP 2



B		3 pcs
J		2 pcs



- Insert Wood Dowel (J) to designated hole on Bottom Panel (2) as shown.
- Attach Bottom Connect Bar (1) to (2) via Cam-bolts on (1) and Wood dowels on (2).
- Insert Cam-lock (B) into the holes on (2) then turn clockwise to lock onto Cam-bolt.

STEP 3


D		2 pcs
K		1 pc






Attach Magnetic Catch (K) to Shelf (3) by using Screw (D).

STEP 4

- Insert Wood Dowel (J) to designated hole on Left Panel (5) as shown.
- Attach Bottom Panel (2) with Bottom Connect Bar (1), Shelf (3) and Top Connect Bar (11) to (5) via Cam-bolts on (5) and Wood dowels.
- Insert Cam-lock (B) into the holes on (1, 2, 3 & 11) then turn clockwise to lock onto Cam-bolt.






B		4 pcs
J		6 pcs




STEP 5

- Insert Wood Dowel (J) to designated hole on (1, 2, 3 & 11) as shown.
- Attach Right Panel (6) to (1, 2, 3 & 11) via Cam-bolts on (6) and Wood dowels.
- Insert Cam-lock (B) into the holes on (1, 2, 3 & 11) then turn clockwise to lock onto Cam-bolt.







B		4 pcs
J		6 pcs




STEP 6


- Insert Wood Dowel (J) to designated hole on Left Panel (5), Right Panel (6) and Top Connect Bar (11) as shown.
- Attach Top Panel (4) to (5, 6 & 11) via Cam-bolts on (4) and Wood dowels.
- Insert Cam-lock (B) into the holes on (5 & 6) then turn clockwise to lock onto Cam-bolt.
- Fasten Top Connect Bar (11) to Top Panel (4) with Screw (C).



B		4 pcs
C		3 pcs
J		6 pcs



STEP 7




F		26 pcs
---	---	--------




Attach Back Panel (9 & 10) with Screw (F).
Important: the upper back panel is bigger.

STEP 8



- Attach Hinge (G) to Door (7 & 8) with Screw (E).
- Attach Magnetic Bar (L) to Door (7 & 8) with Screw (E).
- Attach Handle (I) to Door (7 & 8) with Handle Bolt (H).

STEP 9



- Attach Door (7 & 8) to Side Panel with Hinge on Door and Screw (E).
- Drill a hole in the dry wall as per the length and diameter of Plastic Anchor (M) and the height need to be same as the screw hole on Bracket (O).
- Press Plastic wall anchor (M) into the drilled hole. Ensure that the anchor fits securely in the wall.
- Drive Screw (N) through the screw hole on Bracket (O) into the screw hole on (M) to secure the Cabinet to the wall.

The Assembly of the cabinet is complete.