



+ QUICK SCREEN PLUS



Innovative frame designed to grip each slat with no need for welding or screwing

Complete powder coated aluminium screening kit in a box!

Easy to assemble and adjust size

Patented no weld system

- › **Width + height adjustable**
Simply cut to desired size if required
- › **Easily adjustable slat spacing**
Spacer blocks included in kit for 9mm, 15mm or 20mm slat spacing (any slat spacing is possible)
- › **Quick & easy assembly**
- › **Simple push together system**
No welding or screws required!
- › **Clean finish**
No visible fixings
- › **Full instructions in pack**

Powder coat & timber image finishes



Black



Monument



Woodland grey









Primrose



White

1800mm W x 1200mm H panel



Profile	Description	Length	Qty
	65mm slat	1786mm	16
	Snap together side frame	1200mm	2
	Side frame end cap (Fitted to side frame with screws)	-	4
	Self drilling wafer head screws	-	16
	Spacer blocks	-	34

ORDER CODE:

QSP-1800-1200-B (Black) - SC-10560


QSP-1800-1200-MN (Monument) - SC??








QSP-1800-1200-G (Woodland Grey) - SC-10562

QSP-1800-1200-P (Primrose) - SC-10561

QSP-1800-1200-W (White) - SC-10563

2400mm W x 1200mm H panel




Profile	Description	Length	Qty
	65mm slat	2386mm	16
	Snap together side frame	1200mm	2
	Side frame end cap (Fitted to side frame with screws)	-	4
	Midrail with cover	1200mm	1
	Midrail end cap	-	1
	Self drilling wafer head screws	-	16
	Spacer blocks	-	34








ORDER CODE:

QSP-2400-1200-MN (Monument) - SC-10512

Quickscreen PLUS Kits

2400mm W x 1800mm H panel



Profile	Description	Length	Qty
	65mm slat	2386mm	24
	Snap together side frame	1800mm	2
	Side frame end cap (Fitted to side frame with screws)	-	4
	Midrail with cover	1800mm	1
	Midrail end cap	-	1
	Self drilling wafer head screws	-	24
	Spacer blocks	-	50

ORDER CODE:

QSP-2400-1800-B (Black) - SC-10564


QSP-2400-1800-MN (Monument) - SC-10513







QSP-2400-1800-G (Woodland Grey) - SC-10566

QSP-2400-1800-P (Primrose) - SC-10565

QSP-2400-1800-W (White) - SC-10567

1000mm W x 1800mm H gate



Profile	Description	Length	Qty
	65mm slat	964mm	20
	65mm gate slat	964mm	4
	Gate side frame	1800mm	2
	Top cap	-	2
	Hex head screws	-	17
	D&D latch packer	-	1

ORDER CODE:

QS-GATE-B (Black) - SC-10049

QS-GATE-MN (Monument) - SC-10526


QS-GATE-G (Woodland Grey) - SC-10050

QS-GATE-P (Primrose) - SC-1005

QS-GATE-W (White) - SC-10051


Tools required for installation

- Metal tape measure
- Spirit level
- Phillips head screwdriver bit (for drill)
- Carpenters pencil
- Power and/or cordless drill
- Timber, masonry or steel drill bits (as needed)
- Drop saw with suitable blade for cutting aluminium (if adjusting height or width)




STEP 1

Take measurement between wall or post at 3 points: top, middle and bottom.
Take note of the smallest width measurement.




STEP 2

Remove top cap and set aside for later use (Do not remove cap from bottom end of side frame).
Slide out the inner gripping channel.



STEP 3

Affix outer frame to post or wall with screws (sold separately)




STEP 4

Slide inner gripping channel back into outer frame

Panel assembly


25mm total deduction (cut one end only)



STEP 5

Cut aluminium slats **25mm** less than total width of opening. Refer to measurement in step 1.
The **25mm** deduction takes into account thickness of side frame on both sides of the screen

Rotate block for
9mm, 15mm or
20mm spacing




STEP 6

Push slats down into side frame ensuring spacer blocks are placed between each slat.


Spacer blocks supplied in kit allow slat spacing of 9mm, 15mm or 20mm. If a different spacing is required, source appropriate spacer blocks to achieve your desired slat spacing.

Spacer blocks are NOT removed after inserting slats and remain as part of the assembled screen



STEP 7

Once all slats are in place, carefully reattach top cap with screws




FINISHED!

HEIGHT ADJUSTMENT

To adjust height simply cut outer frame and inner gripping channel as required to desired height.

NOTE: Exact heights depend on spacing of slats. Please take care before cutting side frames to ensure height has been calculated correctly

Post & accessories



50x50mm full post

1800mm or 2400mm (Includes top cap)



Black
XP-1800-FP-B (1800mm Post)
HB-4624
XP-2400-FP-B (2400mm Post)
HB-4628



Monument
XP-2400-FP-MN (2400mm Post)



Woodland grey
XP-1800-FP-G (1800mm Post)
HB-4626
XP-2400-FP-G (2400mm Post)
HB-4630



Primrose
XP-1800-FP-P (1800mm Post)
HB-4625
XP-2400-FP-P (2400mm Post)
HB-4629



White
XP-1800-FP-W (1800mm Post)
HB-4627
XP-2400-FP-W (2400mm Post)
HB-4631



Base plate set suits 50x50mm post

100x100mm aluminium BP with 4x screws



Black
XP-BP-SET-B
HB-4641



Monument
XP-BP-SET-MN





Woodland grey
XP-BP-SET-G
HB-4643



Primrose
XP-BP-SET-P
HB-4642



White
XP-BP-SET-W
HB-4644



Louvre brackets

Pair of brackets - 2 Brackets + 2 Fixing Screws



Black
QS-LB-B
SC-10332



Monument
QS-LB-MN
SC-10333



Woodland grey
QS-LB-G
SC-10338



Primrose
QS-LB-P
SC-10376




White
QS-LB-W
SC-10377

Gate hardware




Tru close heavy duty hinges
Rated for gates up to 70kg
Pair of hinges

ORDER CODE:
TC-H-AT-HD-B
SLHSTRATE



Lokk latch deluxe


ORDER CODE:
LL-DL
SLLD



Aluminium hinge

Sold as a pair
Each hinge is rated up to 20kg

ORDER CODE:
KF-AH-AT
ZLB-QFALUM-2PK




D&D latch packer

Only required if using D&D Lokk latch deluxe
SUPPLIED WITH GATE

ORDER CODE:
XP-PACKER





Post to post installation




OR




Wall to post installation




Gate assembly



On a flat protected surface, lay 1x gate side frame with slotted spacer infill and rest against a padded stop and tap slats and gate blades into place




Elevate the slats and gate side frame on two padded bearers to allow the second gate side frame to be attached
Place the slat comb between all slats to prevent any movement of slats in the next step




Engage the second gate side frame to the slats and tap the frame until all the slats are fully engaged


TIP: Start at one end and work slats in from one end to the other



Screw off gate blades at required positions. Ensure gate is square by measuring diagonals




Slide the 2x outer infills down into position to hide screw heads



Slide 2x outer infills past end of gate side frame (approx. 10mm), then using pliers, bend inner legs of outer infill slightly outwards.

Tap outer infill back to level with gate side frame

This step is required to stop the outer infill from sliding down prior to hardware installation



Insert top caps into side frames

To determine the actual slat width for your gate, make a deduction of 36mm to the overall gate width (outer edge to outer edge of gate side frame)

FORMULA: $\text{OVERALL GATE WIDTH} - 36\text{MM}$
for slat width

You need to allow for hinge and latch gaps

Check hinge and latch hardware specifications for gaps required and take this information into account when determining overall gate width