



## Assembly Instructions




# General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are : wood dowels , screws and bolts.
- V. The provided glue is to secure wood dowels in place . When first inserting dowels , locate the appropriate hole for the dowel , place a small amount of glue in the hole and insert the dowel . Wipe away excess glue immediately.




In future assembly steps when dowels are necessary to attach assembly parts together , place a small amount of glue on the end of the dowel before attaching parts together . Wipe away excess glue immediately.




- VI. A Phillips head screwdriver is required for the assembly of this product .





















- VII. Power tools should not be used to assemble this product .




# Parts List



# Hardware List


A		Ø3x15	screw	2 pcs
B		Ø8x30mm	Wooden dowel	25 pcs
C		Ø15x11mm	Cam lock	20 pcs
D		Ø6x32mm	Cam bolt	20 pcs
E		Ø30mm	Sticker	20 pcs
F			Plastic wedge	4 pcs
G		Ø3x17	Flat-head screw	4 pcs
H		Ø6x50mm	Bolt	3 pcs
J		Ø5x16mm	Shelf support pin	8 pcs
K		Ø3x12	Screw	13 pcs
L			Glue tube	1 pcs
M		Ø4x22mm	Bolt	2 pcs
N			Handle	1 pcs
P			Door plate	1 pcs
Q			Hinge	2 pcs
R			Door stopper	1 pcs
S		M 4	Hex key	1 pcs
T		Ø4x38mm	Screw	4 pcs




Phillips head screwdriver required for assembly  
(not included)

*The hardware quantities listed above are required for proper assembly.  
Some extra hardware may also have been included.*


# Step 1




# Step 2





### Step 3





### Step 4





# Step 5




# Step 6




# Step 7




# Step 8





# Step 9




# Step 10




# Step 11





# Step 12




# Step 13




# Step 14




## Step 15




## Step 16



## Step 17



## Step 18



Final Assembly