



# ASSEMBLY INSTRUCTIONS

## Bookcase






























**AJ-DJ505465**  
**version: 1.0**

















# ASSEMBLY INSTRUCTIONS




# ASSEMBLY INSTRUCTIONS

 <p>① x1</p>	 <p>② x1</p>	 <p>③ x2</p>	 <p>④ x1</p>
 <p>⑤ x1</p>	 <p>⑥ x2</p>	 <p>⑦ x1</p>	 <p>⑧ x2</p>
 <p>⑨ x2</p>	 <p>⑩ x2</p>	 <p>⑪ x2</p>	 <p>⑫ x2</p>
 <p>⑬ x1</p>	 <p>⑭ x1</p>	 <p>⑮ x2</p>	 <p>⑯ x2</p>
 <p>⑰ x2</p>	 <p>⑱ x2</p>	 <p>⑲ x1</p>	 <p>⑳ x1</p>
 <p>㉑ x1</p>	 <p>㉒ x1</p>	 <p>㉓ x2</p>	 <p>㉔ x6</p>
 <p>㉕ x2</p>	 <p>㉖ x1</p>	 <p>㉗ x1</p>	

# ASSEMBLY INSTRUCTIONS


<p><b>A</b> x62+4</p>  <p>Ø6x30mm</p>	<p><b>B</b> x58+4</p>  <p>Ø6x35mm</p>	<p><b>C</b> x58+4</p>  <p>Ø15x10mm</p>	<p><b>D</b> x34+2</p>  <p>Ø5x38mm</p>
<p><b>E</b> x1</p> 	<p><b>F</b> x21+2</p> 	<p><b>G</b> x4</p> 	<p><b>H</b> x29+2</p>  <p>Ø6xØ3x12mm</p>
<p><b>I</b> x8+1</p> 	<p><b>J</b> x56+4</p>  <p>Ø20mm</p>	<p><b>K</b> x28+2</p>  <p>Ø6x3x16mm</p>	<p><b>L</b> x2</p>  <p>Ø8xØ4x38mm</p>  <p>Ø8xØ4x12mm</p>
<p><b>M</b> x1</p>  <p>5.0V 2.0A</p>	<p><b>N</b> x1</p>  <p>3mm</p>		

# ASSEMBLY INSTRUCTIONS





## friendly reminder

To avoid errors and confusion during the installation of accessories, use the type and quantity of hardware accessories according to the installation procedure described in the instructions. First, unroll the accessories bag and lay out the hardware accessories, cut holes in the side, and take out the hardware accessories






# INSTALLATION INSTRUCTION

## STEP 01



# X2

## STEP 02




# X2

# INSTALLATION INSTRUCTION

## STEP 03

# X2



A x4



Ø6x30mm

C x4




Ø15x10mm


Notice that the groove is on the reverse side

## STEP 04

# X2




B x6




Ø6x35mm

# INSTALLATION INSTRUCTION

## STEP 05




## STEP 06



# INSTALLATION INSTRUCTION

## STEP 07

# X2




A x4




Ø6x30mm

## STEP 08

# X2




Hx8




Ø6xØ3x12mm

Gx4



# INSTALLATION INSTRUCTION

## STEP 09



# X2

A x8





Ø6x30mm



C x12



Ø15x10mm



## STEP 10




The thin plate needs to be fully inserted into the groove. If the insertion is not smooth, you can try pressing from the front or the back to make adjustments until the thin plate is fully inserted into the groove.




# INSTALLATION INSTRUCTION

## STEP 13




## STEP 14




# INSTALLATION INSTRUCTION

## STEP 15





## STEP 16





# INSTALLATION INSTRUCTION

## STEP 17




The thin plate needs to be fully inserted into the groove. If the insertion is not smooth, you can try pressing from the front or the back to make adjustments until the thin plate is fully inserted into the groove.

## STEP 18




# INSTALLATION INSTRUCTION

## STEP 19





## STEP 20




# INSTALLATION INSTRUCTION

## STEP 21



## STEP 22





Note that both sides of Board No. ⑥ protrude by the same amount

Plate # ⑥ must not be tilted during installation.



When installing Component No. 6, the cooperation of two people is required. One person pulls in the front and the other pushes from behind.

# INSTALLATION INSTRUCTION


## STEP 23



## STEP 24





This step requires the cooperation of two people. First, insert the Dowel (A 6pcs). Then, one person uses both hands to push Part #(6) inward so that it can fit into the slot of Part #(7). The other person is preparing to carry out step 24.





# INSTALLATION INSTRUCTION

## STEP 25





## STEP 26






# INSTALLATION INSTRUCTION




## STEP 27



## STEP 28




First lock accessory D,  
then lock accessory C.




# INSTALLATION INSTRUCTION

## STEP 29




This step requires you to push Part #6 back into the groove of Part #7.

## STEP 30




The thin plate needs to be fully inserted into the groove. If the insertion is not smooth, you can try pressing from the front or the back to make adjustments until the thin plate is fully inserted into the groove.




# INSTALLATION INSTRUCTION

## STEP 31




# INSTALLATION INSTRUCTION

## STEP 32





## STEP 33



The thin plate needs to be fully inserted into the groove. If the insertion is not smooth, you can try pressing from the front or the back to make adjustments until the thin plate is fully inserted into the groove.



# INSTALLATION INSTRUCTION

## STEP 34




## STEP 35

The thin plate needs to be fully inserted into the groove. If the insertion is not smooth, you can try pressing from the front or the back to make adjustments until the thin plate is fully inserted into the groove.





Caution: If the screw #D cannot be installed properly, you can raise the bottom and then tighten the screw #D.





# INSTALLATION INSTRUCTION

## STEP 36

The thin plate needs to be fully inserted into the groove. If the insertion is not smooth, you can try pressing from the front or the back to make adjustments until the thin plate is fully inserted into the groove.






This installation step takes two people to complete



# INSTALLATION INSTRUCTION

## STEP 37



# INSTALLATION INSTRUCTION

## STEP 38

The LED light strip (E) is first inserted from the back of Part # 26.

Diagram of wire installation for lamp fixture







Diagram of wire installation for lamp fixture

First, pass the lamp through the hole on the layer board, then remove the back film of the lamp. When removing the film, if you encounter the layer board, you can pull the lamp upwards to ensure that the film of the lamp can be removed. When pasting the lamp, it should be pasted from bottom to top.






# INSTALLATION INSTRUCTION

## STEP 39





The power input method of this lamp is to be connected to an external power socket (M).


- Fx20**  

- Hx20**  
  
 Ø6xØ3x12mm
- Mx1**  


# INSTALLATION INSTRUCTION

## STEP 40



OR



Based on your usage situation, you can fix the switch inside or outside the cabinet at a position that suits you.

Fx1





Hx1






Ø6xØ3x12mm

# INSTALLATION INSTRUCTION

## STEP 41









## STEP 42




# INSTALLATION INSTRUCTION

## STEP 43





# INSTALLATION INSTRUCTION

## STEP 44




X 2






# INSTALLATION INSTRUCTION

## STEP 45




# INSTALLATION INSTRUCTION

## STEP 46




First mark the wall with a pencil, drill the hole to a depth of about 40mm, and knock in the accessory (L)

L x2






# INSTALLATION INSTRUCTION

## STEP 47




# INSTALLATION INSTRUCTION

## STEP 48



Cover the visible hole with a cap

J x56



Ø20mm