


# 6 DOOR 2 DRAWER WARDROBE ASSEMBLY INSTRUCTIONS




**IMPORTANT**  
**FOR DOMESTIC USE ONLY**  
**PLEASE READ BEFORE YOU CONTINUE FURTHER**


## **CARE AND MAINTENANCE**

After unpacking this product please keep the original packaging in case it needs to be returned for any reason.

- Please ensure all fittings and parts are present before commencing with assembly.
- Never drag or push products as this could cause damage to the joints making it inferior.
- We strongly recommend that you keep children away from your work area.
- We recommend that you lay a blanket or sheet on the floor to avoid damage to both your floor and the product.
- Assemble this product as close to its final position as possible.
- Do not place this product next to a radiator or in direct sunlight.
- Do not drag or push items across your high gloss furniture as this may cause the surface to scratch
- Wood is a natural product and may expand if subjected to damp and may shrink or crack if subjected to heat. Therefore it is recommended that room temperature is maintained, with no sudden temperature fluctuations.
- Make sure any spillage is wiped off immediately.
- Do not place hot or chilled items directly on to the surface, use a place mat or marking will occur.
- For general cleaning use a soft cotton or micro fibre cloth, and do not use detergents of any kind.
- From time to time it may be necessary to tighten fittings, regular inspections should be carried out.
- Do not place on a wet or damp floor as staining may occur to your floor.



#### TOOLS REQUIRED
































### PARTS LIST

***Please Note:***

The below parts have all been stamped with the part number to help identify them during assembly.




Part Number	Part Description	Quantity	Carton
1	Base Panel	3	2/4
2	Frame	1	3/4
3	Right Side Panel	1	1/4
4	Right Division Panel	1	1/4
5	Left Division Panel	1	2/4
6	Back Baseboard	1	3/4
7	Left Side Panel	1	1/4
8	Front Baseboard	1	3/4
9	Top Panel	1	3/4
10	Upper Panel	3	2/4
11	Right Large Door	2	4/4
12	Left Large Door	2	3/4
13	Right Small Door	1	4/4
14	Left Small Door	1	4/4
15	Drawer Side	4	1/4
16	Drawer Back Panel	2	1/4
17	Drawer Front	2	1/4
18	Drawer Bottom	2	2/4
19	Drawer Bottom Support Bar	2	1/4
20	Back Panel	6	(2) 2/4 / (4) 4/4
21	Central Baseboard	2	1/4

## FITTINGS LIST




<b>A</b>  Flat Head Screw Ø6,0 x 10mm (8x) +/1	<b>B</b>  Flan Head Screw Ø4,0 x 14mm (18x) +/1	<b>C</b>  Flat Head Screw Ø4,0 x 14mm (96x) +/2	<b>D</b>  Flan Head Screw Ø4,0 x 20mm (16x) +/2
<b>E</b>  Flat Head Screw Ø3,5 x 40mm (4x) +/1	<b>F</b>  Flat Head Screw Ø4,0 x 50mm (36x) +/2	<b>G</b>  Dowel Ø6,0 x 30mm (60x) +/2	
<b>H</b>  Nail 10 x 10 (136x) +/2	<b>I</b>  Back Panel Bracket (32x) +/2	<b>J</b>  'L' Metallic Support (19x) +/1	<b>K</b>  Washer (4x) +/1
<b>L</b>  Plastic Foot (8x) +/1	<b>M</b>  Hanging Rail Support (6x) +/1	<b>N</b>  Flan Head Screw Ø3,5 x 30mm (2x) +/1	<b>O</b>  Hinge (18x)
<b>P</b>  Hinge Plate (18x)	<b>Q</b>  Drawer Runners (2x)		
<b>R</b>  Back Panel Strip (3x)	<b>S</b>  Strap (2x)	<b>T</b>  Handle (8x)	<b>U</b>  Hole Plugs (18x) +/2
<b>V</b>  Glue (2x)	<b>W</b>  Cam Nut (4x) +/1	<b>X</b>  Cam Bolt (4x) +/1	<b>Y</b>  Hanging Rail (3x)
<b>Z</b>  Flat Head Screw Ø4,0 x 12mm (50x) +/2	<b>A1</b>  Door Support (6x)	<b>B1</b>  Dowel Ø6,0 x 50mm (4x) +/1	<b>C1</b>  Hole Plugs (10x) +/2

### TIPS FOR FITTINGS CAM-LOCKS

WHEN FITTING CAM NUT. ENSURE STARTING POSITION IS CORRECT BEFORE YOU INSERT CONNECTING CAM BOLT TURN CLOCKWISE UNTIL SECURE



**CAMBOLT**  
 Tighten until shoulder in flush with panel. Do not overtighten or undertighten (see example beside)




# STEP 1

## PARTS REQUIRED

1 - BASE PANEL x3

10 - UPPER PANEL x1


## HARDWARE REQUIRED

G  12  
Ø6,0 x 30mm



V  01  
Glue

Z  06  
Ø4,0 x 12mm

A1  03

B1  04  
Ø6,0 x 50mm

## TOOLS REQUIRED



# STEP 2

## PARTS REQUIRED

6 - BACK BASEBOARD x1

8 - FRONT BASEBOARD x1



10 - UPPER PANEL x2

## HARDWARE REQUIRED

G  12  
Ø6,0 x 30mm

V  01  
Glue

## TOOLS REQUIRED




# STEP 3

## PARTS REQUIRED

5 - LEFT DIVISION PANEL x1


## HARDWARE REQUIRED

C  08  
Ø4,0 x 14mm






G  02  
Ø6,0 x 30mm

M  01

P  03

V  01

## TOOLS REQUIRED



# STEP 4

## PARTS REQUIRED

5 - LEFT DIVISION PANEL x1

## HARDWARE REQUIRED

A  04  
Ø6,0 x 10mm






C  08  
Ø4,0 x 14mm

M  01

P  03

Q  Left 02

## TOOLS REQUIRED





# STEP 5

## PARTS REQUIRED

4 - RIGHT DIVISION PANEL x1


## HARDWARE REQUIRED

C  08  
Ø4,0 x 14mm






G  02  
Ø6,0 x 30mm

M  01

P  03

V  01

## TOOLS REQUIRED




# STEP 6

## PARTS REQUIRED

4 - RIGHT DIVISION PANEL x1


## HARDWARE REQUIRED

A  04  
Ø6,0 x 10mm






C  08  
Ø4,0 x 14mm

M  01

P  03

Q  02  
Right

## TOOLS REQUIRED




# STEP 7

## PARTS REQUIRED

3 - RIGHT SIDE PANEL x1

## HARDWARE REQUIRED

C  08  
Ø4,0 x 14mm






H  02

L  02

M  01

P  03

## TOOLS REQUIRED



# STEP 8

## PARTS REQUIRED

7 - LEFT SIDE PANEL x1

## HARDWARE REQUIRED

C  08  
Ø4,0 x 14mm






H  02

L  02

M  01

P  03

## TOOLS REQUIRED



# STEP 9

## PARTS REQUIRED


9 - TOP PANEL x1

## HARDWARE REQUIRED



G  04  
Ø6,0 x 30mm

V  01  
Glue

Z  06  
Ø4,0 x 12mm

A1  03

## TOOLS REQUIRED



# STEP 10

## PARTS REQUIRED



9 - TOP PANEL x1

## HARDWARE REQUIRED

J  05

Z  05  
Ø4,0 x 12mm

## TOOLS REQUIRED




# STEP 11

## PARTS REQUIRED



21 - CENTRAL BASEBOARD x2

## HARDWARE REQUIRED

G  08  
Ø6,0 x 30mm

V  01

## TOOLS REQUIRED



# STEP 12

## PARTS REQUIRED

6 - BACK BASEBOARD x1

8 - FRONT BASEBOARD x1


21 - CENTRAL BASEBOARD x2


## HARDWARE REQUIRED

H  04




J  04

L  04


V  01

Z  08  
Ø4,0 x 12mm


## TOOLS REQUIRED



Detail 1



Detail 10




Detail 11

# STEP 13




## PARTS REQUIRED

1 - BASE PANEL	x1
4 - RIGHT DIVISION PANEL	x1
5 - LEFT DIVISION PANEL	x1
10 - UPPER PANEL	x1


## HARDWARE REQUIRED



## TOOLS REQUIRED




Detail 1



Detail 12


# STEP 14

## PARTS REQUIRED




10 - UPPER PANEL	x2
------------------	----


## HARDWARE REQUIRED



## TOOLS REQUIRED



Detail 1





# STEP 15





## PARTS REQUIRED

1 - BASE PANEL	x2
9 - TOP PANEL	x1


## HARDWARE REQUIRED

F	 Ø4,0 x 50mm	08
V	 Glue	01

## TOOLS REQUIRED




Detail 1



Detail 12



# STEP 16






## PARTS REQUIRED

3 - RIGHT SIDE PANEL	x1
7 - LEFT SIDE PANEL	x1


## HARDWARE REQUIRED

F	 16 Ø4,0 x 50mm
V	 01

## TOOLS REQUIRED




Detail 1



Detail 12

# STEP 17




## PARTS REQUIRED

20 - BACK PANEL x6


## HARDWARE REQUIRED

B  18  
Ø4,0 x 14mm

H  24  
10 x 10


R  03

## TOOLS REQUIRED




### IMPORTANT PLEASE FOLLOW !

Please make sure Part 20 is lined up correctly at the top before placing fitting H into the panel as this can affect the alignment of the doors once assembled.




\* For your future reference Order Number should be here




### IMPORTANT PLEASE FOLLOW !

Please make sure Part 20 isn't overhanging at the sides before you screw fitting B into the plinth.




Detail 13





Detail 16

# STEP 18




## PARTS REQUIRED




## HARDWARE REQUIRED

H	 10 x 10	48
I		24

## TOOLS REQUIRED




Detail 13






Detail 14

# STEP 19




## PARTS REQUIRED




## HARDWARE REQUIRED

H	 10 x 10	08
J		08
Z	 Ø4,0 x 12mm	16

## TOOLS REQUIRED




Detail 13



Detail 15

# STEP 20



## PARTS REQUIRED




2 - FRAME x1

## HARDWARE REQUIRED

J  02

Z  Ø4,0 x 12mm 09


## TOOLS REQUIRED






Detail 17

# STEP 21

## PARTS REQUIRED



## HARDWARE REQUIRED



Detail 18

# STEP 22



## PARTS REQUIRED

15 - DRAWER SIDE	x4
------------------	----

16 - DRAWER BACK PANEL	x2
------------------------	----

19 - DRAWER BOTTOM SUPPORT BAR	x2
--------------------------------	----

## HARDWARE REQUIRED



Detail 1

# STEP 23




## PARTS REQUIRED

17 - DRAWER FRONT x2

## HARDWARE REQUIRED

X  04

## TOOLS REQUIRED




# STEP 24

## PARTS REQUIRED




15 - DRAWER SIDE x4

16 - DRAWER BACK PANEL x2

## HARDWARE REQUIRED

F  Ø4,0 x 50mm 04


## TOOLS REQUIRED



# STEP 25


## PARTS REQUIRED


17 - DRAWER FRONT x2




## HARDWARE REQUIRED

C1  04



V  01

W  04


## TOOLS REQUIRED




X2



Detail 1




Detail 21




# STEP 26


## PARTS REQUIRED

18 - DRAWER BOTTOM x2




## HARDWARE REQUIRED




H  10 x 10 08

V  01





## TOOLS REQUIRED



X2




Detail 22




# STEP 27


## PARTS REQUIRED

19 - DRAWER BOTTOM SUPPORT BAR X2




## HARDWARE REQUIRED


E  04  
Ø3,5 x 40mm

H  12  
10 x 10


## TOOLS REQUIRED




X2



Detail 1




Detail 22




# STEP 28

## PARTS REQUIRED




## HARDWARE REQUIRED


C  08  
Ø4,0 x 14mm

D  04  
Ø4,0 x 20mm



Q  04

T  02


## TOOLS REQUIRED



X2



X2





# STEP 29



## PARTS REQUIRED

11 - RIGHT LARGE DOOR	x2
12 - LEFT LARGE DOOR	x2
13 - RIGHT SMALL DOOR	x1
14 - LEFT SMALL DOOR	x1

## HARDWARE REQUIRED

C		36
O		18


## TOOLS REQUIRED





# STEP 30

## PARTS REQUIRED




11 - RIGHT LARGE DOOR	x2
12 - LEFT LARGE DOOR	x2
13 - RIGHT SMALL DOOR	x1
14 - LEFT SMALL DOOR	x1



## HARDWARE REQUIRED



U		16
C1		04

## TOOLS REQUIRED




# STEP 31





## PARTS REQUIRED



## HARDWARE REQUIRED




## TOOLS REQUIRED




Detail 26

# STEP 32



## PARTS REQUIRED




## HARDWARE REQUIRED




## TOOLS REQUIRED





### Height Adjustment




### Internal Adjustment




### Depth Adjustment



### Drawer Adjustment



### Drawer Lock



Detail 27

# WARNING

**Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall.**

Wall fixings are not supplied with this product as different wall materials require different types of fixing devices.

Please make sure you use fixings suitable for the walls in your home.

