

Outdoor Storage Shed


Assembly Guide



3 Hours



x 2




CUSTOMER FIRST, SERVICE FOREMOST!

QUESTIONS? ISSUES?

CONTACT US

REPLY WITHIN 24 HOURS IN BUSINESS DAYS

Exploded View



Thank you for purchasing this item, please read this instruction guide carefully before assembly and keep it for future reference.

THE TOOLS YOU NEED TO PREPARE



WARNING

- Remove all parts from the box and sort them by number. Ensure all parts are present before assembly.
- Wear work gloves, long sleeves and safety goggles during assembly. Some components contain sharp edges that may cause damage.
- Set your drill's torque limit to prevent damage to the metal parts.
- Ensure ground stability is adequate when necessary to use a ladder. Never rest your entire weight on the roof or on any other part of the storage shed.
- Do not attempt to assemble the storage shed in strong windy conditions.
- Keep children and animals away from the assembly site.

NOTICE: If there is slight bending on the corners



- ① Pls wear gloves and stretch the corners slightly until they are flat







































- ② Then the sheets will be normal and there is no effect to the assembling




Part List





The parts are stacked together for easier transportation. When you think something is missing, please try to separate every part first and check.

| PART | NO. | Qty. |
|---|-----|------|
|  | B1 | 1 |
|  | B2 | 1 |
|  | BL | 1 |
|  | BR | 1 |
|  | L1 | 1 |
|  | L2 | 1 |
|  | L3 | 1 |
|  | UP1 | 1 |
|  | M3 | 4 |
|  | M4 | 2 |
|  | W1A | 5 |
|  | W2A | 4 |
|  | W3A | 1 |
|  | P1 | 2 |
|  | P2 | 1 |
|  | P3 | 1 |
|  | DL1 | 1 |
|  | DR1 | 1 |
|  | ULA | 1 |
|  | URA | 1 |
| | 20 | 2 |


| PART | NO. | Qty. |
|---|------|------|
|  | S2 | 1 |
|  | S4 | 1 |
|  | S3 | 1 |
|  | DF | 1 |
|  | DX1 | 2 |
|  | DH | 2 |
|  | DG | 1 |
|  | GC | 4 |
|  | LOCK | 1 |
|  M4x10 | F1 | 172 |
|  M4x10 | F2 | 9 |
|  M5x12 | F3 | 16 |
|  M4x16 | F5 | 4 |
|  M10x100 | F6 | 4 |
|  | V2 | 150 |
|  | V1 | 150 |



Step1




| | |
|-----------|---|
| B1 |  |
| B2 |  1 PC |
| BL |  1PC |
| F1 |  4 PC |

Step2




| | |
|-----------|---|
| BR |  1 PC |
| F1 |  4 PC |


Step3



Remove the protective films from all panels first.
The light color side is the interior of the panel.
Combine [F1] and [V2] like this:







Step4






Step5


X: This screw hole doesn't need to be assembled in this step.







| | |
|-----|---|
| W2A |  |
| | 2 PC |
| F1 |  |
| | 7 PC |
| V2 |  |
| | 7 PC |


Step6

| | |
|----|---|
| L3 |  |
| | 1 PC |
| F1 |  |
| | 6 PC |
| V2 |  |
| | 6 PC |







Step7

| | | |
|----|--|------|
| L1 |  | 1 PC |
| L2 |  | 1 PC |
| F1 |  | 8 PC |
| V2 |  | 8 PC |




Step8

| | | |
|-----|---|-------|
| W1A |  | 2 PC |
| F1 |  | 16 PC |
| V2 |  | 16 PC |




Step9

W1A




2 PC

F1




16 PC

V2




16 PC




Step10

W1A




1 PC

F1




4 PC




V2




4 PC







Step11

| | |
|-----|---|
| UP1 |  |
| F1 | 1 PC |
| V2 |  |
| | 9 PC |
| |  |
| | 5 PC |



Step12









| | |
|-----|---|
| W3A |  |
| F1 | 1 PC |
| V2 |  |
| | 4 PC |
| |  |
| | 4 PC |

X: This screw hole doesn't need to be assembled in this step.




Step13


internal setup




| | | |
|-----|---|------|
| URA |  | 1 PC |
| ULA |  | 1 PC |
| F1 |  | 8 PC |
| V2 |  | 9 PC |
| F2 |  | 1 PC |

Step14

| | | |
|----|---|------|
| S2 |  | 1 PC |
| F1 |  | 8 PC |
| V2 |  | 8 PC |




Step15









| | |
|-------|--|
| S3 | |
| 1 PC | |
| S4 | |
| 1 PC | |
| F1 | |
| 8 PC | |
| V2 | |
| 10 PC | |
| F2 | |
| 2 PC | |


Step16



| | |
|-------|--|
| P1 | |
| 2 PC | |
| P2 | |
| 1 PC | |
| P3 | |
| 1 PC | |
| F1 | |
| 32 PC | |
| V2 | |
| 32 PC | |


Step17

| | | |
|----|--|------|
| M3 |  | 4 PC |
| M4 |  | 2 PC |
| GC |  | 4 PC |
| F1 |  | 2 PC |
| F5 |  | 4 PC |
| V2 |  | 2 PC |













Step18

The Parts List of Door





Step19







| | | | |
|---|---|--|---|
| DX1  2 PC | 20  2 PC | DL1  1 PC | DR1  1 PC |
| DG  1 PC | F1  14 PC | F2  6 PC | V2  8 PC |

Step20



Step21



Step22

After completing the installation,
cover the protruding screw tips with [V1] to prevent injury.

