


ASSEMBLY INSTRUCTIONS

Console Table



NOTE TO CUSTOMERS:

- For ease and speed of assembly we recommend that before you commence each step of the assembly that you identify all the parts required to complete that step.
- We recommend that where possible you allow sufficient space to assemble the item as close as possible to the place where it will be once assembled.
- For the protection of your furniture we recommend that the product is placed on protected surfaces during assembly to prevent any damage.
- During assembly do not over tighten, as this may damage the product.
- Please ensure you retain all the product packaging until the item completely assembled.
- Please periodically check all fittings and re-tighten as necessary.
- Please never allow any liquids to remain on your furniture as absorption can cause the wood to warp or finish to de-laminate.
- It is recommended that this item should be assembled by two adults.

To insert a cam lock: (Please read below instructions before assembling)





Diagram A



1. Insert cam screw into hole as shown in diagram A .





Diagram B



Make sure not to insert the cam screw:
Too deep as shown in figure B as this will cause the
cam screw to be misaligned and unable to
interlock properly.







Diagram C




Also avoid inserting the cam screw too close to the
surface of the hole as shown in figure C, as this will
cause the cam lock to be too loose, and not interlock
properly.



2. Connect the panels together.



3. When inserting the cam lock make sure the arrow
of the cam lock faces the cam screw.



4. To tighten the cam lock turn the cam lock clockwise
90-180 degree or until the arrow is facing opposite
the place cam lock was inserted.

**NOTE: DO NOT USE AN AUTOMATIC
SCREWDRIVER TO TIGHTEN CAM LOCKS.**

Note:

- Read these instructions carefully before assembling.
- Tools required : Phillips screwdriver, flat screwdriver.
- Find a clean, smooth area on which to work , such as a carpet, in order to avoid scratching the wood surfaces.
- Wait to dispose of the packing material until assembly is complete and all parts and hardware are accounted for.
- Two or more people might be required for assembly.














WARNING:

**Serious or fatal crushing injuries can occur from furniture tip-over.
To help prevent tip-over:**










- Place heaviest item in the lowest drawers.
- Unless specifically designed to accommodate, do not set TVs or other heavy objects on top of this product.
- Never allow children to climb or hang on drawers, doors or shelves.
- Never open more than one drawer at a time.(OR)
- Do not defeat or remove the drawer interlock system.

Use of tip-over restraints may only reduce, but not eliminate the risk of tip-over.











Part List

A1  Top Panel	Quantity of 1	A2  Side Panel (L&R)	Quantity of 2	A3  Bottom Panel	Quantity of 1	A4  Shelf Panel	Quantity of 1
A5  Divider	Quantity of 1	A6  Drawer Front Panel	Quantity of 2	A7  Drawer Side Panel (L&R)	Quantity of 4	A8  Drawer Back Panel	Quantity of 2
A9  Drawer Bottom Panel	Quantity of 2	A10  Cross Bar	Quantity of 1	A11  Back Panel	Quantity of 1		


Hardware List




B1  Wood Dowel	Quantity of 13	B2  Cam-Lock	Quantity of 12	B3  Knob with Screw	Quantity of 2	B4  Screw	Quantity of 18	B5  Bolts with Washers	Quantity of 4
B6  Screw	Quantity of 14	B7  Screw	Quantity of 2	B8  Anchor with Screw	Quantity of 1	B9  Anti-tip kit	Quantity of 1		

APPENDIX: Dimension of Hardwares in this AI.

B1  Wood Dowel	B2  Cam-bolt	B3  Cam-Lock	B4  Screw
B4  Screw	B5  Bolt	B6  Screw	B7  Screw
B8  Screw	B9  Screw		


STEP 1



B1		2pcs
B2		1set
B4		2pcs


Assemble Cross Bar A10 and Shelf Panel A4 to Divider A5 using Wood Dowels B1, Camlocks B2 and Screws B4 as shown above.

STEP 2



Assemble Side Panels A2(L&R) to Bottom Panel A5, Shelf Panel A4, Cross Bar A10 using Wood Dowels B1, Bolts with washers B5 and Camlocks B2 as shown above.


STEP 3



Assemble Top Panel A1 to Side Panels A2(L&R), Cross Bar A10 and Divider A7 using Wood Dowels B1, Camlocks B2 and Screws B7 as shown above.

STEP 4


B6  14pcs



Attach Back Panel A11 to the back of the table using Screws B6 as shown above.


STEP 5

B3  2sets
B4  16pcs




- 1). Assemble Drawer Side Panels A7(L&R) to Drawer Back Panel A8 using Screws B4.
- 2). Insert Drawer Bottom Panel A9 into the grooves on the Drawer Side Panels A7(L&R), Drawer Back Panel A8.
- 3). Assemble Drawer Front Panel A6 to Drawer Side Panels A7 (L&R) using Screws B4.
- 4). Attach Drawer Handle B3 to Drawer Front Panel A6 using included screws.
- 5). Repeat above steps to assemble the other drawer.


STEP 6



Insert Drawers into the table as shown above.

STEP 7

B8		1set
B9		1set



For your safety, please attach the table to the wall using Anchor with screw B8 and Anti-tip Kit B9 as shown above.