


# ***Assembly Instructions***



## ***warning notice***



- Open your item in the area you plan to keep it for less heavy lifting.



- Identify, sort, and count the parts before attempting assembly.



-Lay all parts on smooth flat surface.



-Make sure to always face the point on the top of the Cam Lock towards the outer edge.



-Do NOT use harsh chemicals or abrasive cleaners on this item.



- Never push, pull, or drag your furniture.



## ***Teamwork***

Failure to use 2 people for assembly could result in unit damage or personal injury.

# Before You Start


Read through each step carefully and follow the proper order

Separate and count all your parts and hardware

Give yourself enough room for the assembly process


Have the following tools: Phillips Head Screwdriver and Hammer

Caution: If using a power drill or power screwdriver for screwing please be aware to slow down and stop when screw is tight. Failure to do so may result in stripping the screw.




If the door panel is not sitting at a right position or angle, follow the steps below to improve.

- (1) Loosen the hinge, adjust the door panel position (up and down) then fasten the screws to secure the hinge (Step 1), or,
- (2) Loosen the middle screw of the hinge and adjust the door panel in and out, to desired position, then fasten the screws to secure the hinge (Step 2), or
- (3) Adjust the nut at the centre of the hinge to fine tune the tilting angle of the door panel (left or right) to make the door panel to be vertical.




# Components




# Components


① 1PC




② 1PC




③ 1PC




④ 1PC




⑤ 1PC




⑥ 1PC




⑦ 1PC




⑧ 1PC




⑨ 4pcs




⑩ 4pcs




⑪ 4pcs




⑫ 4pcs


















⑬ 4pcs



⑭ 4pcs




# Components

 <p>A x 30+2</p>	 <p>B x 30+2</p>	 <p>C x 10+1</p>	 <p>M3.5x12mm D x 32+2</p>
 <p>M4x30mm E x 24+2</p>	 <p>F x 4</p>	 <p>M3x12mm G x 8+1</p>	 <p>H x 8</p>
 <p>I x 4</p>	 <p>J x 1</p>	 <p>M4x12mm K x 16+1</p>	 <p>CR x 4</p>
 <p>CL x 4</p>	 <p>DL x 4</p>	 <p>DR x 4</p>	


# Assembly Instructions

## STEP 1



CR x 4	CL x 4	M3. 5x12mm
D x 16		


## STEP 2



A x 6

# Assembly Instructions

## STEP 3




Bx3



Cx1

## STEP 4




Bx3



Cx1

# Assembly Instructions

## STEP 5




C x 4



M4x30mm

E x 4

## STEP 6



F x 4





M4x12mm

K x 16

# Assembly Instructions

## STEP 7




Ax4



Jx1

## STEP 8




Bx4



Cx4

# Assembly Instructions



## STEP 9



M4x30mm

E x 20

## STEP 10



A x 20



B x 20



M3x12mm


G x 8



I x 4


# Assembly Instructions

## STEP 11




x 4


REMARK:



D x 16





DL x 4



DR x 4



## STEP 12



H x 8

# Assembly Instructions

## STEP 13



J x 1

# Assembly Instructions

## STEP 14

