














**CROSLEY**  
FURNITURE










Low Record Console  
CF1149



# PART LIST


<b>A</b> 	<b>B</b> 	<b>C</b> 	<b>D</b> 	<b>E</b> 
Left Frame 1 PC	Right Frame 1 PC	Top 1 PC	Bottom 1 PC	Back Top Rail 1 PC
<b>F</b> 	<b>G</b> 	<b>H</b> 	<b>I</b> 	<b>J</b> 
Back Bottom Rail 1 PC	Left Partition Panel 1 PC	Right Partition Panel 1 PC	Front Rail 2 PCS	Middle Partition Panel 1 PC
<b>K</b> 	<b>L</b> 			
Leg 4 PCS	Support Leg 1 PC			

# HARDWARE LIST

<p>#1</p>  <p>Ø8mm*1-1/8"</p>	<p>#2</p>  <p>Ø1/4"*1-3/4"</p>	<p>#3</p> 	<p>#4</p>  <p>Ø1/4"*1-1/4"</p>	<p>#5</p>  <p>Ø1/4"*5/8"</p>
<p>Wood Dowel 30 PCS (Extra 1)</p>	<p>Long Bolt 4 PCS (Extra 1)</p>	<p>Crescent Washer 4 PCS (Extra 1)</p>	<p>Medium Bolt 15 PCS (Extra 1)</p>	<p>Short Bolt 24 PCS (Extra 1)</p>
<p>#6</p> 	<p>#7</p> 	<p>#8</p> 	<p>#9</p>  <p>4mm</p>	
<p>Metal Plate 4 PCS</p>	<p>Cam Bolt 10 PCS (Extra 1)</p>	<p>Cam Lock 10 PCS (Extra 1)</p>	<p>Allen Wrench 1 PC</p>	

## ADDITIONAL TOOLS (Not Provided)






Note: It is not recommended to use power tools during assembly.



Phillips Head Screwdriver



Note: Wood dowels are intended for alignment. Additional clearance between wood dowel and pre-drilled hole is intentional for ease of assembly.



Step 1. Attach cam bolts (part #7) to left frame (part A), right frame (part B), top (part C), left partition panel (part G) and right partition panel (part H).  
Note: Do not overtighten cam bolts. Stop tightening once threads on cam bolt are no longer visible.





#7  x 10



Step 2. Attach middle partition panel (part J) to top (part C) using wood dowels (part #1), cam locks (part #8) and phillips head screwdriver. Note: Cam locks must rotate a full 180°. See pictured insert.




- #1  x 2
- #8  x 2



Step 3. Attach left partition panel (part G) and right partition panel (part H) to top (part C) using wood dowels (part #1), cam locks (part #8) and phillips head screwdriver. Note: Cam locks must rotate a full 180°. See pictured insert.





- #1  x 4
- #8  x 4



Step 4. Attach back top rail (part E) to assembled unit (parts G & H) using medium bolts (part #4) and allen wrench (part #9).



- #4  x 2
- #9  x 1



Step 5. Attach front rails (part I) to assembled unit (parts G & H) using cam locks (part #8), wood dowels (part #1) and phillips head screwdriver. Note: Cam locks must rotate a full 180°. See pictured insert.








- #1  x 2
- #8  x 2


Step 6. Attach right frame (part B) to assembled unit (parts E & I) using cam lock (part #8), wood dowels (part #1), long bolt (part #2), crescent washer (part #3), allen wrench (part #9) and phillips head screwdriver.





Note: Cam locks must rotate a full 180°. See pictured insert.



- #1  x 3
- #2  x 1
- #3  x 1
- #8  x 1
- #9  x 1


Step 7. Attach back bottom rail (part F) to right frame (part B) using wood dowels (part #1), long bolt (part #2), crescent washer (part #3), and allen wrench (part #9)








- #1  x 2
- #2  x 1
- #3  x 1
- #9  x 1


Step 8. Attach left frame (part A) to assembled unit (parts E, F & I) using cam lock (part #8), wood dowels (part #1), long bolts (part #2), crescent washers (part #3), allen wrench (part #9) and phillips head screwdriver.




Note: Cam locks must rotate a full 180°. See pictured insert.




- #1  x 5
- #2  x 2
- #3  x 2
- #8  x 1
- #9  x 1

Step 9. Attach bottom (part D) to assembled unit (parts A, B, F, G, H & J) using wood dowels (part #1), medium bolts (part #4) and allen wrench (part #9).



- #1  x 12
- #4  x 13
- #9  x 1

Step 10. Attach metal plate (part #6) to leg (part K) using short bolts (part #5) and allen wrench (part #9).





#5  x 8

#6  x 4

#9  x 1


Step 11. Attach assembled legs (part K) to bottom (part D) using short bolts (part #5) and allen wrench (part #9). Attach support leg (part L) to bottom (part D).



#5  x 16

#9  x 1

Step 12. Carefully turn unit upright.



**Note:** It is important to adjust levelers once fully assembled and upright. Extend adjustable leveler until it's firmly in contact with the floor. If relocating, adjust leveler as needed until it's firmly in contact with the floor in new location.