



# Assembly Instructions























HOU864/HOU865














We come with the necessary tools for assembly, but for faster assembly, a power drill is recommended.
























## Parts List


ITEM	PART	QTY	ITEM	PART	QTY
①		1PC	⑫		2PCS
②		1PC	⑬		1PC
③		1PC	⑭		2PCS
④		1PC	⑮		1PC
⑤		1PC	⑯		1PC
⑥		1PC	⑰		1PC
⑦		1PC	⑱		1PC
⑧		1PC	⑲		2PCS
⑨		1PC	⑳		2PCS
⑩		1PC	㉑		1PC
⑪		1PC	㉒		2PCS


## Parts List

ITEM	PART	QTY
23		1PC
24		1PC
25		1PC
26		1PC
27		1PC
28		1PC
29		2PCS
30		1PC
31		1PC
32		2PCS
33		1PC

## Hardware List


ITEM	PART	QTY	ITEM	PART	QTY
A	 Ø6x35mm	71+5 PCS	K		8+1 PCS
B	 Ø15x10mm	83+5 PCS	L	 M6x40mm	2+1 PCS
C	 Ø6x30mm	48+4 PCS	M	 M6x30mm	2+1 PCS
D	 Ø5x38mm	13+1 PCS	N		38+3 PCS
E	 340mm	2 PCS		 Ø6xØ3x16mm	38+3 PCS
F	 Ø6xØ3x12mm	24+2 PCS	O		2 PCS
G		3 PCS	P	 Ø20mm	36+4 PCS
H	 Ø7xØ3.5x14mm	24+2 PCS	Q		6+1 PCS
I		4 PCS	R	 4mm	1 PC
J		1 PC	S		6 PCS
		1 PC			






## friendly reminder

To avoid errors and confusion during the installation of accessories, use the type and quantity of hardware accessories according to the installation procedure described in the instructions. First, unroll the accessories bag and lay out the hardware accessories, cut holes in the side, and take out the hardware accessories




# 01




Extend slides E x2, then push the release lever upward to detach the outer rail E1 x2 and the inner rail E2 x2 as shown.




# 02



Install the outer rail E1 x2 to Part #7 and Part #8 with screws F x6 as shown.




03




Install Cam Bolt A x4 to Part #7 and Part #8 as shown.





04



Install O x2 to Part #9 with screws F x4 as shown.



# 05




Attach Part #7&8 to Part #9 with dowel C x4 and nuts B x4 as shown.

Attach Part #7&8 to Part #33 with screws L x2 as shown.

Then turn nuts B x4 to secure position.

	<b>Bx4</b>
	<b>Cx4</b>
	<b>Lx2</b>
	<b>Rx1</b>


# 06



The thin plate needs to be fully inserted into the groove. If the insertion is not smooth, you can try pressing from the front or the back to make adjustments until the thin plate is fully inserted into the groove.

Turn the assembled unit 90° as shown.  
 Unfold Part #31 and insert it into the grooves of the assembled unit as shown.

# 07




When inserting component **B**, the dimensions of the protruding parts on both sides of component **Q** should be kept consistent, and component **B** should be locked simultaneously.

Connect Part #3 to Part #4 with Q x3, dowel C x2, and nuts B x6 as shown.  
 Then tighten the nuts B on both sides of each Q simultaneously using a screwdriver and tool R as shown.

	Bx6
	Cx2
	Qx3
	Rx1


08



Install Cam Bolt A x20 to Part #3 and Part #4 as shown.




09



Install Cam Bolt A x10 to Part #15, #16 and #17 as shown.




# 10



Attach Part #15, #16 and #17 to Part #3&4 with dowel C x6 and nuts B x10 as shown.  
Then turn nuts B x10 to secure position.

	Bx10
	Cx6


# 11



Attach Part #3&4 to Part #7&8 with dowel C x4 and screws D x4 as shown.  
This step should be carried out by two adults.


	Cx4
	Dx4

12





Make sure the components are kept level.


Attach Part #20 x2 to Part #21 with screws D x2 as shown.





13



Install Cam Bolt A x2 to Part #18 as shown.






14





Attach Part #18 to Part #20 x2 with nuts B x2 as shown.  
Then turn nuts B x2 to secure position.






# 15





Attach the assembled unit to Part #3&4 with dowel C x4 and nuts B x10 as shown.  
Then turn nuts B x10 to secure position.

	Bx10
	Cx4



# 16



Turn the assembled unit 90° as shown.  
 Attach Part #19 x2 to Part #3&4 with dowel C x4 and nuts B x6 as shown.  
 Then turn nuts B x6 to secure position.  
 This step should be carried out by two adults.




# 17




Attach Part #22 x2 to Part #3&4 with nuts B x4 as shown.  
 Then turn nuts B x4 to secure position.





18




Secure Part #22 x2 with screws D x2 as shown.




19





Install Cam Bolt A x4 to Part #5 and Part #6 as shown.



# 20





Attach Part #5&6 to Part #3&4 with dowel C x4 and nuts B x4 as shown.  
Then turn nuts B x4 to secure position.

	Bx4
	Cx4


Ø6x30mm

# 21



Turn the assembled unit 90° as shown.  
When performing the flipping operation, make sure that the two people involved coordinate their movements and do it gently.


# 22




The thin plate needs to be fully inserted into the groove. If the insertion is not smooth, you can try pressing from the front or the back to make adjustments until the thin plate is fully inserted into the groove.

Insert Part #29 x2 and Part #30 into the grooves of the assembled unit as shown.

# 23



When inserting component **B**, the dimensions of the protruding parts on both sides of component **Q** should be kept consistent, and component **B** should be locked simultaneously.




Connect Part #1 to Part #2 with Q x3, dowel C x2, and nuts B x6 as shown.

Then tighten the nuts B on both sides of each Q simultaneously using a screwdriver and tool R as shown.

	Bx6
	Cx2
	Qx3
	Rx1


# 24




Install Cam Bolt A x18 to Part #1&2 as shown.




# 25







Attach Part #13 and Part #14 x2 to Part #1&2 with dowel C x6 and nuts B x10 as shown.  
Then turn nuts B x10 to secure position.




# 26



Turn Part #1&2 180° as shown.  
 Attach Part #1&2 to the assembled unit from Step 22 with  
 dowel C x8 and nuts B x8 as shown.  
 Turn nuts B x8 to secure position.  
 Then secure Part #33 to Part #1&2 with screws M x2 as  
 shown.

	<b>Bx8</b>
 Ø6x30mm	<b>Cx8</b>
 M6x30mm	<b>Mx2</b>
 4mm	<b>Rx1</b>

27




X2

Install Cam Bolt A x8 to Part #12 x2 as shown.

Ax8

28



Installation completion diagram

Attach Part #12 to Part #5 with dowel C x2 and nuts B x4 as shown.


Then turn nuts B x4 to secure position.

Bx4

Ø6x30mm

Cx2

# 29




Installation completion diagram

Attach Part #12 to Part #6 with dowel C x2 and nuts B x4 as shown.  
Then turn nuts B x4 to secure position.

	Bx4
	Cx2 Ø6x30mm

# 30





Pay attention to first passing the socket wire through the hole in the back panel.

Attach socket J to Part #1 with screws F x2 as shown.

	Fx2 Ø6xØ3x12mm
	Jx1

# 31




You can also install the No. (11) component on the right side.

Install K x8 to the assembled unit, then put Part #10 and Part #11 on K x8 as shown.



Kx8

# 32



Attach hinge I x4 to Part #32 x2 with screws H x8 as shown.




Hx8

Ø7xØ3.5x14mm



I x4


# 33




Attach Part #32 x2 to the assembled unit with screws H x16 as shown.




# 34



Install handle G x2 to Part #32 x2 with screws F x4 as shown.



# 35




Pay attention to the slot direction of each component.

Attach Part #24 and Part #25 to Part #26 with screws D x4 as shown.




# 36



Attach Part #27 to Part #26 with screws D as shown. Pay attention to the hole direction of Part #27.





37



The thin plate needs to be fully inserted into the groove. If the insertion is not smooth, you can try pressing from the front or the back to make adjustments until the thin plate is fully inserted into the groove.

Insert Part #28 into the grooves of the assembled unit as shown.


38



Install Cam Bolt A x5 to Part #23 as shown.



# 39




Attach Part #23 to the assembled unit from Step 37 with nuts B x5 as shown.  
Then turn nuts B x5 to secure position.



Bx5

# 40



Attach the inner rail E2 to Part #24 with screws F x2 as shown.  
Then turn the drawer 180° as shown.  
Attach the inner rail E2 to Part #25 with screws F x2 as shown.



E2x2



Fx4

Ø6xØ3x12mm

# 41





F x2



G x1

Install handle G to Part #23 with screws F x2 as shown.


# 42



When installing the slide rail, it should be inserted at the same time, and then pushed together. If you have trouble pushing the drawer forward, pull back and push again

This screw can be loosened to adjust the top and bottom gaps of the drawer


Lock screw **F** after adjusting the upper and lower gaps



F x2

Insert the inner rail E2 x2 into the outer rail E1 x2 as shown. After adjusting the upper and lower gaps, lock screws F x2 onto the inner rail E2 x2 as shown.


# 43



Install N x38 to the assembled unit as shown.






# 44



(Optional)

Install spacer S x6 to the assembled unit as shown if needed.





We provide round stickers P x36. You can stick it to cover the exposed nuts or holes so as to look nicer.

