





STOP!

Before beginning the assembly process, ensure all boxes and parts have been delivered.


ATTENTION: BEFORE START ASSEMBLING TAKE A PICTURE OF THE LABELS ON THE PACKAGES, THIS WILL BE REQUIRED IN CASE THE PRODUCT HAS ANY ASSISTANCE DEMAND.


FOR BEST RESULTS:

- Do not throw away packaging materials until assembly is complete.
- Assemble item on a soft surface, such as cardboard or carpet, to protect finish.
- Proper assembly requires two people.





TOOLS REQUIRED









Prepare the room before starting the assembly, leaving it completely clean and the area in good condition to start the work.
Use the cardboard of the packaging to separate and support the parts removed from the boxes.



Recommended tools (not included)











Parts




N°	Description	Qty.
01	Base	01
02	Left side panel	01
03	Right side panel	01
04	Top panel	01
05	Back panel	01
06	Front of the drawer	03
07	Left side panel of the drawer	03
08	Right side panel of the drawer	03
09	Rear panel of the drawer	03
10	Base of the drawer	03
11	Decorative apply	03
12	Feet	04
13	Left slides	03
14	Right slides	03


Hardware



HOW TO IDENTIFY THE SLIDES?




*plastic wheel always pointed to the ground.



*plastic wheel always pointed to the ground.

WICH HOLES USE TO ATTACH THE SCREWS?






Attention, all the assemblage must be done on the cardboard box or the Styrofoam boards to avoid damage to the parts.

Step 01




F = 18x



ATTENTION!



It is mandatory to apply an additional screw (F) at the position informed, please observe there is no pre hole in the 02 and 03 parts.

Step 02




C = 08x

Insert the hardware (C) into the parts 02 and 03.



Step 03




B = 02x

Connect the part 02 onto the part 01 with the hardware (B).




G = 02x

Apply the hardware (G) onto the hardware (B).



Step 04




B = 02x

Connect the part 03 onto the part 01 with the hardware (B).




G = 02x

Apply the hardware (G) onto the hardware (B).



Step 05




B = 04x

Connect the part 05 onto the parts 02 and 03 with the hardware (B).




G = 04x

Apply the hardware (G) onto the hardware (B).





Step 06



D = 04x

Apply the hardware (D) into the part 04.





E = 04x


Connect the part 04 onto the parts 02 and 03 with the hardware E.



G = 04x






Apply the hardware (G) onto the hardware (E).




Step 07


Pay attention to the correct position of the feet.
The arrows refers to the correct hole to align the feet.


$$A = 16x$$

Use some pieces of Styrofoam boards (package part) to avoid contact of the feet (part 12) with the floor. Connect the parts 12 onto the part 01 with the hardware (A).



Step 08

Assembling the drawers

Step 09



D = 12x


Apply the hardware (D) into the part 06.



F = 09x

Before applying the part 11, observe if your product has the option of matching colors with the front of the drawer (part 06).

Connect the part 11 onto the part 06 with the hardware (F).



Step 10





E = 12x

Connect the parts 07, 08 onto the part 06 with the hardware E.





G = 12x




Apply the hardware (G) onto the hardware (E).

Step 11

Apply the part 10 in the groove of the parts 07, 08 until the groove of the part 06.



Step 12




B = 12x




G = 12x

Connect the part 09 onto the parts 07, 08 with the hardware (B).

Apply the hardware (G) onto the hardware (B).






Step 13

I = 06x



F = 06x

Apply the hardware (I + F) into the groove of the part 06 as shown on detail.



**Step 14**

I = 06x





F = 06x

Apply the hardware (I + F) into the groove of the part 09 as shown on detail.




Step 15

You must apply the screws
on the holes
indicated by the arrows.



*plastic wheel always pointed
to the rear panel of the drawer
part 09.






Attention!

Assemble item on a soft surface,
such as cardboard or carpet,
to protect finish.

Step 16

Attention! Tipover system.

First, approach the furniture as close as possible to the wall.




Then, pass the hardware (K) through the hole of the part (05) from inside to the outside as shown in the figure above until it reaches the wall.


Step 17

Attention! Tipover system.


You will need a pencil to mark where you should drill the wall with a 3/8" drill bit to put in the hardware (J).




Use the 3/8" drill bit to drill the wall.





Press the wings of the hardware (J) and put it in to the hole that you drilled on the wall.




Step 18

Attention! Tipover system.

Connect the hardware (K) on the wall, using the hardware (H).




Connect the hardware (K), under the part 04 with the hardware (F).



Step 19

Install the drawers fitting them into the slides fixed on the parts 02,03.



WARRANTY POLICY

All furniture products are warranted, to the original purchaser at the time of purchase and for a period of 30 days thereafter.

Our warranty is limited to new products purchased in factory sealed cartons.

In order to provide you with timely assistance, please thoroughly inspect your furniture for missing or defective parts immediately after opening the carton.

Manhattan Comfort offers a 30-day parts replacement warranty on all items.

Our furniture products are no intended for outdoor use.

THE WARRANTY DOES NOT COVER:

- Defects/damages by improper assembly or disassembly.
- Defects/damages caused by shipping. Claims for damage during transit should be placed immediately to the transportation company.
- Defects/damages caused by inappropriate use of the furniture.