


ASSEMBLY INSTRUCTIONS



Let's get started!



Read through all of the instructions before starting



Care instructions are listed in the last step of this manual



Approx. 60 minutes assembly time



Make sure you have all parts and components before discarding any packing materials



2 people recommended for assembly

Only use hand tools to assemble this item. Do not use power tools. Do not tighten bolts or screws completely until all hardware is lined up and inserted into the holes.


Do not over-tighten screws and bolts to avoid stripping the hardware or cracking the item.

Assemble your item on a flat, carpeted area, with plenty of space to work. This will prevent damage and scratches to your floors or the item while you're assembling the product.

Keep all components and packing out of reach of children or animals to avoid risk of choking or suffocation.

Furniture components:

- ① Top Panel x1
- ② Bottom Panel x1
- ③ Center Panel x2
- ④ Side Panel (L) x1
- ⑤ Side Panel (R) x1
- ⑥ Back Panel x1
- ⑦ Door Panel x2
- ⑧ Drawer Face Panel x1
- ⑨ Drawer Side Panel x2
- ⑩ Drawer Back Panel x1
- ⑪ Drawer Mdf Board x1



Provided hardware:




- Ⓐ Minifix
M5x24MM x12



- Ⓑ Minifix
Casing x12



- Ⓒ Wood Dowel
M8x30MM x16




- Ⓓ Pvc Handle x5
Screw M4x28MM x10



- Ⓔ Screw
M4x38MM x8



- Ⓕ Allen Key x1



- Ⓖ Ball Bearing
with Holder 12" x1
Screw M3.5x16MM x10



- Ⓗ Furniture Leg-H150 x4
Screw M4x16MM x16



- Ⓘ Candle Wax x1

What you need:



Screwdriver


Step 1

HARDWARE :

- ① Candle Wax x1

COMPONENTS :

- ① Top Panel x1
- ② Bottom Panel x1



Applying Hardware 1 (Candle Wax) to the Door Groove:

Use Hardware 1: Rub the Hardware 1 (Candle Wax) along the groove of the door. This application will facilitate smoother sliding of the door.

Step 2

HARDWARE :

- (C) Wood Dowel M8x30MM x4
- (G) Ball Bearing with Holder x1
- Screw M3.5x16MM x6

COMPONENTS :

- (4) Side Panel (L) x1
- (5) Side Panel (R) x1

Step 1: Separate the Slide:

Release the Lock: Inside the slide, locate a lock.

Move part A down, and part B up.

Push the lock device down to release the lock.

Separate the two parts.


Identify the Parts: This will result in two separate components, now referred to as Part A (left) and Part B (right).

Step 2: Attaching Part A of the Ball Bearing to the Panel

•**Insert Part A:** Place Part A of the ball bearing into the panel.






•**Align the Holes:** Ensure that Hole No. 2 from the front of Part A aligns with the pre-drilled hole on the panel.

•**Secure with Screw:** Use the screwdriver to fix an M3.5x16mm screw into the aligned holes.



Installation Wood Dowel:

As Shown, Please using the hammer to insert the wood dowel(C) into hole of panel.




Step 3

HARDWARE :

- (C) Wood Dowel M8x30MM x12


COMPONENTS :

- (3) Center Panel x2
- (6) Back Panel x1



Installation Wood Dowel:

As Shown, Please using the hammer to insert the wood dowel(C) into hole of panel.




Step 4

HARDWARE :

- Ⓜ Furniture Leg x4
M4x16MM x16




COMPONENTS :

- ② Bottom Panel x1



Installation Furniture Leg :

As Shown, insert all the the hardware on the furniture leg panel (H) with using a screwdriver.




Step 5

HARDWARE :


- Ⓜ Minifix M5x24MM x12

COMPONENTS :

- ① Top Panel x1
- ② Bottom Panel x1



Installation Minifix Screw:
Please insert the screw (A)
on panel using a screwdriver.




Step 6

HARDWARE :

- Ⓓ Pvc Handle x4
- Screw M4x28MM x8

COMPONENTS :

- ⑦ Door Panel x2




Installation Handle :

As Shown, insert all the the hardware handle (D) on the door panel using a screwdriver.

Step 7

COMPONENTS :

- ④ Side Panel (L) x1
- ⑤ Side Panel (R) x1
- ⑥ Back Panel x1




Step 8

HARDWARE :

- (B) Minifix Casing x4
- (F) Allen Key x1


COMPONENTS :

- (2) Bottom Panel x1



Installation:

As shown, the head of minifix housing goes into the open mouth of the mini fix bolt. Use Allen Key then turn the minifix housing so it tightens over the mini fix bolt.




Step 9

HARDWARE :

- (B) Minifix Casing x2
- (F) Allen Key x1


COMPONENTS :

- (3) Center Panel x2



Installation:


As shown, the head of minifix housing goes into the open mouth of the mini fix bolt. Use Allen Key then turn the minifix housing so it tightens over the mini fix bolt.



Step 10

COMPONENTS :

⑦ Door Panel x2



Door Inside groove:
As Shown, Put insert the door
inside the groove

Step 11


HARDWARE :

ⓑ Minifix Casing x6

ⓕ Allen Key x1

COMPONENTS :

① Top Panel x1



Installation:

As shown, the head of minifix housing
goes into the open mouth of the mini fix bolt.
Use Allen Key then turn the minifix housing
so it tightens over the mini fix bolt.


Step 12

HARDWARE :

- (D) Pvc Handle x1
- M4x28MM x2
- (E) Screw M4x38MM x8
- (G) Ball Bearing with Holder x2
- M3.5x16MM x4

COMPONENTS :

- (8) Drawer Face Panel x1
- (9) Drawer Side Panel x2
- (10) Drawer Back Panel x1
- (11) Drawer Mdf Board x1









Installing Ball Bearing Slide Part B on the Drawer:

Prepare Drawer Bottom: Place the drawer with its bottom side facing up.

Position Ball Bearing Slide: Set the ball bearing slide Part B on the drawer.


Align with Drawer Face: Ensure Part B is aligned with the drawer face.

Secure with Screws: Use an M3.5 x 16mm screw and a screwdriver to fasten the slide securely to the drawer.



Installation Handle :


Please insert the screw (E) on panel using a screwdriver.



Installation Handle :

As Shown, insert all the the hardware handle (D) on the drawer panel using a screwdriver.

Step 13



Great job!

Model Description assembly is complete.



CARING FOR YOUR ITEM

Indoor use only.

Not contract grade.

Clean using a non-abrasive cloth and a mild cleaner.

Never use harsh chemicals, as they could damage the finish or integrity of the item.

Top Insert : About 40KG

