




1×10pcs




2×10pcs




3×5pcs




4×8pcs




A×8pcs




B×4pcs



C×2pcs






D×2pcs



# 1

Note that the hoist hole in part #4 has the large opening facing up and the small opening facing down.

Using a small hammer, tap the flat side of part #1 (flat side up) so that the circular slot in part #1 is completely inside the hoist hole in part #4 (as shown)




Note that this is a flat area



Note that this is a flat area

Install the other lower side frame in the same way, taking care to keep the installation height consistent



Note that this is a flat area






Note that this is a flat area

This product supports custom spacing between partitions on each layer. It is recommended to install Attachment 1 at the lowest and middle ends of Attachment 4 during the installation process

# 2

Using a small hammer, tap the flat surface of part #1 (with the flat surface facing up) so that the circular slot in part #1 is completely inside the hoist hole in part #4 (as shown), and note that the hoist hole in part #4 has the large opening facing up and the small opening facing down.




Note that this is a flat area



Note that this is a flat area



Install the other lower side frame in the same way, taking care to keep the installation height consistent




Note that this is a flat area




Note that this is a flat area

This product supports custom spacing between partitions on each layer. Suggest installing Attachment 1 at the top and middle of Attachment 4 during the installation process

# 3




# 4



5


When installing, please use a hammer to hit the flat surface of the connector.



**B×4**




6

Snap the upper frame into the connector.




7


Snap part #1 into the hoist holes on the lower part of part #4 and the upper part of part #4 respectively. And tap them flat with a small hammer




8






Snap part #2 into the hoist holes on the lower part of part #4 and the upper part of part #4 respectively. And tap them flat with a small hammer



Install the remaining part #2 (connect in the same manner)




9







C×2

10




This step is to connect the cabinet to the wall,  
if you do not need to ignore it



D×2



11



12

