




# Product Installation Instructions







Ax6




Bx6




B1x6




Cx6




Dx6




Ex1




Fx1




Gx1




Hx1




Ix2




Jx1




Kx2




Lx1




Mx2




Nx2















Ox1




Px6








1


①		Two In One Screw (6x28mm)	92pcs +4pcs
②		Two In One Nut (10x12mm)	92pcs +4pcs
③		Wood Chipping (6x30mm)	12pcs +2pcs
④		Handle & Screw (4x16mm)	12pcs +1pcs 6pcs
⑤		Screw (3x10mm)	30pcs +1pcs
⑥		Non-slip pads	8pcs +2pcs
⑦		Fixing Clip & Screw (3x16mm)	16pcs +1pcs
⑧		Wire Clamp	2pcs +1pcs
		Remote Control	1pcs
		AC/DC Adapter (12V==3.0A)	1pcs
<div>  1pcs </div> <div>  Double-head screwdriver, use as required </div> <div> 2 </div>			

# Product structure decomposition






1		48pcs	4	 6pcs	 12pcs
2		48pcs	5		30pcs




Use parts ① and ②




Step1



Step2



Step3




Use a screwdriver to lock in the direction of the "+" sign

Disassemble along the direction of the "-" sign

Step 1


①

x4





5

## Step 2





## Step 3




6

## Step 4





## Step 5





Don't beat the acrylic board too tightly, it will crack

7

## Step 6




## Step 7











8

Step 8





Repeat the drawer installation steps


1		44pcs	6		8pcs
2		44pcs	7		16pcs
3		12pcs	8		2pcs
		1pcs			



## Step 9




## Step 10






## Step 11





## Step 12

Pay attention to the slot position




## Step 13

①  x4





## Step 14

②  x4




13



## Step 15





## Step 16



## Step 17



## Step 18




## Step 19

2




x10




## Step 20

1



x10




16

## Step 21

2




x10




## Step 22

6




x8

Tear off release paper and stick the black foot pad on the board





Step 23







## Step 24





## Step 25




20

## Step 26

②  x6




## Step 27




As shown, When installing the drawer, pull the guide rail out first, Slide beads are also pulled out.

## Step 28




Step 29



Repeat the drawer installation steps

## Step 30




If a large gap is found after installing the drawer the slide rail can be moved up and down to adjust the gap

## Step 31


7



x16






## Step 32







Step 33



Step 34





## User's Guide

1. To use this product, please plug it into a 12V DC power supply.
2. If there is no touch response suddenly, Re-plug the power to reset the touch static electricity.
3. If bubbles appear on the panel, remove the protective film.

## Product Introduction

Smart RGB large box is powered by USB-A and Type-C, meeting the general charging needs of all phone models. Equipped with a built-in human body sensor, it can detect objects approaching within a range of 2 meters and achieve intelligent sensing to turn on lights. And with 24 colors light, fast and wireless charging function is 15W.

This touch button enables the switch of radar sensing function  
**A.** touch this button once to turn on the radar sensing function (indicator light on). After the person leaves or remains stationary for more than 30 seconds, the light strip goes out; people and objects within a range of 2 meters move will light up the light strip.  
**B.** Long press this button for 0.5 seconds to turn off the human body sensing function (the indicator light goes out).  
 At this point, Keep the light strip as it was before turning off and no longer be affected by human and object activities.  
 By default, radar sensing is enabled when powered on.

This area is for wireless charging function, supports fast charging with a maximum power of 15W. When charging, the product should be placed the center of the identification to maximize the charging efficiency. After powering on, the wireless charging function is enabled by default.

USB-A Output Port


Type-C Output Port



This touch button achieves functions such as light strip on /off, light color switching, and adjust the brightness of the light.

- A. Touch this button can turn on or off the light (the indicator light will turn on or goes out).
- B. With the circle of light, long press this button to achieve to adjust brightness of the light's function. White light is enabled by default when powered on.

This area is the color switch function, you can click or slide to any color circle position to achieve color switch. The center hexagon of the color circle is marked as the dynamic phantom color mode which have 5 magic color modes.



Pull out the plastic card before using it

## LED Lights Controller-use instructions

1. After inserting the DC power adapter you can use the remote control to control the lights. Press The "on /off" key to turn on the light and it will enter the static light mode.
2. There are 7 RGB Dynamic Modes. You can press the "MODE+/-" key to choose dynamic colors that you preferred and press the "Speed+/-" key to adjust color change speed.
3. There are 7 static colors: White/Red/Green/Blue/yellow/ice blue/ pink light. You can press the "Brightness +/-" key to adjust the brightness.
4. You can press the "lock" key to fix the color you like. When you press the "Switch Dynamic /Static Mode" the light will change between dynamic mode and static mode.