




























K	L
	
18PCS	4PCS

A	B	C	D	E	F	G	H	I	J
									
50PCS	50PCS	17PCS	16PCS	22PCS	4PCS	8PCS	2PCS	2PCS	2PCS


<div>1</div> <div></div> <div>1350*300 1PS</div>	<div>2</div> <div></div> <div>1350*300 1PS</div>	<div>3</div> <div></div> <div>1050*285 1PS</div>	<div>4</div> <div></div> <div>1050*285 1PS</div>	<div>5</div> <div></div> <div>1290*285 1PS</div>
<div>6</div> <div></div> <div>1290*285 1PS</div>	<div>7</div> <div></div> <div>340*265 4PS</div>	<div>8</div> <div></div> <div>340*285 3PS</div>	<div>9</div> <div></div> <div>285*60 1PS</div>	<div>10</div> <div></div> <div>285*60 1PS</div>
<div>11</div> <div></div> <div>1290*60 1PS</div>	<div>12</div> <div></div> <div>1350*60 2PS</div>	<div>13</div> <div></div> <div>268*60 2PS</div>	<div>14</div> <div></div> <div>1320*50 2PS</div>	<div>15</div> <div></div> <div>646*398 6PS</div>




Hardware installation demonstration

NOTE: Please make sure "A" hardware tightened and can't be pulled out!


I




II



III



1



A*26




C*2

put A on board ① ② ⑤

put C on board ⑤

2



A*10




C*4





put A on board ③④⑥

put C on board ③④⑥

3




put A on board ⑨ ⑩ ⑪ ⑬
put C on board ⑦ ⑧ ⑪

	A*14
	C*11
	D*16
	G*8


4

Make sure the arrow on the screw align to the hole on the side.

put B on board 9 10 11



B*2




E*8

5



Make sure the arrow on the screw align to the hole on the side.

put B on board ⑪ ⑬




B*14

⑥



E*12

7




put B on board ⑦ ⑧



B*6

8




B*8

put B on board ⑤ ⑥

9


Make sure the arrow on the screw align to the hole on the side.

put B on board ⑧





B*2


10



11




E*2




F*4

12




put B on board ③ ④ ⑦ ⑧



B*10

13









put B on board ⑤ ⑥



B*8


14



L*4



H*2




I*2




J*2

15



K*18



END