

L-SHAPED DESK WITH HUTCH

ASSEMBLY INSTRUCTION





CAUTION

Put the screws in loosely until all pieces are together and then tighten them all. It will save your time if you make a mistake while installing.



There are two packages for this rack, you may not receive them at the same time, please wait a few days if you only get one package. Dear Customers,

Thank you for purchasing our products.


As a reliable seller, we have been pursuing to provide customers with 100% satisfied products and services, so we hope that you will enjoy this shopping experience.

If you find any damage, missing parts, or dissatisfaction after receiving the product, please contact us freely at the first time. We will provide you with a 100% satisfactory solution.

Thanks again for your order. Please feel free to contact us from Amazon or **homeycs@hotmail.com** in case of any problem regarding assembling or the product itself. We will do everything we can to resolve it.



Please follow the instruction manuals and use a pad to protect the product during your assembly.



Using Camlocks Connect the male camlock as Push the male camlock DO NOT OVER TIGHTEN directed in the assembly into the entry hole. instructions using a screwdriver. 0 Insert the female camlock as Turn the female camlock shown in the instruction. clockwise with a screwdriver. Note: ensure that the arrow on the top of the camlock points You should feel a click toward the entry hole for the when the camlock is male camlock. locked in place. The joint is now secure. (F)


HOW TO ADJUST THE EUROPEAN ADJUSTABLE HINGES ON DOOR


If the doors require adjustment, follow the below options as needed:


To adjust door up or down, loosen screws (a), adjust door and retighten screws.


To adjust door left and right, turn screw (b) in or out.

To adjust door in and out, loosen screw (c), adjust door and retighten screw.














STEP 1 3 **□ ••••••••** ×4 W STEP 2 x4 W



























































TIPPING RESTRAINT HARDWARE



Note: We have included two Tipping Restraint Hardware set for this Unit. When properly installed, this restraint can provide protection against the unexpected tipping of the Unit due to small tremors, bumps or climbing. We strongly recommend mounting this hardware to a wall stud and your Unit.

Note: You must install the Tipping Restraint Hardware with the unit in use to prevent any accidents or damage to the unit.

