


















## DAYBED ASSEMBLY INSTRUCTION


### HARDWARE LIST:

<b>A</b>  Allen Key (M4) = 1pc	<b>B</b>  Bolt (M6 x 80mm) = 12pcs	<b>C</b>  Bolt (M6 x 30mm) = 8pcs	<b>D</b>  Wood Screw (16mm) = 12pcs	<b>E</b>  Wood Screw (30mm) = 48pcs
<b>F</b>  Nut = 12pcs	<b>G</b>  Dowel (M12 x 50mm) = 6pcs	<b>H</b>  Castor = 6pcs	<b>I</b>  Screw Driver (+/-) Not Available	


### ITEM PARTS LIST:

<b>1</b>  Side Wall Panel ( Right ) = 1pc	<b>2</b>  Side Wall Panel ( Left ) = 1pc	<b>3</b>  Upper Bed Rails = 2pcs	<b>4</b>  Upper Horizontal Rail = 1pc
<b>5</b>  Lower Front Panel = 1pc	<b>6</b>  Lower Back Rail = 1pc	<b>7</b>  Lower Side Attached Rails = 2pcs	<b>8</b>  Upper & Lower Bed Slats = 24pcs


### STEP #1: ASSEMBLY UPPER BED




Before assembling the two upper bed & horizontal rails, insert a (M12 x 40mm) dowel into the center hole of each joint.



Attach the bed slats to the slots using 1 (30mm) screw on each end.






Connect the upper bed & horizontal rails (3 & 4) with side wall left & right together. Then using 2 (M6 x 80 mm) bolts and tighten on each rails end. Nut (F) may need to be adjusted with a screw driver.





**UPPER BED**

## STEP #2: ASSEMBLY LOWER BED

Before assembling the lower bed, Tighten each 3pcs castor with 2 (16mm) screw on the lower front panel & back rail underneath marking holes.



Attach the bed slats to the slots using 1 (30mm) screw on each end.





Connect the lower side attached rails with lower front panel & back rail together. Then tighten 2 (M6 x 30mm) bolts on each end.

**LOWER BED**

**STEP #3: CONNECTING THE UPPER & LOWER BED**

Slide the lower bed underneath the upper bed.



**COMPLETED**