

Pent Sheds – Standard – Side - Reverse

Instructions



Thank you for purchasing your shed from us and supporting UK Manufacturing.

The type and quantity of components may vary for different style sheds. Assembly of all shed styles - are by the same method - as detailed.

Before assembling the shed, please check that all parts are present. Report any shortages or other issues immediately.


Treatment – Your shed is pressure treated to protect your shed from mould and rot. We recommend you treat your shed once a year with a water base treatment to protect your shed from the British Weather and to make it watertight.

Base – We recommend a firm level base for your shed. Please contact us if you require advice or need to purchase a timber base from us.

DO NOT attempt to modify the shed or any of its parts as this may invalidate the warranty.

Packing List


No.	Components	Number
1	Front panel	1 or 2
2	Rear panel	1 or 2
3	Left side panel	1 or 2
4	Right side panel	1 or 2
5	Felt	Pre-cut
6	Floor (may be 1 or 2 panels)	1 or 2
7	Roof panel (may be 1 or 2 panels)	1 or 2
8	Doors	1 or 2
9	Windows (optional)	Optional
10	Window bead 15mm x 20mm (optional)	Optional
11	Floor bearers tanalised 26mm x 38mm	Variable
12	Barge boards	4
13	Tee Hinges	3 (single door) 6 (double door)
14	Turn button	1 (single door) 2 (double door)
15	Corner cover strips 11mm x 41mm	Variable




No.	Fixings	
1	60mm screws	Variable
2	25mm black screws	Variable
3	32mm nails	Variable
4	13mm Roof felt nails.	Variable
5	100mm Screws - specifically for double door framing – left or right only – to secure side panel to front panels through triple framing.	Variable

1. FLOOR SECTION

We have supplied the floor with the bearers attached to the floor. To join the additional pieces (if more than one part) of flooring you will need to screw the sections together using 40mm Screws.



2. WALL PANELS




Step 1 – SIDE PANELS

Position the first **side panel** so that the edge of the panel is flush with the edge of the floor and the overhang on the bottom of the panel is butted up to the floor.

Step 2 – FRONT AND REAR

Place the **front or rear panel** along the edge of the floor and line up the framework of both of the panels to make a corner. **NB: IF YOU HAVE DOUBLE DOOR ON THE FRONT OF THE SHED POSITIONED LEFT OR RIGHT YOU WILL NEED TO USE 100MM SCREWS (SUPPLIED)**


Step 3 – SECURING THE FRONT




Secure the rear and side panels together as shown below, using 60mm screws. Note that the framework of the panels rests on the floor with the cladding over hanging. Continue until all sides including the front panel are in place and fixed together.

! – PLEASE ENSURE ALL PANELS ARE BUTTED FLUSH AGAINST FLOOR

Step 4 – Securing wall panels to floor




Once all of the side panels are in place, make sure that they are sitting squarely on the floor and fix each side panel to the floor as shown. Use 60mm screws and ensure that the screws go through the floor into the bearers.



All the sides of the shed should be assembled and fixed to the floor.

! – ENSURE ALL PANELS ARE BUTTED FLUSH AGAINST FLOOR

Step 5 – Adding corner strips




Position the corner cover strips as shown above and fix with 30mm nails. Additional strips will be supplied if the side/front and back panels are split into more than one panel.

3. ROOF

The roof board(s) have been supplied with the batons attached.


Step.1 – Attaching Roof Boards



Lay the roof on the shed as shown. Using the 40mm screws, fix the roof into position by screwing through the roof panel into the internal framework of the shed.

Please note – when supplied with more than one roof panel – please make sure the roof is laid with framing on the panel - meeting in the middle – so they can be screwed together – leaving no framing on the pent side of the shed. Please call if having any difficulties with this.

Step.2 – Felting the Roof – IF MORE THAN ONE PIECE OF FELT SEE STEP 2a




Coat the roof with adhesive. Lay the roof felt with an overhang all round (dark side up). Fold down the felt at the front and secure using the 13mm clout nails. Tension the felt over the roof and secure to the rear of the roof. Space the clout nail approximately 15cm apart. Follow for all side of the felt and trim off any excess

2a- If the shed has two or more lengths of felt, position the first piece along the lower edge of the roof and fix as shown. Then overlap the second piece and fix as shown, ensuring that the felt overhangs allowing rain water to run off the roof

Step.3 – Attaching Roof Facia Boards - THE BARGE BOARDS WILL BE SUPPLIED A FEW INCHES LARGER THAN REQUIRED AND WILL NEED TRIMMING WITH A SAW. THIS IS BECAUSE THE WAY THE FELT IS FITTED CAN AFFECT THE BARGE BOARD SIZE SLIGHTLY.

! – YOU WILL NEED TO LEAVE 1/2CM GAP BETWEEN THE DOOR AND OUTSIDE FRAME TO ALLOW THE DOOR TO OPEN AND CLOSE




Attach a short barge board to each side of the roof with the 30mm nails, ensuring that the board is flush with the top and front line of the roof.

Attach the front and rear barge boards making sure board is flush with the topline.


! – YOU MAY NEED TO TRIM THE FACIA BOARDS

4. DOORS

Lie the door on a flat surface with the **cladding facing upwards**. Take one T hinge and position on the door as shown below, making sure that the T hinge is directly above the brace on the underside of the door. Fix the T hinge into place with the 25mm black screws. Repeat for the next T hinge. With the T hinges secured, position the door squarely in the door frame. Fix the top hinge first and the bottom hinge second with the 25mm black screws. Make sure that the door can open and close freely.




5. HASP & STAPLE



Position the two parts of the hasp & staple across the join in the doors. Make sure that that they are both level and will fit together when fixed into place.

Use the screws provided to fix each part of the hasp & staple to the doors.

6. Windows - (Optional)



To fit the windows it is recommended that a waterproof sealant is applied around the edge of the glazing before fitting. From the inside of the building fit the styrene window into the frame and secure in place with the 4 strips of window bead. Fix the window bead to the window frame with 32mm Nail.

Important Information

Adequate provision must be made to ensure that the building does not come into direct contact with the ground and air is able circulate underneath. A concrete or paving slab base is acceptable, but the building must not be allowed to sit in pooled water during wet conditions. **Timber Information.** Timber is a natural product and can therefore be subject to warping, shrinkage, splitting etc...Periods of excessive dry spells can cause the timber to lose internal moisture resulting in shrinkage on a panel. During periods of excessive wet spells, the timber may experience some swelling. Unfortunately this process cannot be avoided. If you have problems with certain boards shrinking, try to decrease the amount of direct sunlight it gets. During hot spells spray any shrunken boards with a hose pipe, this will replenish the moisture in the timber. **Our sheds are pressure treated to prevent rotting however if you wish for your building to be watertight please treat with a wood preservative.** If you have any questions or queries during the assembly of your building please contact us:-

We are constantly improving and updating the quality of our products and as such some components may differ from those shown. We reserve the right to change the specification of our products without prior notice.