




Thank you for purchasing your shed. No matter what size garden, a shed is the most practical of garden structures. Simply follow these step by step instructions and our top tips and you'll be enjoying your shed for many years to come. If you have any questions or need advice, our friendly team is here to help.


SHED INSTRUCTIONS

PENT SHEDS (6x4, 7x5, 8x6, 10x6)


FIXING PACK CONTAINS:



Flush Hinges
QTY: 2



Hasp & Staple
QTY: 1



Z-Brackets (45mm)
QTY: 4


BEFORE YOU START

Please read through these instructions to familiarise yourself with your shed. We recommend that you **check all the components** using the lists found on the front and back pages before you start to build.

All of our sheds are constructed in the same way. They simply come with different components depending on the type of shed you have. Don't worry if your fixing pack contains some spare items at the end of the build (you haven't missed a bit!) we have sent you a generic fixing pack to suit the shed range.

BASE PREPARATION

It's vital that you build your new shed on a **solid, level base**. Timber or Plastic Shed Bases are ideal, as is solid concrete or concrete slabs.



If you have an existing base and think it's suitable for your new shed to be sited on, it is important you check that it is level and doesn't deviate by any more than 15mm from edge to edge. If this isn't the case the building will twist, causing gaps to appear in the sections and the roof, doors and windows to misalign.

TOOLS NEEDED

We recommend using the following tools (not supplied):



Assembly is relatively straightforward if you follow these step by step instructions. We recommend getting everything aligned properly before screwing together and that **screw holes should be pre-drilled** to avoid splitting the timber.



IMPORTANT
Assembly requires 2+ adults.



REMINDER
Always pre-drill before screwing.

PLEASE KEEP PLASTIC BAGS AND SMALL PARTS AWAY FROM CHILDREN

To help you get the most out of our products it's useful to know a little more about the properties of timber, what's normal and how your shed may behave as the seasons change. Wood is an extremely durable material for construction but as a natural product when used outdoors it is susceptible to changes in the environment.

THINGS THAT YOU MIGHT SEE IN YOUR PRODUCT



MOVEMENT, TWISTING & WARPING

Wood contains a natural level of moisture so decreasing humidity levels in the surrounding air may cause panels to change their shape as the porous fibres shrink. This can be exaggerated during prolonged periods of dry weather. Movement and gaps in timber products are normal, in most cases the wood will revert to its original form once the high temperatures subside and there is more moisture content in the air. Similarly, in the winter months, the opposite may occur with wood swelling.



EXPANSION, CONTRACTION, SPLITS & CRACKS

All timber will expand and contract according to its environment. As a result of this expansion and contraction, it is very common to see splits and cracks developing in the wood. Splits are common during the spring and summer months as the wood begins to dry out. The outer surface dries first and contracts, contracting over a still expanded core of the wood. The result of this is that splits and cracks appear along the grain of wood. These splits are not a fault and do not affect the structural integrity of a product.



MOULD & BLUE STAIN

Mould is a surface-dwelling fungus that feeds on the nutrients and debris contained in the surface cells of timber. The most common problems associated with mould are discoloured timber and an increase in permeability of the timber. Blue stain is part of the same family but penetrates deeper into the surface layers of the timber. It stains the timber a dark blue, whereas mould is usually black. These do not cause the timber to rot. Keep the building well ventilated to avoid mould.

ADVICE ON FELT HANDLING & USAGE

Roofing felt is flexible at temperatures above 5°C. In cold temperatures extra care must be taken when handling and installing to prevent cracking and damage to the felt. The felt should not be rolled, folded or used in temperatures lower than 5° C. In cold temperatures the felt should be stored above 10°C (indoors) for 24 hours prior to use. Felt must be lifted, not dragged and should be stored on its end on a dry surface.

THE ROOF OF THIS BUILDING IS NOT A LOAD BEARING STRUCTURE

8 TOP TIPS TO ENSURE YOUR SHED IS FULLY WATERPROOF

- 1 MAKE SURE YOU POSITION YOUR SHED IN THE BEST LOCATION IN YOUR GARDEN**
Avoid areas where water pools and is constantly wet. Position away from trees and cut back any overhanging foliage which can cause moisture to be trapped against shed walls and debris to collect on the roof.
- 2 RAISE YOUR SHED OFF THE GROUND**
Ideally any concrete base should be the same footprint as the shed to allow surface water to run off without pooling, a timber shed base can also be used. Raise 50mm above ground level.
- 3 SEAL THE BASE**
We recommend a treatment containing wax or oil, paint the bearers that come into contact with the ground to prevent moisture coming up.
- 4 USE AN END-GRAIN PROTECTOR**
To protect the corners and panel joints, an end grain treatment can be applied.
- 5 SEAL THE PANELS & WINDOWS**
Use a flexible silicone sealant around windows to prevent water ingress. This can also be used where 2 sections of the shed joint together. Apply internally.
- 6 CONSIDER ADDING GUTTERS**
Adding guttering around the fascia of the shed will redirect rain water away from the shed's foundation.
- 7 KEEP VENTILATED**
Good airflow around the perimeter of the shed and regular ventilation inside the shed will help prevent mould and mildew.
- 8 CONSIDER A WEATHERPROOFING STAIN OR CLEAR TREATMENT**
We recommend you paint your garden shed with a weatherproofing treatment at least once a year. This will help maintain the wood, stabilise timber movement and help prolong the life of your shed.



TREATED TIMBER CONTAINING A BIOCIDAL PRODUCT CONTROL OF WOOD DESTROYING ORGANISMS

Active Ingredients - Propiconazole, Tebuconazole, IPBC, Permethrine, Benzalkonium chloride. (Dip Treated Sheds)
Basic Copper Carbonate, DDA Carbonate, DDA Chloride (Pressure Treated Sheds)


Wear gloves when handling. Avoid inhalation of sawdust. Do not use in contact with drinking water or food. Do not use for animal bedding or in fish ponds. Dispose of treated wood responsibly.

IDENTIFY YOUR SHED

From the **section layout** below, identify your shed based on the **width** and **depth** dimensions of your shed – eg 6x4. You'll need this to identify the side panel positions.

Assembly of your chosen shed will slightly differ throughout the steps based on the size of your shed. This will be mentioned throughout the instructions for guidance.

KEY









- **A** - 2ft Panel (590 x 1603mm)
- **B** - 2ft Panel (590 x 1945mm)
- **C** - 3ft Panel (885 x 1603mm)
- **D** - 3ft Panel (885 x 1717mm)
- **E** - 3ft Panel (885 x 1945mm)
(With windows)
- **F** - 4ft Panel (1180 x 1603mm)
- **G** - 4ft Panel (1180 x 1717mm)
- **H** - 4ft Panel (1180 x 1945mm)
(With windows)

PLEASE NOTE

The sheds are made up of multiple sections where same size panels are interchangeable.

The door is flexible for all shed types and can be hinged onto either side.





1 CONSTRUCTION




1a FLOORS & SIDES



Position the floor in your desired location. The 6x4 and 7x5 sheds will only have **one floor**. For the 8x6 and 10x6 sheds, turn the floors upside down to secure the sections together by screwing through the adjoining bearers. 8x6 and 10x6 will have **two floors**.

Layout the panels around your shed base.




We recommend to start in a back corner then work from the back panels to the front panels for assembly.




1b Start at a back corner. See the section layout on page 4 to confirm position. Secure the corner as shown below.


Repeat the process for remaining panels and **secure panels together**. Make sure that the bottom frame of the wall panel rests on the outer edge of the floor.

Secure the panels into place by **screwing into the floor**. Screw into the door frame in the door panel into the floor to keep secure.




1c Attach the Triangular Pent Section by screwing to the wall panel. Also screw from the front panel into the Triangular Pent Section to keep it more secure as shown below. Repeat for the other Triangular Pent Section.






Secure windows by screwing through the window cover strips and window into the panel frame. Screw into the bottom of the window and into the interior sill to keep secure. Make sure the window is centralised for all window frames as shown below.



WINDOW POSITIONING







Attach the cover strips onto the corners. Ensuring they are flush to the bottom edge of the panels as shown below.

Attach the cover strips onto the adjoining panels. Ensuring it is flush to the bottom edge of the panels as shown below.

Secure the door weather strip onto the side you want the hinges, and ensure it's flush to the floor and against the face of the wall panel framing.

Attach the slamming strip onto the opposite side you want the hinges, onto the wall panel shown below.




PLEASE NOTE
Screwing the door weather strip onto the wall panel determines the side of your hinges.

COVER STRIPS(See pages 8-9 for measurement for chosen shed)

DOOR WEATHER STRIP (38 x 12 x 1710)






SLAMMING STRIP(28 x 12 x 1637)



Attach 2 hinges onto the door frame with the measurements provided. Please take note of the hinge position shown below.

Place the door into the opening, ensuring it's level. Make sure the hinges are up against the door weather strip face.

Fix the Hasp and Staple as shown. Ensure the screws go into the framework behind.



Make sure the outer face of the notch on the hinge is in line with the door face.

Allow a 5mm gap at the top when placing door.

TOP TIP: Line up the hasp & staple. Mark the edges with a pencil for guidance.

FRAMEWORK

5 ROOF


5a

PRE-DRILL WITH 2MM BIT FOR ALL STEPS BELOW.

Attach the Z-brackets with screws onto the top face at each end of the beam(s).

For the 6x4 and 7x5 sheds, you will have only one beam. Screw the Z-brackets to the centre of the front and back panels (measurements shown below). Ensure the Z-brackets are facing the right way as shown below.

For the 8x6 and 10x6 sheds, you will have two beams. Use the measurements below to space them across the front and back panels and screw as shown below. Ensure the Z-brackets are facing the right way as shown below.




5b

Place the OSB roof sheets, one at a time onto the shed frame and beams. Ensure where the OSB roof sheets join, are central for each beam.

Before screwing the OSB roof sheets onto the roof, screw the roof support strips to the OSB roof sheets. Ensure they are flush to the edges. Repeat this for both sides. The measurements shown below are to show the orientation of the sheets. The strip(s) will be the same length as the 2 edges when joined together as shown below.

Once the roof support strips are screwed onto the front and back of the OSB roof sheets, push the sheets forward from the back, ensuring the roof support strip is in contact with the shed as shown below. Then screw the OSB roof sheets into the beam(s) and shed frame.




5c

For the 6x4 and 7x5 sheds, screw the shorter roof support strips central onto the sheets. For the 8x6 and 10x6 sheds, screw the shorter roof support strips into the space provided as shown below. Repeat this for both sides and ensure they are flush to the sheet edges.

Measure out equal lengths based on your chosen shed and overlap it on the top, around the edges and fold the corners; tack to keep secure as shown below. Ensure 50mm at the bottom and work from the bottom to the top.

Secure the fascias with screws as shown below. The fascia options differ based on your chosen shed. The parts that are left over are an indication on which steps to follow. Use pages 8-9 for measurement guidance.



DIP TREATED PENT SHEDS

SELECT YOUR CHOSEN SHED & CHECK YOU HAVE ALL YOUR PARTS.

Overlap Pent 6' x 4' - 2 Windows (ODP64M)			
Part Code	Description	No.	No.
ODPMRHA4	4ft Triangular Pent Section - Right Hand	1	
ODPMLHA4	4ft Triangular Pent Section - Left Hand	1	
ODPM85BP	Section D - 3ft Pent Back Panel (885 x 1717mm)	2	
ODM85TWP	Section E - 3ft Pent Front Window Panel (885 x 1945mm)	1	
ODM85TDP	3ft Pent Front Door Panel (885 x 1945mm)	1	
ODM180PP	Section F - 4ft Panel (1180 x 1603mm)	2	
MSDDR	Door	1	
MSBEL46	Floor	1	
2812163PDT	Slamming Strip (28x12x1637mm)	1	
2816050DDT	Window Cover Strip (28x16x550mm)	3	
28281934	Roof Support Strip (28x28x934mm)	2	
38121710PDT	Weather Strip (38x12x1710mm)	2	
44161695DDT	Cover Strip (44x16x1695mm)	3	
44161695DDT	Cover Strip (44x16x1925mm)	1	
45451153PAU79	Roof Beam	1	
5912130PDT	Fascia (59x12x1390mm)	2	
59121979PDT	Fascia (59x12x1978mm)	2	
OSB13759678	OSB Sheet - Roof	1	
FEL144BL	Felt	1	

Overlap Pent 7' x 5' - 2 Windows (ODP75M)			
Part Code	Description	No.	No.
ODPMRHA5	5ft Triangular Pent Section - Right Hand	1	
ODPMLHA5	5ft Triangular Pent Section - Left Hand	1	
ODPM85BP	Section D - 3ft Pent Back Panel (885 x 1717mm)	1	
ODPM180BP	Section G - 4ft Pent Back Panel (1180 x 1717mm)	1	
ODM85TWP	3ft Pent Front Window Panel (885 x 1945mm)	1	
ODM85TDP	3ft Pent Front Door Panel (885 x 1945mm)	1	
ODM85PP	Section C - 3ft Panel (885 x 1603mm)	2	
ODM50PP	Section A - 2ft Panel (590 x 1603mm)	2	
ODM180TWP	Section H - 4ft Pent Front Window Panel (1180 x 1945mm)	1	
MSDDR	Door	1	
MSBEL57	Floor	1	
2812163PDT	Slamming Strip (28x12x1637mm)	1	
2816050DDT	Window Cover Strip (28x16x550mm)	3	
28281934	Roof Support Strip (28x28x934mm)	6	
38121710PDT	Weather Strip (38x12x1710mm)	1	
44161695DDT	Cover Strip (44x16x1695mm)	3	
44161800DT	Cover Strip (44x16x1810mm)	2	
44161925DT	Cover Strip (44x16x1925mm)	1	
45451447PA81	Roof Beam	1	
5912132PDT	Fascia (59x12x132mm)	2	
59121688PDT	Fascia (59x12x1688mm)	2	
RPE1590	Window	2	
OSB16881158	OSB Sheet - Roof	2	
FEL178BL	Felt	1	

Overlap Pent 8' x 6' - 2 Windows (ODP86M)			
Part Code	Description	No.	No.
ODPMRHA6	6ft Triangular Pent Section - Right Hand	1	
ODPMLHA6	6ft Triangular Pent Section - Left Hand	1	
ODPM180BP	Section G - 4ft Pent Back Panel (1180 x 1717mm)	2	
ODM85BP	Section C - 3ft Panel (885 x 1603mm)	4	
ODM180TWP	Section H - 4ft Pent Front Window Panel (1180 x 1945mm)	1	
ODM180TDP	4ft Pent Front Door Panel (885 x 1945mm)	1	
MSDDR	Door	1	
MSBEL46	Floor	2	
2812163PDT	Slamming Strip (28x12x1637mm)	1	
2816050DDT	Window Cover Strip (28x16x550mm)	3	
28281934	Roof Support Strip (28x28x988mm)	4	
38121710PDT	Weather Strip (38x12x1710mm)	1	
44161695DDT	Cover Strip (44x16x1695mm)	3	
44161810DT	Cover Strip (44x16x1810mm)	2	
44161925DT	Cover Strip (44x16x1925mm)	2	
45451732PA83	Roof Beam	4	
5912132PDT	Fascia (59x12x132mm)	2	
59121688PDT	Fascia (59x12x1688mm)	2	
RPE1590	Window	2	
OSB20328288	OSB Sheet - Roof	3	
FEL178BL	Felt	1	

Overlap Pent 10' x 6' - 2 Windows (ODP106M)			
Part Code	Description	No.	No.
ODPMRHA6	6ft Triangular Pent Section - Right Hand	1	
ODPMLHA6	6ft Triangular Pent Section - Left Hand	1	
ODPM85BP	Section D - 3ft Pent Back Panel (885 x 1717mm)	2	
ODPM180BP	Section G - 4ft Pent Back Panel (1180 x 1717mm)	1	
ODM85BP	Section C - 3ft Panel (885 x 1603mm)	4	
ODM50TWP	Section B - 4ft Pent Front Window Panel (890 x 1945mm)	1	
ODM180TWP	Section H - 4ft Pent Front Window Panel (1180 x 1945mm)	1	
ODM180TDP	4ft Pent Front Door Panel (885 x 1945mm)	1	
MSDDR	Door	1	
MSBEL56	Floor	2	
2812163PDT	Slamming Strip (28x12x1637mm)	1	
2816050DDT	Window Cover Strip (28x16x550mm)	3	
28281934	Roof Support Strip (28x28x988mm)	4	
38121710PDT	Weather Strip (38x12x1710mm)	1	
44161695DDT	Cover Strip (44x16x1695mm)	4	
44161810DT	Cover Strip (44x16x1810mm)	2	
44161925DT	Cover Strip (44x16x1925mm)	2	
45451732PA83	Roof Beam	4	
59121020PDT	Fascia (59x12x1020mm)	4	
59121555PDT	Fascia (59x12x1555mm)	2	
RPE1590	Window	2	
OSB102510768	OSB Sheet - Roof	3	
85052	Felt	1	

Shiplap Pent 6' x 4' - 2 Windows (SDP64M)			
Part Code	Description	No.	No.
SDPMRHA4	4ft Triangular Pent Section - Right Hand	1	
SDPMLHA4	4ft Triangular Pent Section - Left Hand	1	
SDPM85BP	Section D - 3ft Pent Back Panel (885 x 1717mm)	2	
SDM85TWP	Section E - 3ft Pent Front Window Panel (885 x 1945mm)	1	
SDM85TDP	3ft Pent Front Door Panel (885 x 1945mm)	1	
SDM180PP	Section F - 4ft Panel (1180 x 1603mm)	2	
MSDDR	Door	1	
MSBEL46	Floor	3	
2812163PDT	Slamming Strip (28x12x1637mm)	1	
28281934	Roof Support Strip (28x28x934mm)	2	
38121710PDT	Weather Strip (38x12x1710mm)	2	
40121655PDT	Cover Strip (40x12x1655mm)	3	
40121925PDT	Cover Strip (40x12x1925mm)	1	
45451153PAU79	Roof Beam	1	
5912130PDT	Fascia (59x12x1390mm)	2	
59121979PDT	Fascia (59x12x1978mm)	1	
RPE1590	Window	2	
OSB13759678	OSB Sheet - Roof	2	
85025	Felt	1	

Shiplap Pent 7' x 5' - 2 Windows (SDP75M)			
Part Code	Description	No.	No.
SDPMRHA5	5ft Triangular Pent Section - Right Hand	1	
SDPMLHA5	5ft Triangular Pent Section - Left Hand	1	
SDPM85BP	Section D - 3ft Pent Back Panel (885 x 1717mm)	1	
SDPM180BP	Section G - 3ft Pent Back Panel (1180 x 1717mm)	1	
SDM85TWP	3ft Pent Front Door Panel (885 x 1945mm)	1	
SDM85PP	Section C - 3ft Panel (885 x 1603mm)	2	
SDM50PP	Section A - 2ft Panel (590 x 1603mm)	2	
SDM180TWP	Section H - 4ft Pent Front Window Panel (1180 x 1945mm)	1	
MSDDR	Door	1	
MSBEL57	Floor	1	
2812163PDT	Slamming Strip (28x12x1637mm)	3	
2812163PDT	Slamming Strip (28x12x1637mm)	1	
28281934	Roof Support Strip (28x28x934mm)	6	
38121710PDT	Weather Strip (38x12x1710mm)	1	
40121655PDT	Cover Strip (40x12x1655mm)	3	
40121925PDT	Cover Strip (40x12x1925mm)	3	
45451447PA81	Roof Beam	1	
59121132PDT	Fascia (59x12x1132mm)	2	
59121688PDT	Fascia (59x12x1688mm)	2	
RPE1590	Window	2	
OSB16881158	OSB Sheet - Roof	2	
85014	Felt	1	

(The parts do not have codes on them. They are listed above should you need to order one.)

PRESSURE TREATED PENT SHEDS

SELECT YOUR CHOSEN SHED & CHECK YOU HAVE ALL YOUR PARTS.

Overlap Pent 6' x 4' - 2 Windows (OPP64M)		
Part Code	Description	No.
OPPMRHA4	4ft Triangular Pent Section - Right Hand	1
OPPMLHA4	4ft Triangular Pent Section - Left Hand	1
OPPM85BP	Section D - 3ft Pent Back Panel (885 x 1717mm)	2
OPPM160BP	Section E - 3ft Pent Front Window Panel (885 x 1945mm)	1
OPM85TDP	3ft Pent Front Door Panel (885 x 1945mm)	1
OPM1180PP	Section F - 4ft Panel (1180 x 1603mm)	2
MSPDR	Door	1
MSBFL46	Floor	1
28121637PPT	Slamming Strip (28x12x1637mm)	1
2816050PT	Window Cover Strip (28x16x550mm)	3
28281934	Roof Support Strip (28x28x1934mm)	2
38121710PPT	Weather Strip (38x12x1710mm)	1
44161695PT	Cover Strip (44x16x1695mm)	3
44161925PT	Roof Beam	1
45451441PAI81	Fascia (59x12x1390mm)	2
59121390PPT	Fascia (59x12x1978mm)	1
RPE7885	Window	2
OSB13758878	OSB Sheet - Roof	2
FELT44BL	Felt	1

Overlap Pent 7' x 5' - 2 Windows (OPP75M)		
Part Code	Description	No.
OPPMRHA5	5ft Triangular Pent Section - Right Hand	1
OPPMLHA5	5ft Triangular Pent Section - Left Hand	1
OPPM85BP	Section D - 3ft Pent Back Panel (885 x 1717mm)	1
OPPM160BP	Section G - 3ft Pent Back Panel (1180 x 1717mm)	1
OPM85TDP	3ft Pent Front Door Panel (885 x 1945mm)	1
OPM85SPP	Section C - 3ft Panel (885 x 1603mm)	2
OPM590PP	Section A - 2ft Panel (590 x 1603mm)	2
OPM1180TWP	Section H - 4ft Pent Front Window Panel (1180 x 1945mm)	1
MSPDR	Door	1
MSBFL57	Floor	1
28121637PPT	Slamming Strip (28x12x1637mm)	1
2816050PT	Window Cover Strip (28x16x550mm)	3
28281115	Roof Support Strip (28x28x1115mm)	6
38121710PPT	Weather Strip (38x12x1710mm)	1
44161695PT	Cover Strip (44x16x1695mm)	3
4416190PT	Cover Strip (44x16x1810mm)	2
44161925PT	Cover Strip (44x16x1925mm)	3
45451441PAI81	Roof Beam	1
5912132PPT	Fascia (59x12x132mm)	2
59121688PPT	Fascia (59x12x1688mm)	2
RPE7590	Window	2
OSB16881158	OSB Sheet - Roof	2
FELT78BL	Felt	1

Overlap Pent 8' x 6' - 2 Windows (OPP86M)		
Part Code	Description	No.
OPPMRHA6	6ft Triangular Pent Section - Right Hand	1
OPPMLHA6	6ft Triangular Pent Section - Left Hand	1
OPPM160BP	Section D - 4ft Pent Back Panel (1180 x 1717mm)	2
OPM85SPP	Section C - 3ft Panel (885 x 1603mm)	4
OPM1180TWP	Section H - 4ft Pent Front Window Panel (1180 x 1945mm)	1
OPM1180TDP	4ft Pent Front Door Panel (885 x 1945mm)	1
MSPDR	Door	1
MSBFL46	Floor	2
28121637PPT	Slamming Strip (28x12x1637mm)	1
2816050PT	Window Cover Strip (28x16x550mm)	3
28281934	Roof Support Strip (28x28x1934mm)	4
38121710PPT	Weather Strip (38x12x1710mm)	1
44161695PT	Cover Strip (44x16x1695mm)	3
44161810PT	Cover Strip (44x16x1810mm)	2
44161925PT	Cover Strip (44x16x1925mm)	3
45451783PAI83	Roof Beam	2
59121020PPT	Fascia (59x12x1020mm)	4
59121259PPT	Fascia (59x12x1259mm)	2
RPE7590	Window	2
OSB20328288	OSB Sheet - Roof	3
FELT81BL	Felt	1

Overlap Pent 10' x 6' - 2 Windows (OPP106M)		
Part Code	Description	No.
OPPMRHA6	6ft Triangular Pent Section - Right Hand	1
OPPMLHA6	6ft Triangular Pent Section - Left Hand	1
OPPM85BP	Section D - 3ft Pent Back Panel (885 x 1717mm)	2
OPPM160BP	Section G - 4ft Pent Back Panel (1180 x 1717mm)	1
OPM85SPP	Section C - 3ft Panel (885 x 1603mm)	4
OPM850TTP	Section B - 2ft Pent Front Panel (590 x 1945mm)	1
OPM1180TWP	Section H - 4ft Pent Front Window Panel (1180 x 1945mm)	1
OPM1180TDP	4ft Pent Front Door Panel (885 x 1945mm)	1
MSPDR	Door	1
MSBFL56	Floor	2
28121637PPT	Slamming Strip (28x12x1637mm)	1
2816050PT	Window Cover Strip (28x16x550mm)	3
28281934	Roof Support Strip (28x28x1934mm)	4
38121710PPT	Weather Strip (38x12x1710mm)	1
44161695PT	Cover Strip (44x16x1695mm)	3
44161810PT	Cover Strip (44x16x1810mm)	2
44161925PT	Cover Strip (44x16x1925mm)	3
45451783PAI83	Roof Beam	2
59121020PPT	Fascia (59x12x1020mm)	4
59121555PPT	Fascia (59x12x1555mm)	2
RPE7590	Window	2
OSB203210258	OSB Sheet - Roof	3
88082	Felt	1

(The parts do not have codes on them. They are listed above should you need to order one.)