

Measuring up

Quick guide to measuring up for your new door



To make sure you purchase the right door sizes, take the following measurements.

Door width: measure the top, middle and bottom of the door frame. The widest measurement determines the width of the door.

Door height: measure inside the vertical side of the frame. The longest length determines the height required. Remember to make allowance for any floor covering.

NB. You can plane door edges slightly to reduce the size, but we advise removing no more than 5mm each side.



Door size conversion chart

A little help if you need to work out the metric and imperial equivalent for door sizes.

HEIGHT & WIDTH

Metric (mm)	Imperial (inches)	Imperial (feet & inches)
1981 x 457	78" x 18"	6'6" x 1'6"
1981 x 533	78" x 21"	6'6" x 1'9"
1981 x 610	78" x 24"	6'6" x 2'0"
1981 x 686	78" x 27"	6'6" x 2'3"
1981 x 711	78" x 28"	6'6" x 2'4"
1981 x 762	78" x 30"	6'6" x 2'6"
1981 x 838	78" x 33"	6'6" x 2'9"
1981 x 915	78" x 36"	6'6" x 3'0"
1981 x 1067	78" x 42"	6'6" x 3'6"
1981 x 1168	78" x 46"	6'6" x 3'10"
1981 x 1220	78" x 48"	6'6" x 4'0"
1981 x 1372	78" x 54"	6'6" x 4'6"
1981 x 1524	78" x 60"	6'6" x 5'0"
2032 x 813	80" x 32"	6'8" x 2'8"
2134 x 915	84" x 36"	7'0" x 3'0"
2040 x 526	80 $\frac{1}{4}$ " x 20 $\frac{11}{16}$ "	6'8 $\frac{1}{4}$ " x 1'8 $\frac{11}{16}$ "
2040 x 626	80 $\frac{1}{4}$ " x 24 $\frac{5}{8}$ "	6'8 $\frac{1}{4}$ " x 2'0 $\frac{5}{8}$ "
2040 x 726	80 $\frac{1}{4}$ " x 28 $\frac{5}{8}$ "	6'8 $\frac{1}{4}$ " x 2'4 $\frac{5}{8}$ "
2040 x 826	80 $\frac{1}{4}$ " x 32 $\frac{1}{2}$ "	6'8 $\frac{1}{4}$ " x 2'8 $\frac{1}{2}$ "
2040 x 926	80 $\frac{1}{4}$ " x 36 $\frac{7}{16}$ "	6'8 $\frac{1}{4}$ " x 3'0 $\frac{7}{16}$ "