

Plow & Hearth®

11895

Product Name: Super Bright Pathlight, Set/4

PARTS:

Please do not throw away any packing material until all parts are verified by you as unpacked.


A – 4 x Lamp Housings

B – 4 x Diffusers

C – 4 x Glass Lens


D – 4 x Posts

E – 4 x Stakes



ASSEMBLY INSTRUCTIONS:

1. Locate housing (A) and move the switch to "On" position as shown in fig. 1,
2. Insert diffuser (B) into housing as shown in fig. 2.
3. Holding housing upside down, twist lamp counter clockwise into housing (fig. 3). Lamp is assembled (fig. 4).
4. After selecting a location for your light, and using a hammer, lightly tap stake (E) into the soil.
5. Twist post (D) onto stake (E) as shown in fig. 6.
6. Attach assembled lamp (fig. 4), and complete by attaching lamp onto post (fig. 7).



TROUBLE SHOOTING:

If the light does not turn on in the evening do the following:

1. Check the surrounding area for high ambient lights, such as porch lights, street lights, etc.
2. Make sure the solar panel is not located in a shady area where sunlight is not reaching the unit.
3. Make sure the batteries are making contact with the terminals (see "Battery Replacement" to learn how to access the battery area).

BATTERY REPLACEMENT:

Note: For replacement battery, same size higher mAh Lithium Phosphate rechargeable battery may be used.

Caution: Insert batteries with the correct polarity. Never short-circuit the battery terminals. Do not dispose of batteries in the fire, batteries may explode or leak. Remove batteries during long periods of non-use or when product is stored. Dispose of batteries safely.

1. To replace battery, remove lamp from post and repeat step 3 of assembly instructions, as shown in figure 3. Battery compartment is located housing as shown in fig. 8.
2. Replace old battery with new battery (ensuring terminal meets with battery end).

MAINTENANCE & CARE:

1. The end point of the ground stake is sharp. Do not allow children to play with the stake.
2. Wipe with soft dry cloth. Do not use any chemicals or abrasives of any kind.
3. The transparent lens on top of the solar panel assembly is sealed. Do not attempt to remove.
4. Solar lights are weatherproof, but during the winter or cold temperatures (below 0°C/32°F), it is best to remove them and store them until extreme weather has dissipated.
5. Check to make sure the batteries are installed correctly and there is nothing blocking the battery terminals from making contact. You may want to re-install the battery as some dislodging may occur during shipment, ensuring correct polarity (+) and (-).

HOW SOLAR LIGHT WORKS:

The solar light comprises of a solar cell, rechargeable batteries and LED light source. Light from the sun charges the batteries during the day, and at night the energy stored in the batteries is used to power the light. The length of time the light stays on for, is dependent on the amount of sunlight the solar panel has been exposed to during the day.

Note: The solar panel should be located where sunlight can fall directly on the unit.

Shadows from buildings, trees, walls, hedges or similar objects should be avoided as these will reduce your light's running time. Light will automatically turn on at night.

Place the solar panel where it will not be affected by artificial light.

