Product Installation Instructions

Ax1 Bx1 B₁x1 Cx1 Dx1

Ex3 Fx3 F₁x3 Gx3

Hx3 Ix1 Jx2 Kx1

Lx1 Mx1 Nx2 Ox2

Px1 Qx2 Rx1 Sx1 Tx1

1

Accessories list

| No.	Item	Description	Quantity
①		Two In One Screw (6x28mm)	66pcs +2pcs
②		Two In One Nut (10x12mm)	66pcs +2pcs
③		Wood Chipping (6x30mm)	12pcs +2pcs
④	x4 x4 x4	Pull loop handle (4x16mm)	4pcs
⑤		Screw & Guide (3x12mm)	2pcs / 10pcs +2pcs
⑥		Acrylic& Screw (3x12mm)	12pcs +2pcs / 3pcs
⑦		concealed lock & Screw (3x12mm)	6pcs +1pcs / 1pcs
⑧		Non-slip pads	4pcs
⑨		Round head screw (4x12mm)	4pcs +1pcs
⑩		Lamp	1pcs
		AC/DC Adapter (12V=2.0A)	1pcs

1pcs

Double-head screwdriver, use as required

2

Product structure decomposition

T

B A
C
D B₁

N

F E
G
H F₁
H G F₁
H G F₁

S

Q

R

Q

P O K

O N M

I

J

L J

3

①		28pcs	③		4pcs	⑤		2pcs 4pcs
②		28pcs	④		3pcs 12pcs	⑥		4pcs 4pcs 4pcs
⑦		1pcs 2pcs						

4

Use parts ① and ②

Step1

Step2

Step3

Use a screwdriver to lock in the direction of the "+" sign

Disassemble along the direction of "-" sign

Step 1

①		
		x2

②		
		x2

① x2

② x2

A

5

Step 2

Step 3

② ──── x2

Ⓐ Ⓑ Ⓒ Ⓑ₁

② x2

6

Step 4

① x2

D

Step 5

② x4

D

C

B

x4 ②

7

Exploded view of drawer guide rail

① ② ③

Step 1 : Pull the guide rail apart
Step 2 : Push the nylon buckle and
         pull outward ①

①
②
③

①
②
③

④ x1 x1 x1

① x2

x4

Step 6

x4 ⑤

A
B
C
B
D

8

Step 7

7

x1

x2

A

B

C

D

B₁

Step 8

1

x4

1 x4

E

9

Step 9

F

F₁

E

Step 10

G

F

E

F₁

10

Step 11

pay attention to

Acrylic
this side is flat and the reverse side is textured

Don't beat the acrylic board too tightly, it will crack

①	x4
④	x1 x1 x1
⑥	x1 x4

④ x1
x1 x1

① x4

H

H

6

4

Step 12

② x8

H

4

F1

G

E

F

x8 ②

11

| ① | x16 |
②	x16
④	x2	x2
⑥	x2	x8

Install the other two drawers using the same method

12

①		38pcs	③		8pcs	⑧		4pcs
②		38pcs	⑤	2pcs 4pcs		⑨		4pcs (4x12mm)
⑦		1pcs	⑦	(3x12mm) 4pcs		⑩		1pcs

T

S

P

R

Q

Q

D C

N

K

O

O

J I

M

J

L

N

13

Step 14

1 x6

1 x6

I

1 x4

Step 15

1 x4

K

J

J

I

14

Step 16

K

J

J

I

I

x4 2

Step 17

K

8 x4

x6 2

J

J

I

I

15

Step 18

① x4

② x4

2 x4

1 x4

Step 19

① x4

1 x4

M

16

Step 20

The installation method of the P board is also the same

N

M

Q

Step 21

② x4

x4 ②

17

Step 22

P

① ×4

① ×4

Step 23

P

② ×4

② ×4

M

18

Step 24

Flip one side over.

Step 25

② ⊗ x4

x4 ②

19

Step 26

R

9 x4

Step 27

2 x4

20

Step 28

⑦	🔲	1pcs	🔩	(3x12mm)	4pcs

S

① ×4

Step 29

S

×4 ②

21

Step 30

Flip one side over.

S

Step 31

⑤ x1
x3

x3 ⑤

22

Step 32

⑤ x1   x3

Flip one side over.

Step 33

x3 ⑤

As shown，When installing the drawer,
pull the guide rail out first, Slide beads are also pulled out.

23

Step 34

This is the light switch.
Click once to turn on the light,
then click twice to switch colors,
and click the fourth time to turn off the light

Can be bent to the appropriate position

Pass the DC port through the R board

Tighten

If a large gap is found after installing the drawer the slide rail
can be moved up and down to adjust the gap

24

TX1

You can carve the desired shape with a knife

T

Step 36

26

Step 37

x1

27

User's Guide

Thank you for purchasing this product.

To use this product, please plug it into a 12V DC power supply.

Please use if the product works normally after connecting to power.

Introduction

The box is an intelligent controller. It has 1 USB port and 1 type-C portand can distribute the current output up to 5V DC-2A. With 2 touch buttons, it can turn ON/OFF the light, change light colors, and adjust the light luminance.

Operation

This touch button is used to turn on/off, change colors, and adjust brightness.

A. Short touch -> lighting on -> short touch -> change light color -> short touch -> change light color -> short touch -> lighting off.

B. Long touch -> adjust the luminance.

This touch button is used to turn on/off the induction function.

A. Short touch to turn on the induction function. It can auto-turn on the light when people are close to the controller in 1 meters. It can auto power off the light when the body is far away from the controller after 30 seconds.

B. Long touch to turn off the induction function.

C. Note: When you touch the light button to change the light modes, the induction function will automatically turn off. It is best to turn on this function after selecting the light color and adjusting the brightness you want.

This range is a wireless charging area, and only mobile phones with wireless charging function can be charged.

Light Button

Induction Button

USB output port

Type-C output port

⚠ ATTENTION PLEASE

1. If there is no touch response suddenly, Re-plug the power to reset the touch static electricity.

2. If bubbles appear on the panel, remove the protective film.

3. If you have any questions when installing, please feel free to contact us. Thank you.