

Step 1: Insert 1 fresh AA, LR6 1.5 volt ALKALINE battery according to the polarity markings. The battery is a snug fit.

**Step 2:** Rotate the Time Set Wheel to set the time.

Step 3: Mount on the wall and enjoy!

**Note:** The quartz movement will keep the clock running accurately. If the clock does not operate, or steadily loses time, replace the battery.

## Frequently Asked Questions

#### Q. How long will the battery last?

A. A good AA alkaline battery will last over 12 months.

#### Q: Will this clock provide times around the world?

A: The time is set manually. The clock may be set for any time around the world.

#### Q: Why do the hands spin?

A: Hands may spin if the battery is under powered or over powered. Use only Alkaline batteries in the clock.

# Specifications

Warranty

Power Requirements:1 AA LR6 Alkaline BatteryBattery Life:over 12 months

### Care and Maintenance

- Always purchase the correct size and grade of battery most suitable for intended use.
- Clean the battery contacts and also those of the device prior to battery installation.
- Ensure the battery is installed with correct polarity (+and -).
- Remove battery from equipment which is not to be used for an extended period of time.
- Remove expired battery promptly.
- The specs of this wall clock may change without prior notice.
- Improper use or unauthorized opening of housing voids warranty.

Made in China - Printed in China