

















CARE AND MAINTENANCE

Spot clean using a mild water-free solvent. Only a professional cleaner should undertake a complete overall cleaning.
The use of steam or water-based cleaners may cause excessive shrinking or staining.


NOTICE

- * Please make sure that you have all parts indicated before you begin assembly of this item.
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly.
- * This item may require periodic tightening.

Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
A	TOP PANEL		1X
B	LEFT ASSEMBLY		1X
C	RIGHT ASSEMBLY		1X
D	FRONT APRON		1X
E	BACK APRON		1X
F	BACK BOTTOM RAIL		1X
G	VERTICAL RAIL		1X
H	RAILS ASSEMBLY		2X
1	55mm HEAD CAP BOLT	M6x55mm 	8X
2	SPRING WASHER		6X
3	FLAT WASHER		6X
4	ALLEN KEY		1X
5	CAMBOLT		12X
6	CAMLOCK		12X
7	DOWEL		6X
8	PIN		4X

Product Dimensions: 42" W x 20" D x 30" H



WEIGHT CAPACITY:
TOP: 100 LBS

**WARNING: DO NOT OVER TORQUE
BOLTS/SCREWS**


PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.

If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 30 minutes.

Tools Required for Assembly : Phillips Screwdriver



STEP 1 INSERT CAMBOLTS INTO PRE-DRILLED HOLES IN TOP PANEL AND RAILS ASSEMBLIES, THEN TIGHTEN. SCREW-IN CAMBOLTS MUST BE SCREWED DOWN FLUSH.

STEP 2 ATTACH RAILS ASSEMBLY TO BACK APRON USING CAMLOCKS.


PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.

If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 30 minutes.

Tools Required for Assembly : Phillips Screwdriver



STEP 3 ATTACH VERTICAL RAIL TO UNIT USING 55mm HEAD CAP BOLT. ATTACH BACK BOTTOM RAIL TO UNIT USING 55mm HEAD CAP BOLT AND PINS. TIGHTEN BOLTS USING ALLEN KEY.

STEP 4 ATTACH FRONT APRON AND UNIT TO LEFT ASSEMBLY UNIT USING 55mm HEAD CAP BOLTS, SPRING WASHERS AND FLAT WASHERS. TIGHTEN BOLTS USING ALLEN KEY.


PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.

If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 30 minutes.

Tools Required for Assembly : Phillips Screwdriver



STEP 5 ATTACH UNIT TO RIGHT ASSEMBLY UNIT USING 55mm HEAD CAP BOLTS, SPRING WASHERS AND FLAT WASHERS. TIGHTEN BOLTS USING ALLEN KEY.


STEP 6 ATTACH TOP PANEL TO UNIT USING CAM LOCKS.
NOTE: PAY ATTENTION TO THE POSITION OF THE ARROW LABEL IN THE TOP PANEL.

PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 30 minutes.

Tools Required for Assembly : Phillips Screwdriver



STEP 7 ADJUST THE ADJUSTER BOLT THAT HAS ALREADY ASSEMBLED TO THE LEGS TO STABILIZE YOUR UNIT