









# Assembly instruction

- S1**  25mm 8pcs  
**S2**  20 mm 15pcs  
**S3**  10mm 4pcs  
**S4**  8mm 4pcs  
**S5**  2pcs  
**S6**  1pc

Screw detail




A= cage side wall





B= cage back wall


**1** S2\*8pcs  
A1/A2\*1pc; B1/B2\*1pc




**2** S1\*8pcs  
H/C2\*2pc




C=cage front frame





D= small door



E= cage rainproof roof & roof top



**4** S4\*4pcs  
E\*1pc




F= rainproof drawer



G= board & stair

S2\*2pcs; S3\*4pcs; S6\*1pc  
C1/D



H= finished cage front frame

## SOFTLY REMIND

Make sure screws are accurately inserted. Avoid the points of nails sticking into the living space of your pet; they could cause injury.

## SOFTLY REMIND

Fir & plywood sections may twist when unassembled, if you happen to meet this problem do two steps as follow:

1. find out which surface is curved.
2. put the curved face down-ward the floor for a short time under the sunshine (if no sunshine, time should need little more).
3. then you can find the fir & plywood revert to level.

thank you