





# Installation & Assembly




**EN\_IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY.**


**USING CAM LOCK AND QUICKFIT**




**EN\_QUICKFIT:** Tighten quickfit until shoulder is flush with panel. Do not overtighten or undertighten.



**EN\_CAM LOCK:** When fitting cam lock, ensure starting position is correct before you insert connecting quickfit.























**EN\_Quickfit** head should be in the centre of the cam lock when the two panels are joined.  
Cam lock should be inserted before quickfit.
























**EN\_Turn** cam lock clockwise to tighten.



**PACKING DETAILS**

NO.	PARTS	QTY	SPARE
①		x1	
②		x1	
③		x1	
④		x1	
⑤		x2	
⑥		x2	
⑦		x1	
⑧		x2	
⑨		x3	
⑩		x1	


NO.	PARTS	QTY	SPARE
⑪		x1	
⑫		x1	
⑬		x3	
⑭		x1	
⑮		x1	
⑯		x2	
⑰		x2	
⑱		x2	
⑲		x1	
⑳		x1	




 <p><b>A</b> x32 Ø6x35mm +2(spare)</p>	 <p><b>B</b> x32 Ø15x10mm +2(spare)</p>	 <p><b>C</b> x48 Ø6x30mm +3(spare)</p>	 <p><b>D</b> x12 Ø4x35mm +1(spare)</p>	 <p><b>E</b> x24 Ø3.5x12mm +2(spare)</p>	<p><b>F</b> x2</p> <p>F-1 F-2 F-3</p> 
<p><b>G</b> x16 Ø3x16mm +1(spare)</p>  <p><b>G-1</b></p>  <p><b>G-2</b></p>	<p><b>H</b> x4 Ø5x50mm</p> 	<p><b>I</b> x4</p> 	<p><b>J</b> x2 Ø4x14mm</p>  <p><b>J-1</b></p>  <p><b>J-2</b></p>	<p><b>K</b> x2</p>  <p><b>K-1</b></p>  <p><b>K-2</b></p>	<p><b>L</b> x27 Ø20mm +2(spare)</p> 
<p><b>M</b> x8</p> 	<p><b>N</b> x1</p>  <p><b>N-1</b></p>  <p><b>N-2</b></p>	<p><b>O</b> x2</p>  <p><b>O-1</b></p>  <p><b>O-2</b></p>			



A x6



02



x2


B x6



C x4





03




B x4




C x4






H x4



C x4








A x10

E x12


I x4




x2

B x4


C x4



A x8



10




B x6





C x4



11





D x4



C x8




D x4






The backplate groove is facing upwards


B x8

C x8







First fix the anti-rewind screw in the reserved hole of the product.



then, use a ruler to measure the approximate height of the product on the wall, and then mark it with a pen.





Then use a tape drill to make holes in the wall that are suitable for the product screws.



B x4

C x8






G x16




G-1






G-2



L x27  
Ø15mm



M x8



F x2



O x2


F-1 F-2 F-3





O-1

O-2






K x2



Then, put the expansion bolt into the hole

(1)x2



Finally, pass the matching screws through the "anti-rewind" and tighten them to fix them on the wall.

(2)x2

