


INSTALLATION INSTRUCTIONS







10x12 ft Storage Shed



After opening the package, if you notice a slight deformation in the wall panels, there's no need for concern. Our material is flexible and can be manually bent back into place.

Recommended to wear gloves to avoid scratches.
Please read the instructions COMPLETELY before assembly.

REQUIRED TOOLS

Tools			
	Gloves	Table	Ladder
			
	Power drill	Screw drive	Tape Measure

ASSEMBLY TIPS

1. Clear a working area to allow access on all four sides. A raised work surface will make assembly easier. It is easier to install the wall panel on the table.
2. All parts are identified, so when working through the instructions page by page, the diagrams show where each part is positioned.
3. Before starting, to avoid any accidental injury, we recommend the use of gloves to protect your hands.
4. Please keep children away from your construction site.
5. Most assembly can be completed by one person, but assistance may be needed when you reach the erection stage.
6. Please note: Some local government authorities have rules & regulations on shed installation, and you may need approval to erect this shed.








ASSEMBLY STEPS

1. Unpack all components from the carton and lay them out beside your work area. Check parts against the parts list.
2. Work through the assembly instructions page by page.
3. Once assembly is completed, place the shed in position and fix the anchor to the ground.
4. Clean up all metal pieces and screws.



















K1012parts list(A)

[illegible]

K1012parts list (B)


PART	NO.	QTY.
	K1012-7L	2
	K1012-7M	10
	K1012-7R	2
	W5-CD	4
	W3-D	2
	W2-HLD	1
	W2-HRD	1

K1012parts list(C)


PART	NO.	QTY.
	K1012-1L	2
	K1012-1M	2
	K1012-1R	2
	K810-2	2
	K1012-2R	2
	K1012-3L	2
	K1012-3M	2
	K1012-3R	2
	K810-4	2
	K1012-4R	2
	K1012-5L	2
	K1012-5R	2
	K1010-6L	6
	K1010-6R	6
	K1012-8	8
	K1012-9L	2
	K1012-9R	2
	K810-10	1
	K1012-10R	1
	UAD	2
	C3	4
	K1012-11	8
	DAD	2
	DLAD	1

[illegible]


Shed top panels



Shed top frame





Door and Shed base












Sort By Splicing

[illegible]



STEP1






PART	NO.	QTY.
	K1012-1L	2
	K1012-1M	2
	K1012-1R	2
	K810-2	2
	K1012-2R	2
	T-F	4
	F1	42











STEP2

PART	NO.	QTY.
	W5-CD	4
	F1	12







STEP3


PART	NO.	QTY.
	K1012-3L	2
	K1012-3R	2
	K1012-3M	2
	K810-4	2
	K1012-4R	2
	F1	48
	C2	4




STEP4







PART	NO.	QTY.
	W5-D	10
	F1	84
	F2	12







STEP5





PART	NO.	QTY.
	W5-D	8
	F1	66
	F2	9








STEP6

PART	NO.	QTY.
	W5-D	4
	W3-D	2
	F1	40
	F2	6









STEP7

PART	NO.	QTY.
	UAD	2
	F1	8
	F2	2









STEP8

PART	NO.	QTY.
	K1012-5L	1
	K1012-5R	1
	F1	8
	V2	8








STEP9

PART	NO.	QTY.
	K1012-5L	1
	K1012-5R	1
	F1	8
	V2	8






STEP10




PART	NO.	QTY.
	C3	4
	K1012-11	8
	F2	4
	F1	16




STEP11

The K1010-6L is small enough in width to snap into the K1010-6R and align their holes.


PART	NO.	QTY.
	K1010-6L	6
	K1010-6R	6
	F2	30




*3









STEP12



PART	NO.	QTY.
	F2	12







STEP13




PART	NO.	QTY.
	K1012-7L	2
	K1012-7M	10
	K1012-7R	2
	F1	120
	V2	120




STEP14









PART	NO.	QTY.
	K810-10	1
	K1012-10R	1
	F1	4
	V2	4


As shown in the picture: the 2 components of the roof rain stopper are first connected with F1 self-tapping screws before subsequent installation.




STEP15




PART	NO.	QTY.
	K1012-8	8
	K1012-9L	2
	K1012-9R	2
	GC	4
	GE	2
	F1	28
	V2	32
	F4	4




STEP16



STEP17




STEP18








PART	NO.	QTY.
	W5-KD	1
	W2-HRD	1
	F2	2


STEP19






PART	NO.	QTY.
	DAD	1
	DRAD	1
	DDA	2
	DBD	2
	F1	9
	F2	2



STEP20

PART	NO.	QTY.
	DH	4
	DC	2
	F3	16
	GL	1
	F1	4







STEP21

PART	NO.	QTY.
	DL	1
	DR	1
	F3	16



STEP22

PART	NO.	QTY.
	SL	66



Upper cross member K1010-6L
K1010-6R and top cover
assembly screws require
plastic protective caps on
the exposed portion.