

1. Manual panel Version:




- 1) With the unit in Off position, place put container on the blender base. Be sure container is fully seated and that drive coupling I properly engaged. And than plug blender cord into outlet. And be sure Minimise the speed before switch off.
- 2) Put ingredients into container and cover it. Do not fill the liquid to more than 1800ml or it will cause the cover to pop out and, or causespillage. If blending hot liquid, make sure to let the liquid stand for the few minutes with the cover off to let the steam out.
- 3) Press the power switch to ON.
- 4) Chooses the LOW or HIGH speed for operating after starting. Make sure the knob is at the lowest speed before turning on the machine, Adjust the speed higher only after switchingon the blender.
- 5) Switch to OFF, the machine will be shut off.
- 6) Pulse buttons: the pulse key is used to make the cooking machine perform short-term operation and operation. This is the maximum speed.

2. Touch panel Version:



INTELLIGENT OPERATION	
	Power, Start or Stop
	Touch or press this function with the Smoothies1 function,setting time and speed: Smoothies 1 : all time 40S, intelligent timing,Maximum speed 8.
	Touch or press this function with the Smoothies2 function,setting time and speed: Smoothies 2: all time 60S, intelligent timing,Maximum speed 8.
	Touch or press this function with the Fruit function,setting time and speed: Fruit: all time 90S, intelligent timing,Maximum speed 8.
	Touch or press this function with the Sauce function,setting time and speed: Sauce : all time 120S, intelligent timing,Maximum speed 6..
	Touch or press this function with your finger to start working until your hand leaves the machine and will stop.
	Each press plus or minus 10 seconds.
	Each press plus or minus 1 speed, 8 speeds.



1. Manual panel Version:



- 1) With the unit in Off position, place put container on the blender base. Be sure container is fully seated and that drive coupling I properly engaged. And than plug blender cord into outlet. And be sure Minimise the speed before switch off.
- 2) Put ingredients into container and cover it. Do not fill the liquid to more than 1800ml or it will cause the cover to pop out and, or causespillage. If blending hot liquid, make sure to let the liquid stand for the few minutes with the cover off to let the steam out.
- 3) Press the power switch to ON.
- 4) Chooses the LOW or HIGH speed for operating after starting. Make sure the knob is at the lowest speed before turning on the machine, Adjust the speed higher only after switchingon the blender.
- 5) Switch to OFF, the machine will be shut off.
- 6) Pulse buttons: the pulse key is used to make the cooking machine perform short-term operation and operation. This is the maximum speed.

2. Touch panel Version:



INTELLIGENT OPERATION	
	Power, Start or Stop
	Touch or press this function with the Smoothies1 function,setting time and speed: Smoothies 1 : all time 40S, intelligent timing,Maximum speed 8.
	Touch or press this function with the Smoothies2 function,setting time and speed: Smoothies 2: all time 60S, intelligent timing,Maximum speed 8.
	Touch or press this function with the Fruit function,setting time and speed: Fruit: all time 90S, intelligent timing,Maximum speed 8.
	Touch or press this function with the Sauce function,setting time and speed: Sauce : all time 120S, intelligent timing,Maximum speed 6..
	Touch or press this function with your finger to start working until your hand leaves the machine and will stop.
	Each press plus or minus 10 seconds.
	Each press plus or minus 1 speed, 8 speeds.