


ASSEMBLY INSTRUCTION


| | | |
|----------------------|--------------------------|--------|
| A | Arm A1 | 2 pcs |
| B | Slat 13 Pcs | 1 pc |
| C | Back Panel | 1 pc |
| D | Side Rail | 1 pc |
| E | Trundle Front Panel (PU) | 1 pc |
| F | Trundle Back Panel | 1 pc |
| G | Trundle Side Panel | 2 pcs |
| H | Slat 13 Pcs | 1 pc |
| I | Middle Panel | 1 pc |
| Packing Hardware (1) | | |
| 1 | M5 x 70 mm | 1 pc |
| 2 | M5 x 65 mm | 1 pc |
| 3 | CSK M4 x 32mm | 26 pcs |
| 4 | JCBC M6 X 50 | 4 pcs |
| 5 | FLAT WASHER | 4 pcs |
| Packing Hardware (2) | | |
| 6 | M5 x 70 mm | 1 pc |
| 7 | CSK M4 x 32 mm | 44 pcs |
| 8 | Roller With Wooden | 6 pcs |

Step 1: Attach the back panel (C) to arm (A) . Attach side rail (D) to arm (A) by pushing the bracket down to fit it. Tighten with Allen Key (1)




BACK VIEW


Step 3: Tighten the slats with CSK screw (3). The distance of the slats should be sufficient to obtain desirable bed stability.




Step 2: Attach middle panel (H) to arm (A) by pushing the bracket down to fit it. Tighten with Allen Key (1)




Step 4: Attach trundle side panel (G) and trundle front panel (E) to trundle back panel (F) by pushing the bracket down to fit it.




Step 5 :Fix the slat (H) to the side rail at (E) & (F) .



Step 6: Tighten the 4 Corner with Allen Key (3) and fix the slat (H) to the side rail at (E) & (F) .



Step 7: Turn the trundle to another side as below diagram and tighten the roller with wooden (8) at the slat (H) .



Step 8: Assembly is complete

