







ASSEMBLY INSTRUCTIONS






Assemble the furniture on empty carton, carpet, or rug to prevent scratches or damage.




This furniture requires 2 people to assembly.
Make sure no parts are missing or damaged before assembly.


BOARD IDENTIFICATION




① (120X40X1.5cm) X1




② (75.6X39.9X2.5cm) X1




③ (75.6X39.9X1.2cm) X1




④ (75.6X39.9X2.5cm) X1




⑤ (72.2X303X0.3cm) X2




⑥ (28.1X6X1.2cm) X4




⑦ (28.1X9.2X1.2cm) X1




⑧ (26.9X4.8X1.2cm) X2




⑨ (28.1X8X1.2cm) X2



⑩ (28.1X9.2X1.2cm) X1




⑪ (75.6X39.9X1.2cm) X1




⑫ (58.9X119.8X1.7cm) X1


BOARD IDENTIFICATION




⑬ (35X14X1.2cm) X6




⑭ (35X14X1.2cm) X6




⑮ (22.7X26.3X1.5cm) X6




⑯ (22X14X1.2cm) X6




⑰ (23X34.7X0.3cm) X6




⑱ (35X9.7X1.2cm) X1




⑲ (35X9.7X1.2cm) X1




⑳ (15.9X58X1.5cm) X1




㉑ (53.7X9.7X1.2cm) X1



㉒ (54.7X34.7X0.3cm) X1




㉓ (33.7X6X1.2cm) X1




㉔ (105X25X0.4cm) X1


BOARD IDENTIFICATION




②⑤ (119.7X6X1.5cm) X1




②⑥ (57.3X6X1.5cm) X3



②⑦ (58.6X16.5X1.2cm) X1




②⑧ (58.6X8X1.2cm) X1
























②⑨ (58.6X11.7X1.2cm) X1

BOARD IDENTIFICATION







HARDWARE PART LIST







Cam Lock Fastening System


Insert the cam bolt into the hole first, then insert the cam lock and lock it.






STEP 1




(E)	X18
	
ø3.5*12	


(N)	X3
	CL
L=350	


(N)	X3
	CR
L=350	





STEP 2




(E)	X12
	
ø3.5*12	

(N)	X1
	CL
L=350	

(N)	X3
	CR
L=350	




STEP 3




(E)	X12
ø3.5*12	

(N)	X3
L=350	





(N)	X1
L=350	







STEP 4




(B)	X18
A side-view illustration of a screw with a Phillips head and a threaded shaft.	
$\phi 6.5 \times 35$	





STEP 5





STEP 6





(A)	X4
	
$\phi 15 * 9.5$	

(B)	X4
	
$\phi 6.5 * 35$	

(D)	X4
	
$\phi 6 * 30$	







Insert the cam bolt into the hole first, then insert the cam lock and lock it.



Proper orientation of CAM LOCK



STEP 7





No Hole



Pay attention to the installation direction of the 9 board.






Insert the cam bolt into the hole first, then insert the cam lock and lock it.




Proper orientation of CAM LOCK

STEP 8




Insert the cam bolt into the hole first, then insert the cam lock and lock it.




Proper orientation of CAM LOCK

STEP 9



(A)	X9
$\phi 15 \times 9.5$	





(B)	X9
$\phi 6.5 \times 35$	





No Hole



Pay attention to the installation direction of the 9 board.





Insert the cam bolt into the hole first, then insert the cam lock and lock it.




Proper orientation of CAM LOCK


STEP 10



(A)	X9
	
Ø15*9.5	




Insert the cam bolt into the hole first, then insert the cam lock and lock it.



Proper orientation of CAM LOCK





STEP 11




(A)	X6
$\phi 15 * 9.5$	

(B)	X10
$\phi 6.5 * 35$	

(C)	X9
$\phi 8 * 30$	







Insert the cam bolt into the hole first, then insert the cam lock and lock it.




Proper orientation of CAM LOCK

STEP 12





Insert the cam bolt into the hole first, then insert the cam lock and lock it.





Proper orientation of CAM LOCK




STEP 13






(B)	X10
	
$\phi 6.5 \times 35$	

(J)	X6
	
$\phi 6.3 \times 50$	





(L)	X6
	
$\phi 21$	



STEP 15




STEP 16




For this step, you need one helper.

Insert the cam bolt into the hole first, then insert the cam lock and lock it.





STEP 17




(A)	X2
ø15*9.5	

(H)	X20
ø3*14	

(R)	X1set








Insert the cam bolt into the hole first, then insert the cam lock and lock it.




Proper orientation of CAM LOCK

STEP 18




(F) X2	(I) X2	(O) X1	(M) X1
			
ø3*12	ø4*12	145*55*45	109*99*38.5



The plug penetrates the reserved hole in the backboard.

STEP 19




(A)	X24
ø15*9.5	

(B)	X24
ø6.5*35	

(E)	X12
ø3.5*12	


(G)	X24
ø4*35	

(K)	X6
120*38*17	




Step 1

Step 2






Step 4

Step 5




Step 3




X6


Insert the cam bolt into the hole first, then insert the cam lock and lock it.





Proper orientation of CAM LOCK


STEP 20



(E)	X36
	
$\phi 3.5 \times 12$	


(N)	X6
	DL
L=350	

(N)	X6
	DR
L=350	





X6

STEP 21








(A)	X5	(B)	X5	(E)	X2	(G)	X6
$\phi 15 \times 9.5$		$\phi 6.5 \times 35$		$\phi 3.5 \times 12$		$\phi 4 \times 35$	

(K)	X1
$120 \times 38 \times 17$	




Step 1


Step 2





Insert the cam bolt into the hole first, then insert the cam lock and lock it.





STEP 22





(E)	X6
	
$\phi 3.5 \times 12$	

(N)	X1
	
DL L=350	


(N)	X1
	
DR L=350	



STEP 23





Cabinet Slide




Drawer Slide


STEP 24



Pass the bulb wire through the pre punched plate.







STEP 25



Pass the bulb wire through the pre punched plate, Fix It, and then connect the adjacent bulbs successively through the wire head slot on the opposite side (corresponding to the line of the same color).


same color correspond

When connecting the interface, please note that the colors of the wires at both ends correspond one by one.




USB

The USB plug is plugged into the socket of the Q Board.




Switch regulator



STEP 26



Put the Glass "24" in the slot reserved for the panel;
"24" must be sloped into the interior of and then flat.




STEP 27




⚠ WARNING	
	<p>Children have died from furniture tipover. To reduce the risk of furniture tipover:</p> <ul style="list-style-type: none"> ● ALWAYS install tipover restraint provided. ● NEVER put a TV on this product. ● NEVER allow children to stand, climb or hang on drawers, doors, or shelves. ● NEVER open more than one drawer at a time. ● Place heaviest items in the lowest drawers.
	<p><i>This is a permanent label. Do not remove !</i></p>


Install the tipping restraint hardware




1. make mark on the wall




2. drill two Ø6 holes on the wall



3. put two anchors in the holes



4. fix the device on the wall by the long screws



5. Push the cabinet close to the wall so that the two bases are close to each other, and then nylon tie to tighten it.

