


Assembly Instructions




Before Assembly

Tips Before Your Start:


- Remove all wrapping material, including staples & packing straps before you start to assemble.
- DO NOT tighten all screws and bolts until the assembly is completely assembled.
- Keep all hardware parts out of reach of children.

QUICKFIT



Tighten quickfit until shoulder is flush with panel. Do not overtighten or undertighten.


CAM LOCK



When fitting a cam lock, ensure the starting position is correct before inserting the connecting QUI CKFIT

Quickfit head should be in the centre of the cam lock when the two panels are joined.

Cam lock should be inserted before quickfit.




Turn cam lock clockwise to tighten.

Before Assembly


Tips Before Your Start

How to separate the drawer slider:




2. Pull out the inner slider for drawer box fixing

Drawer Front Alignment


















If the drawer front panel is NOT level after being assembled, then...




Loosen the screws on the left and right hand side, then adjust the drawer slide up or down, until the drawer fronts are even/level, then tighten the screws.


Part List

<p>No. A Quantity:64 Pcs Cam Lock Dowel 8*28mm</p> 	<p>No. B Quantity:64 Pcs Cam φ15</p> 	<p>No. C Quantity:64 Pcs Sticker Ø20</p> 	<p>No. D Quantity:8 Pcs Dowel 8*30mm</p> 
<p>No. E Quantity:9 Sets Drawer Slider 10"</p> 	<p>No. F Quantity:36 Pcs Screw M4*30mm</p> 	<p>No. G Quantity:90 Pcs Screw M3.5*12mm</p> 	<p>No. H Quantity:9 Pcs Handle 120*38*17mm</p> 
<p>No. I Quantity:4 Pcs Slip Mat Ø20</p> 	<p>No. J Quantity:6 Pcs Screw M8*35mm</p> 	<p>No. K Quantity:1 Pcs Allen Key 5#</p> 	<p>No. L Quantity:12 Sets Plastic Wedge</p> 
<p>No. M Quantity:2 Sets Anti-falling Parts</p> 	<p>No. N Quantity:2 Pcs Full Thread Screw M8*40mm</p> 	<p>No. O Quantity:2 Pcs Adjust The Foot</p> 	

Product structure



STEP 1



No. A
Quantity: 16 Pcs
8*28 mm







STEP 2



The first screw hole should correspond with the board location hole

⚠ Here are only the corresponding holes




⚠ Here are only the corresponding holes

No. A
Quantity: 4 Pcs
8*28 mm



No. E
Quantity: 3 Sets
10"





No. G
Quantity: 12 Pcs
M3.5*12mm




STEP 3

The first screw hole should correspond with the board location hole

! Here are only the corresponding holes




! Here are only the corresponding holes



No. A
Quantity: 8 Pcs
8*28 mm



No. E
Quantity: 6 Sets
10"




No. G
Quantity: 24 Pcs
M3.5*12mm



x2


STEP 4



No. B
Quantity: 4 Pcs
Ø15




STEP 5



No. B
Quantity: 4 Pcs
Ø15




STEP 6




No. B
Quantity: 4 Pcs
Ø15



STEP 7




STEP 8




No. B
Quantity: 8 Pcs
Ø15




No. D
Quantity: 4 Pcs
8*30mm



STEP 9




STEP 10




No. B
Quantity: 8 Pcs
Ø15



No. D
Quantity: 4 Pcs
8*30mm



STEP 11




Assemble it first

No. J
Quantity: 6 Pcs
M8*35mm




No. K
Quantity: 1 Pcs
5#



No. N
Quantity: 2 Pcs
M8*40mm




STEP 12




No. I
Quantity: 4 Pcs
Ø20




No. O
Quantity: 2 Pcs



STEP 13



x4



x1

No. A
Quantity: 20 Pcs
8*28 mm




No. G
Quantity: 10 Pcs
M3.5*12mm




No. H
Quantity: 5 Pcs
120*38*17mm



STEP 14



x2



x2


No. A
Quantity: 16 Pcs
8*28 mm




No. G
Quantity: 8 Pcs
M3.5*12mm




No. H
Quantity: 4 Pcs
120*38*17mm



STEP 15




×6




×3


No. F
Quantity: 36 Pcs
M4*30mm



STEP 16




×6




×3

STEP 17



x4




x1


No. B
Quantity: 20 Pcs
Ø15



STEP 18



x2



x2


No. B
Quantity: 16 Pcs
Ø15




STEP 19



The first screw hole should corresponded with the board location hole




x4



x1

No. E
Quantity: 5 Sets
10"




No. G
Quantity: 20 Pcs
M3.5*12mm




STEP 20



The first screw hole should corresponded with the board location hole




x2



x2


No. E
Quantity: 4 Sets
10"




No. G
Quantity: 16 Pcs
M3.5*12mm



STEP 21




STEP 22










Description: Insert the thinner end of the reinforcement into the gap in this back panel, then tighten the screws. This will make the cabinet more stable.


No. L
Quantity: 12 Sets



STEP 23



No. M
Quantity: 2 Set



Note:
Please lift up the furniture by two people when moving is needed.
Dragging may cause the legs failure.