


CARE AND MAINTENANCE

Spot clean using a mild water-free solvent. Only a professional cleaner should undertake a complete overall cleaning.
The use of steam or water-based cleaners may cause excessive shrinking or staining.

NOTICE

- * Please make sure that you have all parts indicated before you begin assembly of this item.
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly.
- * This item may require periodic tightening.

Product Dimenions: 66 15/16"W x 31 1/2"D x 29 1/2"H





Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
A	TOP ASSEMBLY		1X
B	LEG		4X

PIECE	DESCRIPTION	PICTURE	QUANTITY
1	THREADED ROD	5/16"x3 5/32"	8X
2	SPRING WASHER	Ø13/Ø8x2mm	8X
3	FLAT WASHER	Ø18/Ø8x2mm	8X
4	NUT	5/16"x1/4"	12X
5	WRENCH		1X



PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.
If any part is missing or damaged, do not attempt to assemble the product.
Estimated Assembly Time: 60 minutes.
Tools Required for Assembly : Phillips Screwdriver

 <p>The diagram shows a perspective view of a rectangular metal frame assembly. A screwdriver is shown removing a screw from the top edge of the frame. A label 'A' points to the inner frame structure.</p>	 <p>The diagram shows the same rectangular metal frame assembly with four legs, labeled 'B', being attached to the corners. A circular inset provides a close-up view of a leg being attached to the corner using a nut, labeled '4'. A label 'A' points to the inner frame structure.</p>
<p>STEP 1 UNINSTALL WOOD SCREWS AT TOP ASSEMBLY AND REMOVE APRON FROM TOP ASSEMBLY.</p>	<p>STEP 2 ATTACH LEGS TO TOP ASSEMBLY USING NUTS. DO NOT TIGHTEN NUTS AT THIS TIME.</p>



PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.
If any part is missing or damaged, do not attempt to assemble the product.
Estimated Assembly Time: 60 minutes.
Tools Required for Assembly : Phillips Screwdriver

	
<p>STEP 3 INSERT APRON TO TOP ASSEMBLY. ATTACH LEGS TO APRON USING THREADED RODS, SPRING WASHERS, FLAT WASHERS AND NUTS. TIGHTEN NUTS USING WRENCH.</p>	<p>STEP 4 TIGHTEN ALL NUT.</p>

PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.
If any part is missing or damaged, do not attempt to assemble the product.
Estimated Assembly Time: 60 minutes.
Tools Required for Assembly : Phillips Screwdriver

 <p>A line drawing showing the underside of a rectangular table. The base is made of several parallel wooden slats. Four legs are attached to the corners. A central crossbar is visible. A Phillips screwdriver is shown pointing to a hole in the wood, indicating where to install a screw. The table is shown in its folded, upright position.</p>	 <p>A line drawing showing the table in its upright position. The table has a rectangular top and four legs. A circular inset shows a close-up of the leg adjustment mechanism, which consists of a central bolt with a circular base and four arrows pointing outwards, indicating it can be adjusted to stabilize the leg.</p>
<p>STEP 5 REINSTALL WOOD SCREWS IN STEP 1.</p>	<p>STEP 6 TURN TABLE OVER ITS' UPRIGHT POSITION. ADJUST THE ADJUSTER BOLT THAT HAS ALREADY INSTALLED TO STABILIZE YOUR UNIT.</p>