


# Hampstead - Storage Cabinet

Assembly Instructions - Please keep for future reference

MS4408



## Dimensions

Width - 84cm

Depth - 24cm

Height - 103cm

**Important** – Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts,  
email us at [techstyle.spares@stadiumcp.co.uk](mailto:techstyle.spares@stadiumcp.co.uk)



# Safety and Care Advice

**Important** – Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on pages 2 and 3.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.

- Do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



- We do not recommend the use of power drill/drivers **for inserting screws**, as this could damage the unit. Only use hand screwdrivers.
- Dispose of all packaging carefully and responsibly.

**Glue safety** - Take care when using glue, please follow the advice below

**Skin contact:** Remove contamination by washing with soap and water. This procedure should also be followed prior to eating and drinking.

**Eye contact:** Rinse immediately with clean water for 15 minutes and seek medical advice.

**If swallowed:** Seek medical advice immediately.

**Care and maintenance**

• Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.

• From time to time check that there are no loose screws on this unit.

• This product should not be discarded with household waste. Take to your local authority waste disposal centre.

**Glass care and maintenance**

• Do not place very hot or cold items on the glass surface(s) unless adequately thick table mats or coasters are used to prevent such items from coming into contact with the glass

• Do not sit or stand upon the glass.

• Do not use the glass as a chopping surface.

• Do not strike the glass with hard or pointed items.


• When cleaning glass panels use a damp cloth or leather with washing up liquid or soft

soap if necessary: do not use washing powders or any other substances containing abrasives since these substances scratch glass.

# Components - Panels

If you have damaged or missing components, email us at [techstyle.spares@stadiumcp.co.uk](mailto:techstyle.spares@stadiumcp.co.uk)

Please check you have all the panels listed below






# Components - Fittings


If you have damaged or missing components, email us at [techstyle.spares@stadiumcp.co.uk](mailto:techstyle.spares@stadiumcp.co.uk)


Please check you have all the fittings listed below

**Note:** The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.


<b>1</b>  Wooden dowel x 18	<b>2</b>  Glue x 1	<b>3</b>  Camlock nut x 9
<b>4</b>  Camlock bolt x 9	<b>5</b>  Large screw x 8	<b>6</b>  Metal support x 44
<b>7</b>  Back bracket x 8	<b>8</b>  Medium Screw x 8	<b>9</b>  Handle x 2
<b>10</b>  Wall safety kit x 2		

## Tools required

 Crosshead screwdriver (medium & large)

 Flatblade screwdriver (medium)

 7mm Suitable drill bit (for use with wall plug)




Drill

 Small hammer

 Ruler/tape measure

 Eye protection (when using a hammer or glue)

Ruler - Use this ruler to help correctly identify the screws




# Assembly Instructions

## Step 1

### Assemble frame


**a:** Attach base **B** to left side **C**, central upright **E**, and right side **D** using 8 x large screw **5** as shown.

**NOTE:** Make sure all of the grooves for the backboard are nearest the floor.






**b:** Insert 4 x wooden dowel **1** (adding a dab of glue **2** to the ends) into ends of plinth side **L**. Repeat for second plinth side **L**.

Slot plinth front **J** onto 2 x plinth side **L**, slot plinth back **K** onto 2 x plinth side **L**.



**c:** Insert 4 x wooden dowel **1** (adding a dab of glue **2** to the ends) and 6 x camlock bolt **4** into base **B**.

Slot on assembled plinth and secure together by inserting 6 x camlock nut **3** into assembled plinth - rotate clockwise 1/4 to 1/2 a turn until they connect with the camlock bolts.



# Assembly Instructions

## Step 1 cont.

### Assemble frame

**d:** To attach the 2 x back panel **L** to the back of the assembled frame make sure that the wood effect side is facing inwards and the cutouts are at the top.

Attach 2 x back panel **L** to frame by sliding into the grooves as shown.

**e:** Insert 3 x camlock bolt **4** into top **A**.

**f:** Insert 6 x wooden dowel **1** (adding a dab of glue **2** to the ends) to assembled frame as shown.






Attach top **A** to the assembled frame.

inserting 3 x camlock nut **3** as shown - but do not tighten.

**g:** Insert 4 x metal support **6** into level holes - two on each side of the desired shelf position.

Insert shelf **F** resting it on the metal supports **6**. Do this for each of the ten shelves.

**NOTE: The shelf supports can be repositioned at any time to give taller or shorter shelves.**



# Assembly Instructions

## Step 2

### Add doors and secure

**h:** Insert 2 x metal support **6** into the top of left door **G**. Repeat for right door **H**.




**Warning:**  
Handle glass  
with care

Gently lift the front of top **A** and slot left door **G** and right door **H** into top and guide them to “drop” carefully into the groove in the base.

**i:** Secure top **A** by tightening the camlock nuts **3** - rotate clockwise 1/4 to 1/2 a turn until they connect with the camlock bolts.

Insert 2 x handle insert **9** - 1 each into left door **G** and right door **H**.

**j:** Secure back panels **L** to frame using 6 x back bracket **7** and 6 x medium screw **8** as shown - checking that the frame is square and at right angles.



# Assembly Instructions

## Step 3


### Attaching to the wall

For added security you can attach this unit to your wall using wall strap and fixings kit **10**.

Measure the distance between the two cutouts in the backboard of the cabinet. Transpose these measurements to the wall making sure the marks are level.

Drill holes suitable for your wall plugs. Tap wall plugs into drilled holes. Attach unit to wall using 2 x wall fixing straps **10**.

**Note:** make sure you use wall plugs suitable for your type of wall.



**Assembly is complete.**

If you need any help or have damaged or missing parts, email [techstyle.spares@stadiumcp.co.uk](mailto:techstyle.spares@stadiumcp.co.uk)  
Techstyle Spares, Stadium North, Tofts Farm Industrial Estate, Brenda Road, Hartlepool, TS25 2DH

# A Guide to - Wall Mounting & Fixings

Important note:

**If plastic wall plugs are supplied with your product:**



- these are only suitable for use in masonry walls.

If you are in any doubt about the correct wall plugs for your wall, seek professional advice.

Failure of the product due to using incorrect fixings is the responsibility of the installer.



**Important:** When drilling into walls always check that there are no hidden wires or pipes etc.

Make sure that the screws and wall plugs being used are suitable for supporting your unit. Consult a qualified tradesperson if you are unsure.


## Hints:

- 1: General rule:**  Always use a larger screw and wall plug if you are not sure.
- 2:** Ensure you use the recommended drill bit to match the wall plug and hole size.
- 3:** Ensure you drill the hole horizontally, do not force the drill or enlarge the hole.
- 4:** Take extra care when drilling high walls, ceilings and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid the tiles splitting or cracking.
- 5:** Ensure wall plugs are well fitted and are a tight fit in the drilled hole.

## Types of walls


You can use one of the following types of wall plug if your walls are made of brick, breeze block, concrete, stone or wood.

### No.1 "General Purpose" wall plug




Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.

### No.2 "Plasterboard" wall plug




For use when attaching light loads on to plasterboard partitions.

### No.3 "Cavity Fixing" wall plug




For use with plasterboard partitions or hollow wooden doors.

### No.4 "Cavity Fixing-Heavy Duty" wall plug




For use when fitting or supporting heavy loads such as shelving, wall cabinets and coat racks.

### No.5 "Hammer Fixing" wall plug



For use with walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.

### No.6 "Shield Anchor" wall plug Heavy loads



For use with heavier loads such as TV & HiFi speakers and satellite dishes etc.



## Care & Maintenance

**Safety:** Always check the fitting and location to ensure your safety in and around the home.

**Fitting:** From time to time check the fitting to ensure the wall plugs or screws do not become loose.