


---

JY9953




As this item contains many parts, please read the installation instruction carefully before installation . Please use tools properly and carefully. If you have any questions about the product and installation, please contact us.

**[hosoteservice@gmail.com](mailto:hosoteservice@gmail.com)**

Our professional after-sales team will serve you online all day.

## Before You Start




- ✓ Read through each step carefully and follow the proper order
- ✓ Separate and count all your parts and hardware
- ✓ Give yourself enough room for the assembly process
- ✓ Have the following tools: Flat Head Screwdriver, #2 Phillips Head Screwdriver and Hammer
- ✓ Caution: If using a power drill or power screwdriver for screwing, please be aware of to slow down and stop when screw is tight. (Assembly speed can be increased by using electric screwdriver)


## Helpful Hints

### PEOPLE NEEDED FOR ASSEMBLY: 2

- Open your item in the area you plan to keep it to avoid excessive heavy lifting.
- Identify, sort and count the parts before attempting assembly.
- Compression dowels are lightly tapped in with a hammer.
- Slides are labeled with an **R** (right) and **L** (left) for proper placement.
- Make sure to always face the point on the top of the Cam Lock towards the outer edge.
- If there is a back panel in the package, please install it to make sure your unit is complete and sturdy.
- Please fix all the screws provided for the back panel which can enhance product stability. If it is difficult to fix it when tightening, it can be fixed with the help of a hammer and then tightened.
- Do NOT use harsh chemicals or abrasive cleaners on this item.
- Never push, pull, or drag your furniture.















**NOTE: Please push to the bottom.**



21

# Board Identification


Not actual size

①	②	③	④
			
Cross beam riveted piece Qty: 2	Right high foot Qty: 1	Left high foot Qty: 1	Middle crossbar Qty: 1
⑤	⑥	⑦	⑧
			
Sparerib strips Qty: 10	Headstock tail connecting rod Qty: 2	Middle connecting rod Qty: 2	Middle support foot 1 Qty: 1
⑨	⑩	⑪	⑫
			
Middle support foot 2 Qty: 2	Right short foot Qty: 1	Left short foot Qty: 1	Bed-end transverse tube Qty: 1


# Board Identification

Not actual size


- ⑬




Right baffle  
Qty: 1
- ⑭




Left baffle  
Qty: 1
- ⑮




Bedside panel  
Qty: 1
- ⑯




Bedside middle transverse plate  
Qty: 1
- ⑰




Top panel  
Qty: 1
- ⑱




Bedside partition  
Qty: 2
- ⑲




Bedside backboard  
Qty: 1
- ⑳




Bedside Side bottom plate  
Qty: 2
- ㉑




Bedside Side laminate  
Qty: 6
- ㉒



Right front panel  
Qty: 1
- ㉓






Left front panel  
Qty: 1
- ㉔





Right back plate  
Qty: 1


## STEP21






  
M8x14mm  
Ⓐ X2

  
M8x60mm  
Ⓓ X4


  
5x5  
Ⓕ X1



# Board Identification


Not actual size

Ⓗ




Left back plate  
Qty: 1

Ⓗ




Bed-end board  
Qty: 1

Ⓗ




Laminated pin  
Qty: 26

Ⓗ




Yellow plastic parts  
Qty: 4

Ⓗ




LED strip  
Qty: 1

Ⓗ




LED strip clip  
Qty: 6

Ⓗ




Socket  
Qty: 1


# Part List




BOLT  
spare: 1




BOLT  
spare: 1




BOLT  
spare: 1




BOLT  
spare: 1




SCREW  
spare: 1




SCREW  
spare: 1




CONFIRMAT SCREW  
spare: 1




CAM BOLT  
spare: 1




CAM LOCK  
spare: 2




CAM LOCK  
spare: 2




WOOD DOWEL  
spare: 1



HEX KEY





HEX KEY






CROSS RIM WRWNCH


## STEP19




Before you install this screw, please  
make sure the screw size is M8\*60mm




	
M8x14mm	
A	X4



	
5x5	
L	X1



Before you install this screw, please make sure the screw size is M8\*14mm



Please tighten the screws to 80% first, and tighten all screws 100% after all parts are assembled.




Part List


Cam Lock Fastening System

Insert the cam bolt into the hole first, then insert the cam lock and lock it.


1



2




3




The opening must point toward the edge of the board

4






# Board Identification




Not actual size




## STEP17






STEP16




Before you install this screw,please  
make sure the screw size is M8\*40mm




STEP1



STEP2




STEP15







STEP14




STEP3




STEP4

  
ST 4.2x12mm


(E) X2





(N) X1

  
100 100 100


(U) X1




Please tighten the screws to 80% first, and tighten all screws 100% after all parts are assembled.




STEP13

  
M8x14mm

(A) X2


  
M8x30mm

(B) X5



  
5x5

(L) X1


- 1.Connect foot tube(11)(10)with tube(12), then tighten it with bolt(A).
- 2.Install the metal frame on the footboard (26) with bolt(B).



Please tighten the screws to 80% first, and tighten all screws 100% after all parts are assembled.





STEP12




X2


STEP5









## STEP6



## STEP11








STEP10






Proper orientation of CAM LOCK

STEP7



Proper orientation of CAM LOCK

STEP8



STEP9

