

INSTRUCTION MANUAL

Fireplace Log Rack with Tools

NOTICE

Please retain these instructions for future reference.

- Please do not exceed the weight limitations of this item.
- Do not stand on or use any part of this item as a step ladder.
- Firmly secure all bolts, screws and knobs before use.
- Reconfirm that all bolts, screws, and knobs are secure every 90 days.
- Fasten screws loosely during initial assembly. Do not fully tighten screws until the item is completely assembled.
- Be aware that some parts are heavy and have sharp edges.
- If any parts are missing, broken, damaged, or worn, stop using this product until repairs are made and/or factory replacement parts are installed.
- Do not use this item in a way inconsistent with the manufacturer's instructions as this could void the product warranty.

TOOLS REQUIRED



55 LBS
CAPACITY



1 PERSON
ASSEMBLY



UP TO 15 MIN.
ASSEMBLY

HARDWARE

1 M6 x 12mm
BOLT



8 PCS


2 M6 CAP NUT



8 PCS

PARTS

A SIDE



2 PCS

B TOP SHELF




1 PC

C BOTTOM SHELF



1 PC

D FIREPLACE
TOOLS




1 SET

PRODUCT ASSEMBLY


1

Attach the part C bottom to two part A sides with four part 1 screws and four part 2 nuts. Attach the part B top shelf with four part 1 screws and four part 2 nuts.



2

Hang the part D fireplace tools, two on each side.



HELP CENTER



Chat Support



Product Inquiry



Orders FAQ



Product Assembly



Returns & Refunds

PRODUCT WARRANTY INFORMATION

All items can be returned for any reason within 60 days of the receipt and will receive a full refund as long as the item is returned in its original product packaging and all accessories from its original shipment are included. All returned items will receive a full refund back to the original payment method. All returned items will not be charged a re-stocking fee.

All returned items require an RA (Return Authorization) number, which can only be provided by a Customer Service Representative when the return request is submitted. Items received without an RA may not be accepted or may increase your return processing time. Once an item has been received by us, refunds or replacements will be processed within 5 business days.

All returns must be shipped back to the Return Center at the customer's expense. If the reason for return is a result of an error then we will provide a pre-paid shipping label via email. Boxes for return shipping will not be provided and is the customer's responsibility to either use the original shipping boxes or purchase new boxes.

Pictures may be required for some returns to ensure an item is not damaged prior to its return. Items returned are not considered undamaged until they are received and verified as such. All damages to items are the customer's responsibility until the item has been received by and acknowledge as undamaged.



WARNING

Manufacturer and seller expressly disclaim any and all liability for personal injury, property damage or loss, whether direct, indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, unapproved modification, or neglect of this product.