



**ULTRA-LUXURY  
WATER FILTER  
HAND SHOWER  
with Pause Switch**

**Easy Hand-tighten Installation  
with Advanced Crack-resistant  
Nylon Connection Nut**

Nylon seals better than metal! It can stretch and bend around worn or damaged shower arm threads, for secure leak-free connection, yet will not break!

1. Remove old shower head by turning it counter-clockwise. Remove any excess material left on Shower Arm threads. Use steel wool if necessary.
2. Make sure Thick Washer is positioned FLAT and STRAIGHT inside Connection Nut of Bracket (Fig. 1, 4). Hand tighten Connection Nut onto Shower Arm.

**WARNING:** DO NOT OVERTIGHTEN Connection Nut as it may cause Washer to dislocate and be squeezed into Shower Arm. If leakage occurs, see below.

3. Turn Holder clockwise to position Hose Outlet pointing Down (Fig. 1). If it does not turn, loosen Ball Joint Nut slightly by turning it in CLOCKWISE Direction (Fig. 1), then tighten it back after you are done.
4. Turn on water to check for leakage. If leakage occurs, follow instructions below.
5. Screw Hose with Hose Washer in place onto Hose Outlet (Fig. 2). Screw Handle with Hose Washer in place onto other Hose end (Fig. 3), then insert Handle into Holder (Fig. 4).

**IMPORTANT: Hand tighten connections ONLY. DO NOT use wrench or pliers.**

DO NOT overtighten - this may cause washer to bend and be pushed into shower arm.  
Use plumber's tape ONLY if needed on shower arm thread if Washer fails to stop leakage.  
DO NOT use plumber's tape on any other connections.

NOTE: If your shower arm has a ball on the end of it instead of thread, it will not work with this shower and will need to be replaced with a standard shower arm available at most plumbing supply stores.

**If Leakage Occurs at Shower Arm Connection, Reattach Bracket**

Such leak is caused by Thick Washer not seated correctly or not pressing evenly against Shower Arm edge. To seal properly, Washer must stay FLAT and STRAIGHT inside Nut (Fig. A). Completely unscrew Bracket from Shower Arm, then hand-tighten it back on. This simple step should re-orient and straighten out Thick Washer eliminating leakage. If leakage still remains, other options include: a) flipping Thick Washer up-side-down and/or b) wrapping some Plumber's Tape (provided) around Shower Arm threads.

**Low Water Pressure? You can remove Water Flow Regulator.**

As mandated by U.S. federal law, this hand shower is equipped with water flow regulator that limits maximum water flow to 2.5 gallons (9.5 liters) per minute at 80 psi water pressure. In areas with extremely low water pressure causing the shower water flow to be unsatisfactory, the flow regulator may be removed to improve the water flow in the shower head.

Using screwdriver point or long nose pliers, pull out Water Regulator located inside Shower Handle (fig. B).

