

# ASSEMBLY INSTRUCTIONS

## ASSEMBLY

1.5 Hours

2 -Person Assembly

Tools Required (Not Provided):

## REQUIREMENTS

Assembly Time

(Approximate)



Phillips Screwdriver



Flat Head Screwdriver



### Thank you for purchasing our product!

Please refer and use this assembly instruction to assemble the product.  
Contact our customer service department in case there are any missing or damage parts or hardware.  
Replacement parts are normally shipped within 2 or 3 days.

**We appreciate your business!**

**PRODUCTS PURCHASED THROUGH OUR AUTHORIZED VENDORS ONLY ARE ELIGIBLE FOR REPLACEMENT PARTS.**

**THIS PRODUCT IS FOR INDOOR AND HOUSEHOLD USE ONLY - NOT FOR COMMERCIAL USE.**

### ASSEMBLY PREPARATION

1. Remove all packaging materials, staples and packing straps from the carton.
2. Refer to Parts List and Hardware List and ensure they are correct before assembly.  
Contact customer service for missing parts.
3. Place all wooden parts on a clean, flat and soft surface (e.g. carpet or rug) to prevent parts from getting scratched.

### SAFETY PRECAUTION

1. KEEP ALL HARDWARE PARTS OUT OF REACH OF CHILDREN.
2. DISPOSE PLASTIC PACKAGING MATERIAL IMMEDIATELY TO AVOID ANY RISK OF SUFFOCATION TO CHILDREN AND ANIMALS.


### TIPS FOR ASSEMBLY

1. Allow ample room for assembly and in close proximity to where product will be placed.
2. Assemble the product on a surface that does not scratch or damage the exterior gloss and finish of the furniture.
3. Identify all of the parts, hardware and quantities required for each step.
4. During assembly, do not over-tighten any fittings as this may cause damage.
5. DO NOT USE POWER TOOLS TO ASSEMBLE THIS PRODUCT.
6. Always place the product on a flat, level surface.
7. Do not sit or stand on the partially assembled product; only use the product for which it is intended.




















### CARE AND MAINTENANCE

1. Wipe clean with a soft, dry cloth; avoid the use of harsh chemicals or household cleaners as they may damage the exterior finish of the furniture.
2. Hardware may loosen over time. Periodically, check that all connections are tight; re-tighten as necessary.
3. Solid wood is impacted by heat and humidity fluctuations which may cause small joint separations or hairline cracks; place the furniture away from direct sunlight and air conditioning vents, heating vents or units to protect the furniture.

## ASSEMBLY INSTRUCTIONS

























## Hardware List

ITEM	DESCRIPTION	PART	QTY	ITEM	DESCRIPTION	PART	QTY
A	Metal Drawer Glide		2 sets	K	Screw 4X30mm		16 pcs
B	Side Door Hinge		4 pcs	L	Supporter		4 pcs
C	Middle Door Hinge		4 pcs	M	Glass Supporter		16 pcs
D	Screw 4X12mm		34 pcs	N	Screw 2.5X12mm		32 pcs
E	Cam Bolt 6X35mm		32 pcs	O	Screw 5X40mm		2 pcs
F	Camlock 15X12mm		32 pcs	P	Wooden Leg		2 pcs
G	Wooden Dowel 6X30mm		30 pcs	Q	Plastic Anchor		2 pcs
H	Metal Handle		6 pcs	R	Screw 3.5X40mm		2 pcs
I	Handle Bolt 4X16mm		12 pcs	S	Bracket		2 pcs
J	Screw 3.5X12mm		16 pcs				


# ASSEMBLY INSTRUCTIONS

## Parts List


ITEM	DESCRIPTION	PART	QTY	ITEM	DESCRIPTION	PART	QTY
1	Top Panel		1 pc	12	Drawer Front Panel		2 pcs
2	Bottom Panel		1 pc	13	Drawer Left Side Panel		2 pcs
3	Bottom Front Rail		1 pc	14	Drawer Right Side Panel		2 pcs
4	Bottom Back Rail		1 pc	15	Drawer Back Panel		2 pcs
5	Bottom Side Rail		2 pcs	16	Drawer Bottom Panel		2 pcs
6	Left Divide Panel		1 pc	17	Side Back Panel 805X297X3mm		2 pcs
7	Right Divide Panel		1 pc	18	Middle Back Panel 805X284X3mm		2 pcs
8	Left Side Panel		1 pc	19	H Back Rail		1 pc
9	Right Side Panel		1 pc	20	Left Middle Door		1 pc
10	Adjus Middle Shelf		1 pc	21	Right Middle Door		1 pc
11	Adjus Side Shelf		4 pcs	22	Side Door		2 pcs

# ASSEMBLY INSTRUCTIONS

## ASSEMBLY OVERVIEW



# INSTRUCTIONS FOR CAM-BOLT AND CAM-LOCK




CAM-BOLT




CAM-LOCK


## Tools Required




### INSERTING AND TIGHTENING CAM-BOLT



Place Cam-bolt on pre-drilled hole and screw in vertically.




Shoulder is flushed (on the same level) with the panel.



Shoulder is above the panel.

Place Cam-bolt to the designated pre-drilled holes on the panel. Use a Phillips Screwdriver to tighten Cam-bolt vertically until shoulder is flushed (on the same level) with panel. Do not over-tighten or under-tighten.

### INSERTING CAM-LOCK




Insert Cam-lock with arrow align to Cam-bolt head.

CORRECT

WRONG


Align the arrow on the Cam-lock to the Cam-bolt head and insert the Cam-lock. Ensure Cam-lock is fully inserted.

### TIGHTENING CAM-LOCK





Use a Flat-head Screwdriver to turn Cam-lock clockwise so it locks onto the head of the Cam-bolt. Turn until it is snug (about 3/4ths of a turn) -- over-tightening could damage Cam-lock or/and Cam-bolt.

## STEP 1



DO NOT USE POWER TOOLS


	2 pcs
	4 pcs
	16 pcs





X 2

1. Assemble drawer side panel (13 & 14), drawer back panel (15) and drawer bottom panel (16) together by using screws (K). Do not overtighten.
2. Assemble the metal handle (H) to drawer front panel (12) by using handle bolt (I).
3. Assemble the drawer front panel (12) to drawer by using screws (K). Do not overtighten.


## STEP 2



Right




Left



X 2


	2 sets
	8 pcs



DO NOT USE POWER TOOLS


1. Assemble the metal drawer glide (A) to drawer side panel (13 & 14) by using screws (J). **Important:** Please separate the left and right metal drawer glide as shown.

## STEP 3




1. Attach the right metal drawer glide (A) to right divide panel (7) by using screws (J).  
**Important:** Please choose the right hole as shown.
2. Attach the left metal drawer glide (A) to left divide panel (6) by using screws (J).  
**Important:** Please choose the right hole as shown.

## STEP 4




	16 pcs
	4 pcs




DO NOT USE POWER TOOLS

1. Screw the cam bolts (E) to bottom panel (2), bottom front rail (3) and bottom back rail (4).
2. Insert the wooden dowel (G) to bottom front rail (3) and bottom back rail (4).

## STEP 5





	4 pcs
--	-------




DO NOT USE POWER TOOLS

1. Attach the bottom front rail (3) and bottom back rail (4) to bottom side rails (5) as shown.
2. Insert the camlocks (F) to the holes on bottom side rails (5) then rotate clockwise to secure cam bolt in place.

## STEP 6




	12 pcs
	10 pcs
	2 pcs



DO NOT USE POWER TOOLS


1. Attach the wooden leg (P) to bottom panel (2) by using screw (O).
2. Insert the wooden dowels (G) to the holes on bottom frame.
3. Attach the bottom panel (2) to the bottom frame.
4. Insert the camlocks (F) to the holes on bottom frame then rotate clockwise to secure cam bolt in place.

## STEP 7




1. Screw the cam bolts (E) to top panel (1) and bottom panel (2).
4. Attach Bracket (S) to (1) by using Screw (D) as shown.

## STEP 8





1. Insert the wooden dowel (G) to the holes on bottom panel (2).
2. Attach the left side panel (8), left divide panel (6), right divide panel (7) and right side panel (9) to the bottom base as shown.
3. Insert the camlocks (F) to the holes on left side panel (8), left divide panel (6), right divide panel (7) and right side panel (9) then rotate clockwise to secure cam bolt in place.

## STEP 9




	8 pcs
	8 pcs





DO NOT USE POWER TOOLS

1. Insert the wooden dowels to the holes from step 8.
2. Attach the top panel (1) to the unit from step 8.
2. Insert the camlocks (F) to the holes from step 8 then rotate clockwise to secure cam bolt in place.

## STEP 10






	32 pcs
---	--------



1. On a soft, clean surface, turn the unit from step 9.
2. Attach the side back panels (17) and middle back panels (18) to the unit from step 9.
3. Joint two middle back panel (18) by using H back rail (19) as shown.
4. Assemble the back panels by using screws (N).


## STEP 11

	2 pcs
	2 pcs




1. Drill two holes in the dry wall as per the length and diameter of Plastic Anchor (Q) and the distance between the holes and the height need to be the same as the screw holes on Bracket (S).
2. Press Plastic anchor (Q) into the 2 drilled holes. Ensure that the anchor fits securely in the wall.
3. Drive Screw (R) through the screw hole on Bracket (S) into the screw hole on (Q) to secure the Buffet to the wall.

## STEP 12




1. Turn back the unit.
2. Insert the supports (L), then insert adjustable middle shelf (10).
3. Insert the glass supports (M), rotate the screw anticlockwise, insert adjustable side shelves (11), then rotate the screw clockwise to fix the shelves as shown.
4. Insert the drawers as shown.

## STEP 13




1. Assemble the metal handles (H) to the doors (20, 21 and 22) by using handle bolts (I).
2. Attach the side door hinges (B) to side doors (22) by using screws (D).
3. Attach the middle door hinges (C) to left middle door (20) and right middle door (21) by using screws (D).

## STEP 14




1. Attach the side doors (22) to the left side panel (8) and right side panel (9) by using screws (D).
2. Attach the left middle door (20) and right middle door (21) to the left divider panel (6) and right divider panel (7) by using screws (D).

## STEP 15 - A



If find the big gap between Side Doors (22) and Side Panels (8 & 9), please turning the screw on hinge as shown. It is same for the gap between Middle Doors (20 & 21) and Divide Panels (6 & 7).


## STEP 15 - B



If find the big gap between Side Doors (22) and Drawer Front Panels (12) or Middle Door (20 & 21), please turning the screw on hinge as shown.

---

## STEP 15 - C



If necessary, please adjust the height for the door by turning the screws on the hinge as shown.