












## ASSEMBLY INSTRUCTION

Product Name : **WINE CABINET**

<b>PARTS LIST</b>			
Before you begin, please layout all parts and ensure you have the correct count.			
PARTS	DESCRIPTION	QUANTITY	ILLUSTRATION
1	Drawer Panel	1	
2A	Drawer Side Panel Left	1	
2B	Drawer Side Panel Right	1	
3	Drawer Back Panel	1	
4	Drawer Bottom Panel	1	







### PARTS LIST

Before you begin, please layout all parts and ensure you have the correct count.

PARTS	DESCRIPTION	QUANTITY	ILLUSTRATION
5A	Door - Left	1	
5B	Door - Right	1	
6	Top Panel	1	
7	Top Panel Back	1	
8	Middle Panel	1	
9	Division Panel	1	












### PARTS LIST

Before you begin, please layout all parts and ensure you have the correct count.

PARTS	DESCRIPTION	QUANTITY	ILLUSTRATION
10	Shelf	1	
11	Shelf With Wine Support Bar	2	
12	Bottom Panel	1	
13	Side Panel-Left	1	
14	Side Panel-Right	1	
15	Back Panel - Small	1	












## PARTS LIST

Before you begin, please layout all parts and ensure you have the correct count.

PARTS	DESCRIPTION	QUANTITY	ILLUSTRATION
16	Back Panel - Big	1	
17A	Leg	2	
17B	Leg	2	
18	Side Stretcher	2	
19	Table Top Tempered Glass	1	
A	Handle	2	
B	Allen Key M4 x 100mm	1	
C	Allen Key M5	1	
D	Support Shelf	12	
E	Cam-Lock 12mm	12	
F	Cam-Bolt 34mm	12	








## PARTS LIST

Before you begin, please layout all parts and ensure you have the correct count.

PARTS	DESCRIPTION	QUANTITY	ILLUSTRATION
G	Plastic Corner	8	
H	JCBC Bolt M6 x 45mm	4	
I	JCBB Bolt M8 x 60mm	4	
J	Spring Washer 5 / 16"	4	
K	Washer Flat 5 / 16"	4	
L	Wood Dowel M6 x 30mm	3	
M	Wood Dowel M8 x 30mm	12	
N	Magnetic Catches	2	
O	Screw M3 x 12mm (Black)	16	
P	Screw M3 x 16mm (Black)	4	
Q	Screw M3.5 x 12mm	8	

## PARTS LIST

Before you begin, please layout all parts and ensure you have the correct count.

PARTS	DESCRIPTION	QUANTITY	ILLUSTRATION
R	Screw M3 x 20mm	8	
S	Screw M4 x 25mm (Black)	4	
T	Screw #8 x 1 1/2" (Black)	4	
U	Screw #8 x 1 1/4" (Black)	8	
V	Rubber Footing 10Ømm	4	
W	Height Adjuster M6 x 23mm	4	
X	Wine Glass Holder	2	

# INSTRUCTIONS FOR FASTING CAM-BOLT AND CAM-LOCK





**CAM-BOLT**




**CAM-LOCK**

## INSERTING AND TIGHTENING CAM-BOLT

Inserting Cam-bolt into the pre-drilled hole. Use a Philips Screwdriver to tighten until shoulder is snug and flushed with the panel. See illustrations below.




Shoulder is flushed (on the same level) with the panel.




Shoulder is above the panel.

## INSERTING CAM-LOCK

Align the arrow on the Cam-lock to the Cam-bolt head and insert the cam-lock.





## TIGHTENING CAM-LOCK



Cam-Bolt head needs to be in center

Use a Flat-head Screwdriver to turn the Cam-lock clockwise to lock onto the head of the Cam-bolt. Turn until it is snug - over tightening could damage Cam-lock or/and Cam-bolt.

## ASSEMBLY INSTRUCTIONS

STEPS	DESCRIPTION	ILLUSTRATION
1	<p>Place Middle Panel (8) on a material that does not scratch or damage its surface.</p> <p>Insert and tight Cam-Bolt (F) using a Philips Screwdriver. <b>(Not Provided).</b></p> <p>Place Bottom Panel (12) , Side Panel Left (13) and Side Panel-Right (14) as shown.</p> <p>Insert and tighten Cam-Bolt (F) by using Philips Screwdriver. <b>(Not Provided).</b></p>	
2	<p>Insert Wood Dowel (M) to Middle Panel (8) and Bottom Panel (12) as shown.</p> <p>Insert Cam-Lock (E) into designated holes on Division Panel (9) then turn clockwise to lock onto Cam-Bolt (F) on Bottom Panel (12).</p> <p>Attach the Middle Panel (8) to Division Panel (9) into designated holes then turn clockwise to lock onto Cam-Bolt (F) on Middle Panel (8).</p>	



## ASSEMBLY INSTRUCTIONS

STEPS	DESCRIPTION	ILLUSTRATION
3	<p>Insert Wood Dowel (L) into Top Panel Back (7) as shown.</p> <p>Use Screw (S) to fasten Top Panel (6) to Top Panel Back (7) by using Philips Screwdriver. <b>(Not Provided).</b></p>	
4	<p>Insert Wood Dowel (M) into Top Panel (6) as shown.</p> <p>Insert Cam-Lock (E) into designated holes on Top Panel (6) then turn clockwise to lock onto Cam-Bolt (F) on Side Panel-Right (14).</p>	

## ASSEMBLY INSTRUCTIONS

STEPS	DESCRIPTION	ILLUSTRATION
5	<p>Insert Cam-Lock (E) into designated holes on Middle Panel (8) then turn clockwise to lock onto Cam-Bolt (F) on Side Panel-Right (14).</p> <p>Attach the Bottom Panel (12) to Side Panel-Right (14) with JCBC Bolt (H) by using Allen Key (B).</p>	<p>The illustration for Step 5 shows a partial assembly of the cabinet. A callout box labeled 'Parts 8,9 &amp; 12' points to the middle panel (8), side panel-right (9), and bottom panel (12). A detailed inset shows an Allen key (B) being used to tighten a JCBC bolt (H) through the bottom panel (12) into the side panel-right (14). Another inset shows a cam-lock (E) being inserted into a hole in the middle panel (8) and turned clockwise to engage with a cam-bolt (F) in the side panel-right (14).</p>
6	<p>Install Back Panel-Small (15) and Back Panel-Big (16) by inserting at Top Panel (6), Middle Panel (8) and Bottom Panel (12) into groove on Side Panel-Right (14).</p> <p>Insert Cam-Lock (E) into designated holes on Top Panel (6) and Middle Panel (8) then turn clockwise to lock onto Cam-Bolt (F) on Side Panel-Left (13).</p> <p>Attach Bottom Panel (12) to Side Panel-Left (13) with JCBC Bolt (H) by using Allen Key (B).</p>	<p>The illustration for Step 6 shows the cabinet with the back panels being installed. A callout box labeled 'Parts 13, 15, 16' points to the side panel-left (13), back panel-small (15), and back panel-big (16). A detailed inset shows an Allen key (B) being used to tighten a JCBC bolt (H) through the bottom panel (12) into the side panel-left (13). Another inset shows a cam-lock (E) being inserted into a hole in the top panel (6) and turned clockwise to engage with a cam-bolt (F) in the side panel-left (13).</p>

## ASSEMBLY INSTRUCTIONS

STEPS	DESCRIPTION	ILLUSTRATION
7	<p>Attach Leg (17A) and Leg (17B) to corner block at Bottom Panel (12) with JCBB Bolt (I) , Spring Washer (J) and Flat Washer (K) by using Allen Key (C).</p>	
8	<p>Fit Side Stretcher (18) between Leg (17A) and Leg (17B) as shown.</p> <p>Fasten the Leg (17A) and (17B) with JCBB Bolt (I) , Spring Washer (J) and Flat Washer (K) by using Allen Key (C).</p>	



## ASSEMBLY INSTRUCTIONS

STEPS	DESCRIPTION	ILLUSTRATION
9	<p>Use Screw (T) to fasten Side Stretcher (18) to Leg (17A) and Leg (17B) as shown by using Philips Screwdriver. <b>(Not Provided).</b></p> <p>Place the Wine Glass Holder (X) on Top Panel (6). Use Screw (Q) with align pre-hole on Top Panel (6) by using Philips Screwdriver. <b>(Not Provided).</b></p>	<p>The illustration shows a 3D view of the wine cabinet's upper section. It highlights the side stretchers (18) being attached to the legs (17A and 17B) using screws (T). A callout shows a screw (T) being driven into a leg. Another callout shows a screw (Q) being used to secure a wine glass holder (X) to the top panel (6) through a pre-drilled hole. The pre-hole is indicated by a dashed box labeled 'Pre-Hole'.</p>
10	<p>Insert the Height Adjuster (W) into the Leg (17A) and Leg (17B) as shown.</p> <p>Place the Magnetic Catches (N) with align pre-hole on Top Panel (6) by using Philips Screwdriver. <b>(Not Provided).</b></p>	<p>The illustration shows the wine cabinet with height adjusters (W) being inserted into the legs (17A and 17B). A callout shows a height adjuster (W) being placed into a leg. Another callout shows magnetic catches (N) being secured to the top panel (6) using screws (P) through pre-drilled holes. The pre-hole is indicated by a dashed box labeled 'Pre-Hole'.</p>

## ASSEMBLY INSTRUCTIONS

STEPS	DESCRIPTION	ILLUSTRATION
11	<p>Refer to Drawing 11A</p> <p>Attach Drawer Side Panel-Left (2A) and Drawer Side Panel-Right (2B) to Drawer Front Panel (1) as shown - note the groove on each panel has to be aligned. Use Screw (U) to fasten side panels. Do not tighten screws completely until both screws are in place in each panel.</p> <p>Refer to Drawing 11B</p> <p>Fit Drawer Bottom Panel (4) between drawer side panels by inserting the short edge of Drawer Bottom Panel (4) into the groove on the side panel.</p> <p>Check that Drawer Bottom Panel (4) fits into the groove on Drawer Front Panel (1). Next, fit Drawer Back Panel (3) between drawer side panels and check that the top edge of Drawer Bottom Panel (4) fits into the groove on the under-side of Drawer Back Panel (3).</p> <p>Refer to Drawing 14C</p> <p>Use Screw (U) to fasten Drawer Back Panel (3) to Drawer Side Panels. Do not tighten screws completely until both screws are in place in each panel.</p>	<p style="text-align: right;">Drawing 11A</p> <p style="text-align: right;">Drawing 11B</p> <p style="text-align: right;">Drawing 11C</p>

## ASSEMBLY INSTRUCTIONS

STEPS	DESCRIPTION	ILLUSTRATION
12	<p>Insert the assembly drawer as shown.</p> <p>Tear off the Rubber Footing (V) and stick according the illustration and place at Top Panel (6)</p>	
13	<p>Insert Support Shelf (D) into designated holes as shown. Use a mallet (<b>Not Provided</b>) to tap lightly if necessary.</p> <p>Place Shelf (10) and Shelf With Wine Support Bar (11) into the Bar Cabinet with all shelves sit on Shelf Support (D).</p>	

## ASSEMBLY INSTRUCTIONS

STEPS	DESCRIPTION	ILLUSTRATION
14	<p>Place Hinge on Left Door (5A) to align the screw holes to the pilot holes on the Side Panel -Left(13). Use Philips Screwdriver (Not Provided) to drive Screw (O) to fasten hinge to the Side Panel-Left (13).</p> <p>Do not tighten the screw completely until all 6 screws are in place on both hinge.</p> <p>Use the same procedure above to install Right Door (5B).</p> <p>Place the Handle (A) as shown with use Screw (O) by using Philips Screwdriver. <b>(Not Provided)</b>.</p> <p>Place the Table Top Tempered Glass (19) on Top Panel (6) as shown.</p>	

# ASSEMBLY INSTRUCTIONS


STEPS

DESCRIPTION


ILLUSTRATION

15





Attach the Plastic Corner (G) at the back side bar cabinet.  
Use Screw (R) by using Philips Screwdriver. **(Not Provided)**.



BACK VIEW




## ANTI-TIPPING

1		= 4	2		= 2	3		= 2	4		= 2
---	---	-----	---	---	-----	---	--	-----	---	---	-----

### ▲ WARNING

Serious or fatal crushing injuries can occur from tipping furniture.  
To help prevent tip-over : **ALWAYS** secure this furniture to the wall using Cabinet Restraint Device.

See product instructions for more ways to help prevent furniture tip-over.





## HOW TO AFFIX THE SAFETY STRAP

Installation Instruction :

This tie restraint must be attached to a wall stud using the 2" screw enclosed.

1. Attach a Metal Bracket (1) securely to the back top rail of the furniture using the Pan Head Screw (Short) (4) provided, through the smaller mounting position.
2. Attach the other Metal Bracket (1) on the wall over a wall stud and 2 inches below the mounting bracket secured to the back of your unit. Attach to the wall stud using the Pan Head Screw (Long) (3) provided , through the smaller mounting position.
3. Place the furniture into position so both mounting brackets are vertically in line.
4. Lace the end of the Cabinet Restraint Strap (2) through the larger mounting position in each mounting bracket.  
Bring both ends together and slide the flat end through the locking end and draw it through until all slack is removed.
5. Confirm that the Cabinet Restraint Strap (2) is securely laced and locked.



**ASSEMBLY TIPS :**

Please check parts and hardware before assembling. Follow each instruction step by step.  
Place a protective pad or piece of cardboard on the floor while assembling your item on top of it.  
Remove all parts from the carton and separate them into part numbers / groups as indicated on the part list.  
Please follow instructions in the sequence as numbered to assure fast / easy assembly.

**WARNING :**

Don't attempt to repair or modify parts that are broken or defective - if you find a broken part contact your retailer for replacement.  
Keep all hardware parts out of the reach of children.

**FURNITURE CARE :**

Following these few basic steps will help to ensure that you enjoy your furniture for a long time.  
Do not expose your furniture to direct sunlight, dampness or any heat, like a hot cup of coffee or tea. Always use a coaster.  
Excessive exposure to sunlight may cause fading.  
Excessive temperature and humidity or cold may cause cracking or splitting.  
Dust with a clean, damp, lint free cloth.  
Use a damp cloth with water or mild detergent to clean all surfaces - do not use chemicals or paint thinner which will fade the surface.  
Place a piece of felt or a pad under the legs of your furniture to avoid scratching the floor.