









ASSEMBLY INSTRUCTION






End Table





LIST OF HARDWARE

1	 M5/16"	QTY
		1PC
2	 M5/16"x5/8"	QTY
		4PCS
3	 M5/16"	QTY
		8PCS
4	 M5/16"x18mm	QTY
		8PCS
5	 M5/16"x1/2"	QTY
		8PCS
6	 M5/16"x1-1/4"	QTY
		4PCS
7	 M5/32"x5/8"	QTY
		2PCS

LIST OF PART



A		QTY
		1PC
B		QTY
		2PCS
C		QTY
		2PCS
D		QTY
		1PC
E		QTY
		2PCS

1st Step:

1	5
1PC	4PCS
 M5/16"	 M5/16"x1/2"





firstly,Lay top(A)
face-down on a clear
and smooth surface.



Then attach Left
leg(B) to Top(A) with
allen head bolt(5).Use
allen wrench(1) to
tighten the
bolts.Don't fully
tighten !As in
shown.Right leg (C) is
the same as Left
Leg(B).



2nd





Step: Insert stretcher(E) into hole in legs(B,C) WITH FLAT WASHER(4), spring washer(3), allen head bolt(2). Use allen wrench(1) to tighten the bolts. Don't fully tighten! As in shown.



1	2	3	4
1PC	2PCS	2PCS	2PCS
 M5/16"	 M5/16" x 5/8"	 M5/16"	 M5/16" x 18mm









3rd

Step: Get out the drawer from cabinet(D) and put it face front. keep cabinet(D) to legs(B,C) with flat washer(4), spring washer(3), allen head bolt(6), use allen wrench(1) to tighten the bolts. Don't fully tighten. As in shown.


1	6	3	4
1PC	2PCS	2PCS	2PCS
 M5/16"	 M5/16" x 1 1/4"	 M5/16"	 M5/16" x 18mm



4th Step:

1	2	3	4	5	6
1PC	2PCS	4PCS	4PCS	4PCS	2PCS
 M5/16"	 M5/16"x5/8"	 M5/16"	 M5/16"x18mm	 M5/16"x1/2"	 M5/16"x1 1/4"

Connect stretcher(D) with another left(B) with flat washer(4), spring washer(3), allen wrench(1) to tighten the bolts. Finally, pls tighten fully all the bolts. As in shown the diagram.



5th Step:

7

4PCS



M5/32"x5/8"

Turn the assembly table upright position. Then get the drawer knob in drawer out. Use the flat head cross screw(7) to tighten the drawer knob onto the drawer. Pls tighten fully the screws. Finally, place the drawer into the cabinet. As In shown.

