


10'x10'

HARDTOP GAZEBO

ASSEMBLY MANUAL





1. Two or more people are required for assembly.



2. You will need one or more stepladders.




3. Wearing protective gloves is recommended.



4. You may need a safety hat.



5. Use the hex keys in the box.




6. Please use a Phillips screwdriver.




7. Do not fully tighten screws prior to complete assembly.




8. For ease of construction, you may need to use a drill.



AX4




JX4



J1X4



CX4



BX4




KX96



LX4




MX4




C1X4



DX4



NX1



N1X1




PX4



P1X4




D1X4



EX4



E1X4




GX4




G1X4


ITEM	DESCRIPTION	QTY
A	Pole	4
C	Beam	4
C1	Beam	4
D	Corner Roof Bar	4
D1	Roof Bar	4
E	Finishing Bar	4
E1	Finishing Bar	4
G	Solidifying Bar	4
G1	Solidifying Bar	4
J	Corner Solidifying Bar	4
J1	Corner Solidifying Bar	4
B	Base	4
K	Hook	96
L	Joint Cover	4
M	Corner Cover	4
N	Outside Roof Connector	1
N1	Inside Roof Connector	1
P	Finishing End	4
P1	Finishing End	4




QX4




Q1X4




Q2X4




Q3X4




Q4X4




Q5X4




SX4




S1X4




UX88




VX1




WX4





XX56



X1X4



X2X4

M6x12
AAX97+8M5x10
BBX16+2ST4.8x12
IX24+2M6x28
OX56+4M6x45
RX24+2M6x8
TX4+1M6x25
YX4+1M6x50
ZX4+1

ITEM	DESCRIPTION	QTY
Q	Panels	4
Q1	Panels	4
Q2	Panels	4
Q3	Panels	4
Q4	Panels	4
Q5	Panels	4
S	Solide Sidewall	4
S1	Mosquito Sidewal	4
U	Spacer	88
V	Allen Key/Wrench	1/1
W	Joint Cover	4
X	Metal Bracket	56
X1	Metal Bracket	4
X2	Metal Bracket	4
AA	Screws	97+8
BB	Screws	16+2
I	Screws	24+2
O	Screws	56+4
R	Screws	24+2
T	Screws	4+1
Y	Screws	4+1
Z	Screws	4+1

Parts Required:



(A) X4



(B) X4




M5x10


(BB) X12

Step 1:

Set up poles (Part A) with stand palettes (Part B) using screws BB as shown in diagram.



Parts Required:



(C) X4



(C1) X4



(K) X96



M6x12

(AA) X16




S4


(V) X1

Step 2:

Put 6 Hooks to each slot of sidewall track (Part C and C1). Connect Part C and Part C1 into one beam using screws AA.





Parts Required:




Step 3:

Use screws AA to connect poles and beams together as shown in diagram.




Step 4:


Finish connecting beams using corner covers (Part M) and screws I as shown in diagram.




Parts Required:




Step 5:



Affix the frame with corner solidifying bars (Part J and J1) using screws AA as shown in diagram.





Parts Required:




Step 6:

Connect the inside roof connector (Part N1) with the corner roof bar (Part D) using screws AA as shown in diagram.



Parts Required:



(D1) X4



M6x12

(AA) X12




S4

(V) X1


Step 7:

Attach roof bar (Part D1) to inside roof connector using screws AA as shown in diagram.



Attach roof bar (Part D1) to main frame using screws AA as shown in diagram.

Parts Required:



(N) X1



M6x12

(AA) X1




S4


(V) X1

Step 8:


Connect outside roof connector (Part N) to inside roof connector (Part N1) using screws AA as shown in diagram.



Parts Required:



(G) X4



(G1) X4



M6x12

(AA) X4



M6x8

(T) X4




S4










(V) X1

Step 9:

Affix solidifying bar (Part G and G1) to roof bar (Part D1) and corner roof bar (Part D) using screws (AA and T) as shown in diagram.




Parts Required:


-  Q X4
-  Q1 X4
-  Q2 X4
-  Q3 X4
-  Q4 X4
-  Q5 X4
-  X X56
-  X1 X4
-  X2 X4

Step 10:







Cover metal brackets (Part X, X1 and X2) to roof panels as shown in diagram.



Overall roof assembly:







Parts Required:




Step 11 :


Affix roof panels using screws and spacer (Part U) as shown in diagram.



Parts Required:



Ⓔ x4



E1 X4



Ⓟ X4




P1 X4



M6x12


AA X8



V x1

Step 12:


Affix finishing bars (Part E & E1) by (Part P & P1) using screws AA to roof bar and corner roof bar as shown in diagram.




Parts Required:



(K) 48x







(S) 4x






(S1) 4x

Step 13: Hang up solid sidewall as shown in diagram.



Attention: Change hook: take out Part W and Part K into the slot.



In the end check all screws are fixed tightly before using.