


## ASSEMBLY INSTRUCTIONS

1. Unpack all parts from cartons carefully;
2. Fasten the tube (B) onto lamp base (A) until tight,  
be careful not to twist power cord, tighten securely;
3. Place the tube (C) onto the tube (B);
4. Place the tube (D) onto the tube (C);
5. Place the part (E) onto the tube (D);
6. Place the socket assembly (F) onto the tube (E);
7. Place the pole (G) onto the socket assembly (F);
8. Place the shade (H) onto the pole ( G );
9. Fasten the finial ( I ) onto the pole ( G ) until tight.

### IMPORTANT SAFETY INSTRUCTIONS

THIS PORTABLE LAMP HAS A POLARIZED PLUG (ONE BLADE IS WIDER THAN THE OTHER) AS A SAFETY FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK. THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF THE PLUG DOES NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS PLUG CAN BE FULLY INSERTED. DO NOT ALTER THE PLUG.



## ASSEMBLY INSTRUCTIONS

1. Unpack all parts from cartons carefully;
2. Fasten the tube (B) onto lamp base (A) until tight,  
be careful not to twist power cord, tighten securely;
3. Place the tube (C) onto the tube (B);
4. Place the tube (D) onto the tube (C);
5. Place the part (E) onto the tube (D);
6. Place the socket assembly (F) onto the tube (E);
7. Place the pole (G) onto the socket assembly (F);
8. Place the shade (H) onto the pole ( G );
9. Fasten the finial ( I ) onto the pole ( G ) until tight.

### IMPORTANT SAFETY INSTRUCTIONS

THIS PORTABLE LAMP HAS A POLARIZED PLUG (ONE BLADE IS WIDER THAN THE OTHER) AS A SAFETY FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK. THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF THE PLUG DOES NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS PLUG CAN BE FULLY INSERTED. DO NOT ALTER THE PLUG.

